




VSCC Single Screw Compressor Subcritical CO₂ Unit

Installation, Operation & Maintenance Manual



VILTER
by **COPELAND**

Important Message



READ CAREFULLY BEFORE INSTALLING AND STARTING YOUR COMPRESSOR.

The following instructions have been prepared to assist in installation, operation and removal of Vilter™ Single Screw Compressors. Following these instructions will result in a long life of the compressor with satisfactory operation.

The entire manual should be reviewed before attempting to install, operate, service or repair the compressor.

Only qualified personnel shall operate, install and maintain the equipment.

Qualified personnel shall be accredited by a local regulatory agency, which requires that they are continually scrutinized by an organization whose sole mission is to establish, maintain and assure that the highest industry standards are set and met in a continuous and ongoing basis. The credentials shall address topics ranging from plant safety, operating concepts and principles and operations through the basics of refrigeration compliance and PSM (Process Safety Management) requirements.

Follow local workplace occupational safety and health regulations.

A compressor is a positive displacement machine. It is designed to compress gas. The compressor must not be subjected to liquid carry over. Care must be exercised in properly designing and maintaining the system to prevent conditions that could lead to liquid carry over. Vilter Manufacturing is not responsible for the system or the controls needed to prevent liquid carry over and as such Vilter Manufacturing cannot warrant equipment damaged by improperly protected or operating systems.

Vilter™ screw compressor components are thoroughly inspected at the factory. However, damage can occur in shipment. For this reason, the equipment should be thoroughly inspected upon arrival. Any damage noted should be reported immediately to the Transportation Company. This way, an authorized agent can examine the unit, determine the extent of damage and take necessary steps to rectify the claim with no serious or costly delays. At the same time, the local Vilter representative or the home office should be notified of any claim made.

All inquiries should include the Vilter™ sales order number, compressor serial and model number. These can be found on the compressor name plate on the compressor.

All requests for information, services or parts should be directed to:

Copeland Industrial LP (Vilter)
Customer Service Department
5555 South Packard Ave
Cudahy, WI 53110 USA
Telephone: 1-414-373-7615; Fax: 1-414-744-3483
E-mail: info.vilter@copeland.com; Web: Copeland.com/Vilter

Equipment Identification Numbers:

Vilter Order Number: _____ Compressor Serial Number: _____
Vilter Order Number: _____ Compressor Serial Number: _____
Vilter Order Number: _____ Compressor Serial Number: _____
Vilter Order Number: _____ Compressor Serial Number: _____

Important Documents

Standard VILTER™ Warranty Statement

It is now on the web site. You can access it here:

Go to www.Copeland.com/Vilter, then scroll down to find Lifecycle Services -> Warranty Information

Or click directly:

[Warranty Information | Copeland US](#)

The EC Declaration of Incorporation

It is now on the web site. You can access it here:

Go to www.Copeland.com/Vilter, then scroll down to find Lifecycle Services -> Compliance -> Legal & Compliance

Or click below directly:

[EC Declaration of Incorporation - Single Screw Compressor](#)

Table of Contents

Section Title	Page Number
Important Message.....	i
Important Documents	ii
Standard VILTER™ Warranty Statement	ii
The EC Declaration of Incorporation.....	ii
Section 1 • General Information	
How To Use This Manual	1-1
Additional Important Notes	1-1
Refrigeration Compressor Unit Model Designations	1-2
System Unit Identification	1-3
Bare Shaft Compressor	1-3
Compressor Unit.....	1-3
Package Unit.....	1-3
Compressor Unit Component Identification	1-4
Configured Compressor Unit Component Identification - HPLD.....	1-7
Grounding Wire Location	1-9
Instrument Identification Letters	1-10
Symbol Identification	1-12
Major Component Identification	1-12
Control and Instrument Identification	1-13
Line Type Designations.....	1-13
Valve and Instrument Tagging	1-14
Equipment Number Identification	1-14
Equipment Type.....	1-14
Pipe Line Data Identification.....	1-15
Section 2 • Theory of Operation	
Refrigerant Flow.....	2-2
Oil Life and Oil Flow.....	2-2
Oil Cooling	2-2
Glycol Cooled Oil Cooling.....	2-2
Liquid Injection Oil Cooling	2-2
Suction Oil Injection (SOI) for Single Screw Compressors	2-3
Control System	2-3
Temperature Elements, Pressure Transmitters and Indicators.....	2-4
Section 3 • Installation	
Delivery Inspection	3-1
Rigging and Lifting of Compressor Unit	3-1
Compressor Unit Inspections Prior To Installation and Storage	3-2
Recommended On-site Tools	3-2
Long Term Storage Recommendations.....	3-2
Compressor Motor.....	3-3
Foundation	3-5
Considerations Prior To Starting.....	3-5
Foundation Materials	3-5
Building The Foundation	3-5
Compressor Unit Installation.....	3-6
Leveling and Grouting	3-7
Additional Information.....	3-8
Operation and Performance.....	3-8

Table of Contents

Section Title	Page Number
General Design Requirements	3-8
Piping	3-11
Compressor Unit Discharge Piping	3-12
Check Valve and Stop Valve Shipped Loose For Field Installation	3-12
Flange Loads	3-13
Electrical Connections.....	3-14
Field Wiring Instructions	3-14
Testing Refrigeration System For Leaks.....	3-18
CO ₂ Systems	3-18
Evacuating The System	3-19
Notice on Using Non -Vilter Oils	3-20
Unit Initial Oil Charging and Priming.....	3-20
Tool Required.....	3-20
Unit Initial Oil Charging	3-21
Priming Oil Lines and Compressor (Unit With Oil Pump).....	3-21
Unit Initial Oil Charging without Compressor Oil Pump – For CO ₂ Subcritical HPLD Units Only	3-22
System Refrigerant Charging.....	3-23
A. Low Side Equipment	3-23
B. Compressors.....	3-23
C. Condensers.....	3-23
D. Controls.....	3-23
Initial High Side Charging	3-23

Section 4 • Operation

Notice on Using Non-Vilter Oils	4-1
Operation	4-1
Oil Inspection.....	4-1
Dual Oil Filters.....	4-2
Control System	4-2
Calibration.....	4-2
Starting, Stopping and Restarting The Compressor.....	4-2
Starting	4-2
Stopping/Restarting	4-2
Emergency Shutdown.....	4-3
Slide Valve Actuator Operation.....	4-3
Calibrate Slide Valve Actuators (For VSCC 291 - 601 Units Using Vission 20/20™)	4-4
Compressor Control with Vission 20/20™ Micro-controller (No Slide Operation).....	4-10
Coalescing Oil Return Line Setup	4-11
Suction Equalizing Line Setup.....	4-12
Oil Cooling	4-13
Dual Oil Filter Setup For Oil Filters with Filter Head Assemblies	4-14

Section 5 • Maintenance/Service

Maintenance and Service Schedule	5-1
Follow this table for maintaining and servicing the compressor unit at hourly intervals.	5-1
Preventive Maintenance, Checks and Services	5-2
Daily	5-2
Weekly.....	5-2
Monthly	5-2
Trimonthly.....	5-2
Annually	5-2

Table of Contents

Section Title	Page Number
Compressor Unit Isolation For Maintenance/Service (Compressors with Slide Valves).....	5-3
Recommendations when Servicing (Compressors without Slide Valves).....	5-4
Preparation of Unit For Servicing.....	5-4
Compressor Unit Leak Check After Servicing.....	5-5
Oil System Components.....	5-5
Oil Sampling.....	5-5
Recommendations.....	5-5
Installation of The Oil Sampler Valve.....	5-6
Pre-Sampling.....	5-6
Sampling Procedure.....	5-6
Oil Sample Analysis Report.....	5-8
Oil Draining.....	5-9
Oil Charging.....	5-10
Tool Required.....	5-10
Charging During Operation.....	5-10
Charging During Shutdown.....	5-10
Filter Element Replacement.....	5-11
Removal.....	5-11
Installation.....	5-12
Switching Oil Filters For Maintenance (Reference Figure 5-11).....	5-13
Oil Pump Strainer Servicing.....	5-14
Oil Separator Coalescing Filter Replacement.....	5-15
Removal.....	5-15
Installation.....	5-15
Oil Separator Heater Cartridge Replacement.....	5-17
Parts Required.....	5-17
Removal.....	5-17
Installation.....	5-17
Pressure Relief Valve.....	5-18
Service and Maintenance.....	5-18
Replacement.....	5-18
Lovejoy Quick Flex Standard Coupling Installation.....	5-19
Installation.....	5-19
Standard Coupling with High-Speed Cover.....	5-21
QUICK FLEX Insert.....	5-22
Storage of Components.....	5-22
Drive Coupling Hub (Form-Flex BPU) Installation.....	5-23
Straight Bore Hubs.....	5-23
Tapered Bore Hubs.....	5-23
Drive Center Member Installation and Alignment.....	5-24
Drive Coupling Hub (Form-Flex BPU) and Center Member Removal.....	5-26
Drive Coupling (Type C Sure-Flex) Replacement.....	5-26
Removal.....	5-26
Installation.....	5-27
Coupling Guard Replacement.....	5-28
Removal.....	5-28
Installation.....	5-28
Compressor Replacement.....	5-29
Removal.....	5-29
Installation.....	5-30
Bareshaft Compressor Lifting Points and Weights.....	5-31
Bareshaft Compressor Center of Gravity (Models 291-601).....	5-33
Suction Tee Strainer Replacement (For Compressors VSCC 128 - 243).....	5-34
Compressor Inspection.....	5-36
Compressor Shaft Bearing Clearance Inspections.....	5-36

Table of Contents

Section Title	Page Number
Determine Maximum Applied Force.....	5-36
Main Rotor Bearing Axial Clearance Inspection.....	5-36
Gaterotor Bearing Inspection.....	5-38
Gaterotor Inspection.....	5-39
A) Gaterotor - Main Housing Shelf Clearance.....	5-39
B) Gaterotor Float Measurement.....	5-40
C) Gaterotor Backlash Inspection.....	5-41
Important Notes.....	5-43
Additional Inspections.....	5-43
Post Inspection.....	5-43
Gaterotor Assembly Replacement (For VSCC 291 - 601).....	5-43
Removal.....	5-43
Installation.....	5-45
Gaterotor Removal and Installation (For VSCC 128 - 243).....	5-47
Use Gaterotor Tool Set: A25205G and A24061A.....	5-47
Removal.....	5-47
Installation (Refer to Figure 5-49).....	5-51
Gaterotor Disassembly (For VSCC 128 - 243).....	5-53
Gaterotor Blade Removal.....	5-53
Gaterotor Blade Installation.....	5-53
Gaterotor Ball Bearing Removal.....	5-54
Gaterotor Ball Bearing Installation.....	5-54
Gaterotor Roller Bearing Removal.....	5-55
Gaterotor Roller Bearing Installation.....	5-55
Gaterotor Disassembly (For VSCC 291 - 601).....	5-56
Gaterotor Blade Removal.....	5-56
Gaterotor Blade Installation.....	5-56
Gaterotor Thrust Bearing Removal.....	5-57
Gaterotor Thrust Bearing Installation.....	5-57
Compressor Shaft Seal Replacement.....	5-58
Shaft Seal Assembly.....	5-58
Compressor Shaft Seal Replacement.....	5-59
Shaft Seal Removal.....	5-59
Prior to Shaft Seal Installation.....	5-60
Shaft Seal Installation.....	5-61
Slide Valve Actuator Assembly Replacement.....	5-62
Removal.....	5-62
Installation.....	5-62
Actuator Installation Using Anti-Rotation Bolts.....	5-63
Slide Valve Command Shaft Assembly Replacement.....	5-64
Removal.....	5-64
Installation.....	5-64
Liquid Injection Control Valve Station (Danfoss ICF 20-40 Valve Station).....	5-65
Main Rotor Assembly.....	5-67
Torque Specifications.....	5-67
Using A Torque Wrench Correctly.....	5-69
Nord-Lock® Washers.....	5-69

Section 6 • Troubleshooting

Slide Valve Actuator Troubleshooting Guide.....	6-1
Slide Valve Actuator LED Blink Codes.....	6-4
Troubleshooting Guide - General Problems and Solutions with Oil Pump.....	6-6
Troubleshooting Guide - General Problems and Solutions for Units Without Oil Pump.....	6-9

Table of Contents

Section Title	Page Number
Section 7 • Warranty and Parts	
Warranty Claim Processing.....	7-1
Process For Returning Products Covered By the Warranty	7-1
Procedure For Parts Not Manufactured By Vilter™.....	7-1
Motor Warranty Procedure	7-2
On-Site Service Support	7-3
Remanufactured Bare Shaft Single Screw Compressor Process	7-3
Explanation of Rebuild Levels	7-3
Bare Shaft Compressor Description.....	7-3
Section 8 • Spare Parts List	
How to Read a Parts List and Illustration	8-1
Item Number	8-1
Description	8-1
Model Number.....	8-1
VPN	8-1
Quantity	8-1
Assembly and Kit Information	8-1
Terms and Abbreviation Used.....	8-1
Important Notes	8-1
Vilter™ Aftermarket Parts Contact Information.....	8-1
Compressor Models VSCC 128 - 243 (HPLD) Recommended Spare Parts List	8-2
VSCC 128 - 243 Compressor Kits.....	8-3
Suction Covers	8-4
Discharge Manifold	8-5
Housing	8-6
Compressor Models VSCC 291 - 601 (240MM) Recommended Spare Parts List	8-7
Gaterotor	8-8
Shaft Seal.....	8-11
Main Rotor	8-12
Slide Valve Cross Shafts and End Plate	8-13
Slide Valve Carriage Assembly	8-15
Actuator and Command Shaft.....	8-17
Miscellaneous Frame Components	8-18
Miscellaneous Frame Components (Tubing and Fittings)	8-20
Replacement Tools	8-22
Appendices	
Appendix A • Torque Specifications	A-1
Appendix B • Vilter Oil	B-1
Appendix C • Vibration Measurements - Single Screw Compressor	C-1
Appendix D • Liquid Injection Valve Setup Instructions and Quick Start Guide	D-1
Appendix E • Liquid Injection Valve Station ICF 20-25 Installation Guide	E-1
Appendix F • Hand-Held Slide Valve Calibration Tool.....	F-1

Table of Contents

Section Title	Page Number
List of Tables and Figures	
Tables	
Table 3-1. Maximum Allowable Flange Loads.....	3-13
Table 4-1. Command Shaft Rotation Specifications*	4-8
Table 5-1. Maintenance/Service Schedule.....	5-1
Table 5-2. Oil Filter Replacement Parts Required.....	5-11
Table 5-3. QUICK FLEX Standard Coupling Misalignment Tolerances	5-20
Table 5-4. QUICK FLEX Standard Coupling with High Speed Cover Dimensions	5-21
Table 5-5. QUICK FLEX Insert Dimensions.....	5-22
Table 5-6. Shaft and Hub Distances	5-23
Table 5-7. Hub Clamp Bolt and Set Screw Torque Specifications	5-24
Table 5-8. Disc Pack Installation Torque Specifications.....	5-24
Table 5-9. Clamping Bolts and Set Screw Torque Specifications	5-27
Table 5-10. Bareshaft Compressor Component Weights.....	5-31
Table 5-11. Bareshaft Compressor Component Lifting Hole Sizes	5-31
Table 5-13. Maximum Main Rotor Bearing Clearance.....	5-37
Table 5-14. Maximum Gaterotor Bearing Clearance.....	5-38
Table 5-15. Gaterotor Float.....	5-40
Table 5-16. Backlash Range	5-42
Table 5-17. Gaterotor Tool Kits	5-43
Table 5-18. Some of the Shaft Seals	5-59
Table 5-19. Coils for Solenoid Valves (ICFE)	5-66
Table 5-20. Parts for Motorized Valve Station (ICF)	5-66
Table 5-21. Torque Specifications (ft-lbs) (For Compressors Only)	5-67
Table 5-22. SA193 B7/SA320 L7 Bolts / Studs – Torque Requirements Per ASME Codes: B31.5 and B31.3	5-68
Table 6-1. Slide Valve Actuator Troubleshooting Guide (1 of 3).....	6-1
Table 6-1. Slide Valve Actuator Troubleshooting Guide (2 of 3).....	6-2
Table 6-1. Slide Valve Actuator Troubleshooting Guide (3 of 3).....	6-3
Table 6-2. Slide Valve Actuator LED Blink Codes ^(o) (1 of 2)	6-4
Table 6-2. Slide Valve Actuator LED Blink Codes ^(o) (2 of 2)	6-5
Table 6-3. Troubleshooting Guide - General Problems and Solutions with Oil Pump (1 of 3).....	6-6
Table 6-3. Troubleshooting Guide - General Problems and Solutions with Oil Pump (2 of 3).....	6-7
Table 6-3. Troubleshooting Guide - General Problems and Solutions with Oil Pump (3 of 3).....	6-8
Table 6-4. Troubleshooting Guide - General Problems and Solutions for Units WITHOUT Oil Pump (1 of 2).....	6-9
Table 6-4. Troubleshooting Guide - General Problems and Solutions for Units WITHOUT Oil Pump (2 of 2).....	6-10
Figures	
Figure 1-1. CO ₂ Compressor Unit Components for Models VSCC 291 - 601 (1 of 3).....	1-4
Figure 1-1. CO ₂ Compressor Unit Components for Models VSCC 291 to 601 (2 of 3).....	1-5
Figure 1-1. CO ₂ Compressor Unit Components for Models VSCC 291 - 601 (3 of 3).....	1-6
Figure 1-2. CO ₂ Compressor Unit Components for Models VSCC 128 to 243 (1 of 3).....	1-7
Figure 1-2. CO ₂ Compressor Unit Components for Models VSCC 128 to 243 (2 of 3).....	1-8
Figure 1-2. CO ₂ Compressor Unit Components for Models VSCC 128 to 243 (3 of 3).....	1-8
Figure 1-3. The Grounding-wire Hole Location on Housing for Various Single Screw Compressor Models VSCC 128 - 243	1-9
Figure 1-4. The Grounding-wire Hole Location on Housing for Various Single Screw Compressor Models VSCC 291 - 601	1-9

Table of Contents

Table / Figure	Page Number
Figure 2-1. CO ₂ Sub-critical Refrigeration	2-1
Figure 2-2. Suction Oil Injection	2-3
Figure 2-3. Block and Bleed Arrangement.....	2-4
Figure 3-1. Rigging and Lifting Points (HPLD Compressor Unit Shown).....	3-1
Figure 3-2. Concrete Pad with Compressor Unit Dimensions - Side View	3-6
Figure 3-3. Concrete Pad with Compressor Unit Dimensions - Front View.....	3-7
Figure 3-4. Interior Foundation Isolation.....	3-7
Figure 3-5. Foundation with Housekeeping Pads Dimensions - Top View	3-8
Figure 3-6. Housekeeping Pad Dimension Detail - Top View	3-9
Figure 3-7. Level Compressor Unit Using Top Surface of Spherical Washers	3-9
Figure 3-8. Concrete Pad Housekeeping Detail	3-10
Figure 3-9. Maximum Allowable Flange Loads	3-13
Figure 3-10. Example - Vission 20/20 Wiring Diagram	3-15
Figure 3-11. Example - Interconnect Wiring Diagram	3-16
Figure 3-12. Example - V-PLUS Wiring Diagram	3-17
Figure 3-13. Oil Operating Levels.....	3-20
Figure 3-14. Oil Drain Valve	3-21
Figure 3-15. Priming Oil Lines and Compressor (With Oil Pump).....	3-21
Figure 3-16. Unit Initial Oil Charging without Compressor Oil Pump – For CO ₂ Subcritical HPLD Units Only	3-22
Figure 4-1. Oil Operating Levels.....	4-1
Figure 4-2. Actuator Assembly	4-4
Figure 4-3. Slide Valve Calibration Screen (Vission 20/20)	4-5
Figure 4-4. Menu Screen and Slide Calibration Button (Vission 20/20).....	4-6
Figure 4-5. Wire Connections for Capacity and Volume Actuators.....	4-7
Figure 4-6. Photo-chopper	4-9
Figure 4-7. Vission 20/20 Configuration Screen - I/O Configuration (Screen 8)	4-10
Figure 4-8. Compressor and Model Setup with Vission 20/20	4-10
Figure 4-9. Coalescing Oil Return Line	4-11
Figure 4-10. Suction Equalizing Line and Valve	4-12
Figure 4-11. Liquid Injection Variations	4-13
Figure 4-12. Dual Oil Filter Setup for Oil Filters with Manifold Heads	4-14
Figure 5-1. Discharge Bleed Valve, Suction Equalizing Line and Valve.....	5-3
Figure 5-2. Oil Analysis Kit (VPN 3097A).....	5-6
Figure 5-3. Oil Sampler Valve (VPN #3708A) For Gas Compression Applications	5-6
Figure 5-4. Oil Sampling Valve (VPN #3709A) For Ammonia and Refrigerant Compressors	5-7
Figure 5-5. Operating the Oil Sampling Valve	5-7
Figure 5-6. Stages of the Oil Sample Taking Process.....	5-8
Figure 5-7. Oil Strainer Drain Valve and Oil Separator Drain Valve	5-9
Figure 5-8. Suction Oil Charging Valve.....	5-10
Figure 5-9. Oil Filter Inlet, Drain and Shut-Off Valves.....	5-11
Figure 5-10. Filter Assembly (VPN 3677A Oil Filter Housing Shown)	5-12
Figure 5-11. Dual Oil Filter (3677A Oil Filter Housings Shown).....	5-13
Figure 5-12. Oil Pump Strainer and Drain Valve	5-14
Figure 5-13. Oil Separators, Manhole Covers and Coalescing Filter Assemblies	5-16
Figure 5-14. Heater Cartridges	5-17
Figure 5-15. Three-way Dual Shut-off Pressure Relief Valve (Back Seated).....	5-18
Figure 5-16. Standard Coupling with High-Speed Cover	5-19
Figure 5-17. Standard Coupling Cutaway - with Blue Insert.....	5-19
Figure 5-18. Proper Shaft-to-Hub Engagement	5-19
Figure 5-19. Types of Misalignment.....	5-20
Figure 5-20. High Speed Cover	5-21
Figure 5-21. Standard Coupling with High-Speed Cover	5-21

Table of Contents

Table / Figure	Page Number
Figure 5-22. High Speed Cover	5-22
Figure 5-23. Hub Distance (Axial Spacing)	5-24
Figure 5-24. Angular Alignment and Parallel Offset	5-25
Figure 5-25. Coupling Guard Assembly (VPN A27435C shown)	5-28
Figure 5-26. Compressor Replacement and Hardware Assembly	5-29
Figure 5-27. Bareshaft Compressor Lifting Points and Component Weights	5-31
Figure 5-29. Bareshaft Compressor Assembly Center of Gravity (Models 291-601)	5-33
Figure 5-30. Bareshaft Compressor Center of Gravity - Discharge Manifold and Main Compressor Assembly (Models 291-601)	5-33
Figure 5-31. Tool (A24061A) To Handle Suction Tee Assembly	5-35
Figure 5-32. Bearing Axial Clearance Inspection	5-36
Figure 5-33. Bearing Radial Clearance Inspection	5-37
Figure 5-34. Gaterotor Bearing Clearance	5-38
Figure 5-36. Gaterotor and Shelf Clearance Measurement Steps	5-39
Figure 5-35. Gaterotor and Shelf Clearance	5-39
Figure 5-37. Visual Inspection Between Gaterotor and Bushing	5-40
Figure 5-38. Gaterotor Float Dial Location	5-40
Figure 5-39. Gaterotor Float	5-41
Figure 5-41. Location of Dial Indicator Magnetic Base	5-41
Figure 5-40. Alignment of Gaterotor	5-41
Figure 5-42. Placement of Dial Indicator	5-42
Figure 5-43. Measuring Backlash	5-42
Figure 5-44. Chipped Edge of Gaterotor	5-43
Figure 5-45. Gaterotor Assembly Removal and Tools	5-44
Figure 5-46. Gaterotor Assembly Removal	5-45
Figure 5-47. Gaterotor Assembly and Tools	5-46
Figure 5-48. Gaterotor and Shelf Clearance	5-46
Figure 5-49. Rotor Position for Gaterotor/Support Assembly Removal	5-47
Figure 5-50. Gaterotor/Support Assembly Removal	5-47
Figure 5-51. Gaterotor Assembly	5-48
Figure 5-31. Tool (A24061A) To Handle Suction Tee Assembly	5-49
Figure 5-52. Tool To Remove Bearing Housing Assembly	5-50
Figure 5-53. Tool To Install and Remove Bearing Housing Assembly	5-50
Figure 5-54. Tool To Install Bearing Housing Assembly	5-51
Figure 5-55. Check the Clearance Between the Gaterotor and Shelf	5-52
Figure 5-56. Gaterotor and Support Assembly	5-53
Figure 5-57. Gaterotor Top Face Identification	5-53
Figure 5-58. Gaterotor Ball Bearing	5-54
Figure 5-59. Gaterotor Roller Bearing Assembly	5-55
Figure 5-60. Gaterotor Blade Assembly	5-56
Figure 5-61. Gaterotor Blade Installation	5-56
Figure 5-62. Gaterotor Thrust Bearing	5-57
Figure 5-63. Thrust Bearing Installation	5-57
Figure 5-64. Shaft Seal Assembly	5-58
Figure 5-65. Handling Seal Face with Care	5-58
Figure 5-66. Shaft Seal Breakdown (25985Y, 25985YA, and 25985YF)	5-59
Figure 5-68. Shaft Seal Housing	5-60
Figure 5-67. Shaft with Pin	5-60
Figure 5-69. The Alignment of Compressor Shaft and Mating Ring	5-60
Figure 5-66. Shaft Seal Breakdown (25985Y, 25985YA, and 25985YF)	5-61
Figure 5-70. Mounting for Command Shaft D Style	5-62
Figure 5-71. Actuator Installation Using Anti-Rotation Bolts	5-63
Figure 5-72. Command Shaft Assembly Replacement	5-64
Figure 5-73. Danfoss ICF 20-40 Valve Station (Liquid Injection Control)	5-65

Section 1 • General Information

How To Use This Manual

This manual contains instructions for refrigeration compressor units. It has been divided into eight sections and Appendices:

Section 1: General Information

Section 2: Theory of Operation

Section 3: Installation

Section 4: Operation

Section 5: Maintenance and Service

Section 6: Troubleshooting

Section 7: Warranty and Parts

Section 8: Spare Parts List

Appendices

Appendix A: Torque Specifications

Appendix B: Vilter Oil

Appendix C: Vibration Measurements - Single Screw Compressor

Appendix D: Liquid Injection Valve Setup Instructions and ICM/ICAD Motorized Valve Quick Start Guide


Appendix E: Liquid Injection Valve Station ICF 20-40 Installation Guide


Appendix F: Hand-Held Slide Valve Calibration Tool

It is highly recommended that the manual be reviewed prior to servicing system parts.

Figures and tables are included to illustrate key concepts.

NOTE:

The symbol  at the bottom of every page:

Click the symbol . It will take you back to your previous page.

Safety precautions are shown throughout the manual. They are defined as the following:

NOTICE - Notice statements are shown when there are important information that shall be followed. Not following such notices may result in void of warranty, serious fines, serious injury and/or death.

WARNING - Warning statements are shown when there are hazardous situations, if not avoided, will result in serious injury and/or death.

CAUTION - Caution statements are shown when there are potentially hazardous situations, if not avoided, will result in damage to equipment.

NOTE - Notes are shown when there are additional information pertaining to the instructions explained.


Additional Important Notes

- Additional installation, operation and maintenance instructions can be found in the Vission 20/20 Manual (35391SC) or Compact Logix PLC Software Manual (35391CM).
- Due to continuing changes and unit updates, always refer to the website www.Vilter.com to make sure you have the latest manual.
- Any suggestions of manual improvements can be made to Vilter™ Manufacturing at the contact information on Page iii.

Section 1 • General Information

Refrigeration Compressor Unit Model Designations

The compressor unit model designation can be found on the nameplate. For nameplate location, see Compressor Unit Component Identification section on Page 1-4.




System Unit Identification

To keep definitions of units simple and consistent, Vilter™ has defined the following three:

- Bare Shaft Compressor
- Compressor Unit
- Package Unit


Bare Shaft Compressor

A bare shaft compressor is just the compressor with no coupling and motor nor foundation.



Compressor Unit

A compressor unit consists of the bare shaft compressor with the coupling, motor, oil separator, frame, micro-controller system and oil system. A compressor unit typically a single screw compressor unit, is not mounted on a structural steel base.



Package Unit

A package unit is a complete system mounted on a structural steel base with interconnecting piping.



Section 1 • General Information

Compressor Unit Component Identification

Each refrigeration compressor unit may differ, but below are typical components that can be found on each unit.

1 - Motor	6 - Suction Strainer	11 - Vission 20/20 HMI
2 - Motor Conduit Box	7 - Suction Check Valve	12 - Oil Drain/Fill Valve
3 - Coupling and Guard	8 - Suction Stop Valve	13 - Frame
4 - Suction Oil Charging Valve	9 - Compressor	14 - Oil Sight Glass
5 - Thermometer (Optional)	10 - Discharge Pipe	15 - Oil Pump Strainer




Figure 1-1. CO₂ Compressor Unit Components for Models VSCC 291 - 601 (1 of 3)

Section 1 • General Information

- | | |
|---|---|
| 16 - Oil Filter (Optional Dual Oil Filters) | 23 - Oil Separator |
| 17 - Oil Pump Motor | 24 - Discharge Connection |
| 18 - Oil Pump | 25 - Coalescing Oil Return Line |
| 19 - Oil Heater | 26 - Oil Separator Certification Nameplate |
| 20 - Oil Pressure Relief Valve | 27 - Suction Equalizing Line |
| 21 - Oil Temperature Control Valve (Oil Mixing Valve) | 39 - Connection for Suction Oil Injection (SOI) |
| 22 - Oil Cooler (Plate Heat Exchanger) | |




Figure 1-1. CO₂ Compressor Unit Components for Models VSCC 291 to 601 (2 of 3)

Section 1 • General Information

Compressor Unit Component Identification (Continued)

28 - Pressure Transducer (Filter Outlet)	32 - Temperature Element (Oil Separator)	36 - Temperature Element (Discharge)
29 - Pressure Transducer (Filter Inlet)	33 - Temperature Element (Oil Injection)	37 - Temperature Element (Suction)
30 - Pressure Transducer (Suction Pressure)	34 - Capacity Slide Valve Actuator	38 - Block & Bleed
31 - Pressure Transducer (Discharge Pressure)	35 - Volume Slide Valve Actuator	39 - Connection for Suction Oil Injection (SOI)




Figure 1-1. CO₂ Compressor Unit Components for Models VSCC 291 - 601 (3 of 3)

Section 1 • General Information

Configured Compressor Unit Component Identification - HPLD

Each refrigeration compressor unit may differ, but below are typical components that can be found on each unit.

1 - Motor	11 - Vission 20/20 HMI	20 - Oil Pump
2 - Lift Point (Motor ONLY)	12 - HMI Mounting Bracket	21 - Oil Sight Glasses
3 - Motor Conduit Box	13 - Emergency Stop Button	22 - Oil Level Switch
4 - Suction Oil Charging Valve	14 - Block & Bleed Assembly	23 - Motor Mounting Area
5 - Suction Strainer & Cover	15 - Oil Filter Out Shut-off Valve	24 - Heaters
6 - Thermometer Connection	16 - Oil Drain/Fill Valve	25 - Oil Cooler
7 - Suction Check Valve	17 - Oil Filter Assembly	26 - Oil Separator and Cover
8 - Suction Connection Port	18 - Oil Drain Valve for Oil Filter	27 - Discharge Connection
9 - Suction Stop Valve	19 - Temperature Element (Oil Separator)	28 - Lifting Point (Compressor Unit)
10 - Single Screw Compressor		29 - Connection for Suction Oil Injection (SOI)




Figure 1-2. CO₂ Compressor Unit Components for Models VSCC 128 to 243 (1 of 3)




Figure 1-2. CO₂ Compressor Unit Components for Models VSCC 128 to 243 (2 of 3)




Figure 1-2. CO₂ Compressor Unit Components for Models VSCC 128 to 243 (3 of 3)

Grounding Wire Location





Figure 1-3. The Grounding-wire Hole Location on Housing for Various Single Screw Compressor Models VSCC 128 - 243



VSCC 291, 341, 451, 601 (240mm)

Figure 1-4. The Grounding-wire Hole Location on Housing for Various Single Screw Compressor Models VSCC 291 - 601

Section 1 • General Information

Instrument Identification Letters

Use this list to identify components shown in the Piping & Identification Diagram.

A	Analysis	GAH	Gas Detected Concentration Level High	LG	Level Gauge
AAH	Concentration High			LI	Indication (Soft)/Level Sight Indicator (Glass)
AAHH	Concentration/Detection High High	GAHH	Gas Detected Concentration Level High High (Shutdown)	LIT	Level Indicating Transmitter
AI	Analysis/Moisture Indicator	H	Hand	LO	Lock Open
AIT	Analysis/Detection Indicating Transmitter	HH	Hand Hole	LSH	Level Switch High
AT	Analysis/Detection (Blind)	HO	Held Open (Solenoid Valve Only)	LSHH	Level Switch High High (Shutdown)
AU	Analysis/Detection Monitor	HV	Hand Valve	LSL	Level Switch Low
BFV	Butterfly Valve	I	Current	LSLL	Level Switch Low Low (Shutdown)
CV	Check Valve	IAH	Amperage High	LT	Level Transmitter (Blind)
E	Voltage	IAHH	Amperage High High (Shutdown)	LV	Level Control Valve
EAH	Voltage High	II	Current Indication	LY	Level/Relay/Convertor
EAHH	Voltage High High (Shutdown)	IT	Current Transmitter (Blind)	MCC	Motor Control Center
EI	Voltage Indication	J	Power	MGV	Manifold Gauge Valve
F	Flow	JB	Junction Box (Wire Termination)	NC	Normally Closed
FAH	Flow High	Jl	Power Indication	NO	Normally Open
FAHH	Flow High High (Shutdown)	JIT	Power Indicating Transmitter	NV	Needle Valve
FAL	Flow Low	JT	Power Transmitter (Blind)	P	Pressure
FALL	Flow Low Low	K	Time Schedule	PAH	Pressure High
FC	Flow Controller/Fail Close	KC	Time Controller (Blind)	PAHH	Pressure High High (Shutdown)
FG	Flow Gauge	KI	Time Indication	PAL	Pressure Low
FI	Flow Indication (Soft)/ Flow Sight Indicator (Glass)	KIC	Time Indication Controller	PALL	Pressure Low Low
FIC	Flow Indicating Controller	KR	Time Recorder	PC	Pressure Control
FIT	Flow Indicating Transmitter	KY	Time/Relay/Convertor	PDAH	Pressure Differential High
FOP	Orifice Plate	L	Level	PDAHH	Pressure Differential High High (Shutdown)
FT	Flow Transmitter (Blind)	LAH	Liquid Level High	PDAL	Pressure Differential Low
FV	Flow Control Valve	LAHH	Liquid Level High High (Shutdown)	PDALL	Pressure Differential Low Low (Shutdown)
FY	Flow/Relay/Convertor	LAL	Liquid Level Low	PDC	Pressure Differential Control
G	Gas	LALL	Liquid Level Low Low (Shutdown)	PDI	Differential Pressure Indication
GIT	Gas Detecting Indicating Transmitter	LC	Level Controller	PDIC	Pressure Differential Indicating Controller
		LE	Level Probe (Element)		















































Section 1 • General Information

PDIT	Pressure Differential Indicating Transmitter	SIC	Speed Indicating Controller	VU	Vibration Monitoring System
PDSH	Pressure Differential Switch High	T	Temperature	W	Weight
PDSHH	Pressure Differential Switch High High (Shutdown)	TC	Temperature Controller	XA	Status (Stopping/Not Running) Alarm/Common Alarm
PDSL	Pressure Differential Switch Low	TAH	Temperature High	XC	State Controller
PDSLL	Pressure Differential Switch Low Low (Shutdown)	TAHH	Temperature High High (Shutdown)	XI	Running Indication
PDT	Differential Pressure Transmitter (Blind)	TAL	Temperature Low	XV	Solenoid Valve
PDV	Pressure Differential Control Valve (Pneumatic Actuator)	TALL	Temperature Low Low (Shutdown)	XY	State Relay/Convertor
PFY	Pressure Ratio Convertor/Relay	TE	Temperature Element (RTD, Thermocouple, etc.)	Y	Event, State, Presence
PFC	Pressure Ratio Controller	TG	Temperature Gauge	YAH	Fire Alarm
PG	Pressure Gauge	TI	Temperature Indication (Soft)	YE	Fire Detecting Sensor
PI	Pressure Indication (Soft)	TIC	Temperature Indicating Controller	YIT	Fire Indicate and Transmit
PIC	Pressure Indicating Controller	TIT	Temperature Indicating Transmitter	YK	Fire Control Station
PIT	Pressure Indicating Transmitter	TRV	Transfer Valve 3-Way	Z	Position, Dimension
PSE	Pressure Rupture Disk	TSH	Temperature Switch High	ZC	Position Controller
PSH	Pressure Switch High	TSHH	Temperature Switch High High (Shutdown)	ZE	Position Element
PSHH	Pressure Switch High High (Shutdown)	TSSL	Temperature Switch Low Low (Shutdown)	ZI	Position Indicator
PSL	Pressure Switch Low	TT	Temperature Transmitter (Blind)	ZIT	Position Indicating Transmitter
PSLL	Pressure Switch Low Low (Shutdown)	TTSL	Temperature Switch Low Low (Shutdown)	ZT	Position Transmitter (Blind)
PSV	Pressure Safety Relief Valve	TV	Temperature Control Valve	ZY	Position Transmitter (Blind)
PT	Pressure Transmitter (Blind)	TW	Temperature Thermowell	ZZ	Position Actuator (Capacity or Volume)
PV	Pressure Control Valve	TY	Temperature/Relay/Convertor		
Q	Quantity and Heat	U	Multi Variable		
QE	Heater Element, Immersion, Tracing	V	Vibration, Mechanical Analysis		
R	Radiation	VE	Vibration Probe		
S	Speed, Frequency	VFD	Variable Frequency Drive		
SC	Speed Control	VG	Block/Bleed, Gauge Valve		
SD	Shutdown	VSH	Vibration Switch High		
		VSHH	Vibration Switch High High (Shutdown)		
		VT	Vibration Transmitter (Blind)		

Section 1 • General Information











Symbol Identification

Use this list to identify symbols shown in the Piping & Identification Diagram.

	3-Way Valve		Gate Valve		Regulating Valve Inlet Pressure
	3-Way Solenoid Valve		Globe Valve		Regulating Valve Outlet Pressure
	Angle Valve		Hand Expansion Valve		Rotary Valve
	Ball Valve		Heater		Rupture Disc
	Basket Strainer		Heat Trace		Schroder Valve
	Block/Bleed Gauge Valve		Insulation		Solenoid Valve
	Butterfly Valve		Man-Way Cover		Spring-Closing Drain Valve
	Check Valve		Manifold Gauge Valve		Stop/Check Valve
	Diaphragm Actuator		Motorized Ball Valve		Strainer
	Diaphragm Spring-Opposed		Needle Valve		Thermostatic Valve 3-Way
	Diaphragm Pressure-Balanced		Orifice Plate		Thermowell (SW or NPT)
	Differential Pressure Regulating Valve		Pilot Light		Thermowell (SW or NPT)
	Drive Coupling		Pipe Plug		Venturi Injector Nozzle
	Flange Set		Pipe Reducer		Vibration Absorber
	Flow/Sight Glass		Pneumatic Actuator Control Valve		Scope of Supply
			Relief Valve		


Major Component Identification

Use this list to identify major components shown in the Piping & Identification Diagram.

	Compressor		Filter		Motor
	Damper or Louver		Finned Tube Heat Exchanger		Shell and Tube Heat Exchanger
	Engine Drive		Heat Exchanger		Fan
					Tank/Drum Vessel

Section 1 • General Information

Major Component Identification (Continued)



Control and Instrument Identification

- Discrete Instrument, Field Mounted
- Discrete Instrument, Remote, Mount, Normally Accessible to Operator
- Discrete Instrument, Local Rack Mounted, Normally Accessible to Operator
- Shared Display/Control, Field Mounted
- Shared Display/Control, DCS or Remote Control Panel Normally Accessible to Operator
- Shared Display/Control, Local Control Panel Normally Accessible to Operator
- Programmable Logic Control, Field Mounted
- Safety Instrumented System, Field Mounted
- Programmable Logic Control, DCS or Remote Control Panel, Normally Accessible to Operator
- Safety Instrumented System Main Control Panel or DCS
- Programmable Logic Control, Auxiliary (Local) Control Panel, Normally Accessible to Operator
- Safety Instrumented System Auxiliary (Local) Control Panel
- Computer Function, Field Mounted
- Computer Function, DCS or Remote Control Panel, Normally Accessible to Operator
- Computer Function, Local Operator Panel, Normally Accessible to Operator
- Interlock
- Permissive

Line Type Designations

- Pneumatic Signal
- Capillary Tube
- Electrical Signal
- Internal System Link (Software or Data Link)
- Mechanical Link
- Hydraulic Signal
- Customer Field Piping
- Insulation

Section 1 • General Information

Valve and Instrument Tagging

a-bc-yz = ABC-DEFGH-IJKL
a = ABC, b = DE, c = FGH, y = IJK, z = L


- | | |
|---|--------------------------------------|
| A - Process cell or stage of compressor | D - Measured variable |
| B - Unit number in process cell or stage of compression | E - Variable Modifiers |
| C - Service in process cell or stage of compression | F - Readout or passive function |
| 1 - Gas lines | G - Output or active function |
| 2 - Coolant lines | H - Function modifier |
| 3 - Oil lube lines | I - Loop number or sequential number |
| 4 - Refrigerant lines | J - Loop number or sequential number |
| 5 - Condensate lines | K - Loop number or sequential number |
| 6 - Air lines | L - Suffix |

Sample Tag

105-LSH-300-A

- | | |
|---|---|
| 1 - First process cell or stage of compression | 3 - Loop number or sequential number |
| 0 - First unit number in process cell or stage of compression | 0 - Loop number or sequential number |
| 5 - Condensate service | 0 - Loop number or sequential number |
| L - Level | A - Another exactly the same device in the same loop as 105-LSH-300 |
| S - Switch | |
| H - High | |

Equipment Number Identification



Equipment Type

- | | |
|---|---|
| A - Agitator, Mechanical Mixers, Aerators | F - Fans |
| B - Blowers | P - Pumps |
| C - Compressors | R - Reactors |
| D - Drivers | U - Filters, Strainers |
| E - Heat Exchangers | V - Vessels, Tanks, Separators, Scrubbers |

Section 1 • General Information

Pipe Line Data Identification

AB - C - D - E - F

X - Y - Z

20-LFG-001-10-STD

PS-1-ET

A - Process cell or stage of compression

- 1 - Process cell first stage of compression
- 2 - Process cell first stage of compression
- 3 - Process cell first stage of compression
- 4 - Process cell first stage of compression
- 5 - Process cell low pressure refrigeration (booster)
- 6 - Process cell high pressure refrigeration (high stage)
- 7 - Open
- 8 - Open
- 9 - Open

B - Unit number in process cell or stage of compression

C - Service

AR - Process Air	IAS - Instrument Air Supply
BD - Blowdown	LFG - Land Fill Gas
BRR - Brine	LO - Lube Oil
CHWS - Chilled Water Supply	N - Nitrogen
CHWR - Chilled Water Return	NG - Natural Gas
CWR - Cooling Water Return	NH - Ammonia
CWS - Cooling Water Supply	PC - Process Condensate
DR - Drain	PG - Process Gas
ER - Ethylene Refrigerant	PR - Propylene Refrigerant/Propane
GLR - Glycol Return	SV - Safety Relief
GLS - Glycol Supply	SO - Seal Oil
H - Hydrogen	VC - Vacuum Condensate
HR - Hydrocarbon Refrigerant	

D - Numerical Sequence Number

E - Size

#” - Nominal Pipe Size (Inches)

F - Standard/Other Standard

STD -Vilter™

0 - Other Standard (Not Vilter™)

X - Insulation

- AC -Acoustic Control
- CC - Cold Service
- CP - Condensation Control
- N - Not Required
- PP - Personnel Protection
- PS - Process Stability
- TR - Traced (See Tracing Type)

Y - Insulation Thickness

- BO - By Others
- #” - Nominal Thickness (Inches)
- 0 - Insulation Not Required

Z - Heat Tracing

- ET - Electrical Heat Trace
- N - None




Figure 2-1. CO₂ Sub-critical Refrigeration

The refrigeration and oil systems work in unison, but each one will be explained separately. Reference Figure 2-1 for refrigerant and oil flow descriptions.

This is a typical CO₂ sub-critical refrigeration system with liquid injection and heat exchanger oil cooling options.

Section 2 • Theory of Operation

Refrigerant Flow

The refrigerant compression process begins as refrigerant vapor enters the suction inlet (12). The refrigerant vapor flows through suction stop and check valves (11), then through a strainer (10) to the compressor (9). The refrigerant is then pressurized through the compressor and discharged as high pressure refrigerant vapor into the oil separator (1). In the oil separator, the oil is then separated from the discharged refrigerant by impingement separation. The high pressure refrigerant flows out to the condenser for cooling while the oil is pumped or flowing back to the compressor.

Moreover, suction stop and check valves (11) and discharge check valve (2) are provided between the oil separator to prevent refrigerant vapor or liquid from flowing back to the compressor during shutdown periods.

Oil Life and Oil Flow

NOTE

An oil pump is not the standard offering for VSCC compressor units. See SOI Valve operation for units without an oil pump.

Oil in the refrigeration system serves three primary purposes. It provides lubrication to the compressor, sealing clearances between moving parts, and heat removal resulting from heat of compression and friction. Initially, oil flow is driven by a mechanical gear pump (3). Once the system reaches design conditions, the oil pump is shut off and oil flow is maintained by differential pressure.

As the oil is separated from the refrigerant in the oil separator (1), it is pumped or siphoned through an oil cooler (5), then through an oil filter (4) and back to the injection port (6) of the compressor (9). For additional information on oil cooling options, refer to Oil Cooling section below.

Furthermore, to collect oil from the coalescing side of the oil separator (1), an oil return line (8) is installed between the oil separator and the compressor (9). By opening the needle valve (7), this will allow oil dripping off the coalescing filters to be fed back to the compressor.

This is a continuous cycle.

Oil Cooling

There are different methods of oil cooling for Vilter™ refrigeration compressor units. Oil cooling will depend on the type of application. Below is an explanation of each method.

Glycol Cooled Oil Cooling

- In lieu of the three-way oil temperature valve to control the temperature of the oil used for lubrication and cooling of the compressor, it is required to install a liquid regulating valve and solenoid valve combination to control the glycol supply to the oil cooler. The glycol inlet connection should be made on the bottom and the outlet connection on the top. The glycol supply is controlled by the liquid regulating valve to maintain the oil temperature at approximately 120°F. The solenoid valve provides positive glycol shutoff when the compressor is not in operation. A temperature of 150°F is considered high in most circumstances and the compressor is protected by a safety control to prevent operation of the compressor above this temperature.

Liquid Injection Oil Cooling

- This type of oil cooling system is designed to maintain compressor discharge gas temperature within acceptable limits. Cooling is accomplished via injection of the liquid refrigerant into the compressor. For this purpose, a liquid injection control valve station is supplied and installed on the compressor unit. This valve station has an electronically controlled motorized actuator valve assembly that controls the flow of liquid refrigerant being injected into the compressor.
- For additional information, refer to Section 5.

Suction Oil Injection (SOI) for Single Screw Compressors

Suction Oil Injection (SOI) is Vilter's patented technology. It is used to provide immediate lubrication to the single screw compressor during the start-up.

The SOI can comprise a suction oil line and control valves, see Figure 2-2. When the power source is actuated, CO₂ gas is introduced into a suction cavity within the compressor and drawn into a compression chamber within the compressor and compressed. The compressed gas is discharged into the oil separator thereby elevating the separator vessel pressure. The elevated vessel pressure causes the oil within the separator to be transported through the suction oil line. Transportation of the oil through the suction oil line permits immediate lubrication of the compressor to occur following start-up of the compressor, immediate being a few seconds.

When the oil separator pressure reaches a pre-determined pressure, the valve in the suction oil line is closed. The closed valve results in the oil being prohibited from flowing through the suction oil line and permitted to flow through the conventional oil line. As such, the compressor remains continuously lubricated. Further, immediate lubrication can be accomplished without the need for a back-pressure valve or pump.

Control System

The compressor unit is controlled by the micro-processor, i.e. MicroVision 20/20 panel or PLC panel. This panel's main function is to control the refrigeration system from the data that it receives from the sensors around the unit. For additional information, refer to micro-processor manual (35391SC for Vision 20/20 Operating Manual or 35391CM for Compact Logix PLC Software Manual).

WARNING

Software programming credentials shall only be made available by the supplier. The user will only have access to operational features established by the supplier. Failure to comply may result in serious injury or death.




Figure 2-2. Suction Oil Injection

Section 2 • Theory of Operation

Temperature Elements, Pressure Transmitters and Indicators

Temperature elements (TE), pressure transmitters (PT) and pressure indicators (PI) are instruments used to measure temperatures and pressures at specific locations on the compressor unit.

Temperature elements are typically mounted on the compressor, suction pipe, discharge pipe, oil separator, oil filter inlet and outlet pipe.

Pressure transmitters are typically mounted on the block and bleed assembly, see Figure 2-2. The pressure transmitters measure suction pressure, inlet and outlet oil pressure, and discharge pressure in the oil separator.

Typically, pressure indicators are not mounted from the factory, except for a pressure indicator to show the nitrogen holding charge for shipping and storage purposes. If required, end users have the ability to mount pressure indicators at the block and bleed assembly.




Figure 2-3. Block and Bleed Arrangement


NOTICE

Vilter compressors are to be installed and connected to the customer-provided piping. Vilter expects this piping to be designed and built following ASME B31.3 or ASME B31.5 Process Piping Guide, plus any other local applicable codes, and that the installation will be performed by qualified personnel only.

Delivery Inspection

All equipment supplied by Vilter are thoroughly inspected at the factory. However, damage can occur in shipment. For this reason, the units should be thoroughly inspected upon arrival, prior to off-loading. Any damage noted should be photographed and reported immediately to the transportation company. This way, an authorized agent can examine the unit, determine the extent of damage and take necessary steps to rectify the claim with no serious or costly delays. At the same time, the local Vilter representative or the home office should be notified of any claims made within ten (10) days after its discovery. Refer to Compressor Unit Inspections Prior To Installation and Storage for additional recommendations.

Use lifting chains/straps and spreader bar. Evenly distribute weight. Keep lifting chains and spreader bar clear of components to prevent damage.



Rigging and Lifting of Compressor Unit

WARNING

When rigging and lifting a compressor unit, use proper lifting device capable of lifting and maneuvering the weight and size of the compressor unit. Use only qualified personnel and additional personnel and lifting equipment (i.e. spreader bar) as required. Failure to comply may result in death, serious injury and/or damage to equipment.

Only qualified personnel shall operate rigging and lifting equipment. Ensure that the lifting device is capable of lifting the weight of the compressor unit, refer to the supplied Vilter General Assembly (GA) drawing.

To lift the compressor unit, use lifting points on compressor unit frame to attach the lifting device, see Figure 3-1. There are a few points to consider prior to moving the unit:

- Ensure that the weight is evenly distributed amongst the lifting device (i.e. lifting chains and spreader bar) prior to lifting.
- Ensure that the lifting device is not obstructed by any parts of the compressor unit to prevent damage to components.
- Use additional personnel as needed to spot and aid in maneuvering the compressor unit.
- Ensure there is plenty of space to maneuver the compressor unit and a clear path to its location.




Figure 3-1. Rigging and Lifting Points (HPLD Compressor Unit Shown)

Compressor Unit Inspections Prior To Installation and Storage

The compressor unit must be inspected prior to installation since components could have come loose and/or damaged during shipment or moving.

- Check for loose bolts, particularly the compressor and motor mounting nuts.
- Check for bent or damaged components. The compressor unit should have also been inspected prior to off-loading, see Delivery Inspection.
- Check that the nitrogen pressure is still holding pressure. The pressure gauge is located at the discharge bleed valve on the block and bleed assembly. Any leaks must be fixed and the system purged and recharged with dry nitrogen.
- Look into the suction and discharge connections and inspect for any signs of corrosion on parts.
- Prelube the compressor with the main oil pump and rotate by hand several revolutions prior to start.
- Notify Vilter™ Service and Warranty Department when the compressor is started.

NOTE

For Pre Start-Up and Start-Up checklists, please contact Vilter Service and Warranty Department.

CAUTION

Before installation, follow the proper procedures to depressurize the compressor.

Recommended On-site Tools

The tools recommended to have on site are important for troubleshooting, inspection and compressor unit operation. Besides general mechanic tools, these tools are recommended:

- Oil Pump (maximum of 2-3 GPM with motor approved for Division 1 or Division 2 and with ability to overcome suction pressure) (VPN A40849A)
- Infrared Heat Gun
- Torque Wrenches (with ranges from 0 to 600 ft-lbs)
- Sockets and wrenches up to 2-1/2" (63.5 mm)
- Voltmeter

Long Term Storage Recommendations

The procedure described is a general recommendation for long term storage (over one month of no operation) of Vilter compressor units. It is the responsibility of the installation firm and end user to address any unusual conditions. Use the supplied long term storage log sheet to help with record keeping, see Page 3-4.

Warranty of the system remains in effect as described at the beginning of this manual, section Page i.

NOTE

The compressor must be inspected prior to long term storage since components could have come loose and/or damaged during shipment or moving. Refer to Compressor Unit Inspections Prior To Installation and Storage section for inspection details.

The following are recommendations regarding long term storage:

- If the unit is designed for indoor duty, it must be stored in a heated building.
- If the unit is designed for outdoor duty and is to be stored outdoors, a canvas tarp is recommended for protection until installation. Adequate drainage should be provided. Place wood blocks under the base skid so that water does not collect inside the base perimeter or low spots in the tarp.
- All compressor stop valves shall be closed to isolate the compressor from the remainder of the system. All other valves, except those venting to atmosphere, shall be open. The unit is shipped with dry nitrogen holding charge of 5 psig (5 psi above atmospheric pressure). It is essential to maintain the nitrogen holding charge.
- The holding charge of the nitrogen or clean dry gas in the system and compressor shall be monitored on a regular basis for leakage. If not already installed, it is required that a gauge shall be added to help monitor the nitrogen holding charge pressure. If a drop in pressure occurs, the source of leakage must be found and corrected. The system must be evacuated and recharged with dry nitrogen to maintain the package integrity.
- Cover all bare metal surfaces (Main rotor shaft, coupling, flange faces, etc.) with rust inhibitor.
- The volume and capacity slide valve motor enclosures should have corrosion inhibitors installed in them and the enclosures should be sealed. On a six month basis (depending on relative humidity), check and replace inhibitors as necessary, and check for signs of corrosion.

Section 3 • Installation

- Desiccant shall be placed in the control panel. If the panel is equipped with a space heater, it shall be energized. Use an approved electrical spray-on corrosion inhibitor for panel components (relays, switches, etc.).
- All pneumatic controllers and valves (Fisher, Taylor, etc.) are to be covered with plastic bags and sealed with desiccant bags inside.
- Manually rotate the compressor shaft 6 ½ revolutions every month to prevent flat spots on the bearing surfaces. If the compressor unit is installed, wired, and charged with oil, open all oil line valves and run the oil pump for 10 seconds prior to rotating the compressor shaft. Continue running the oil pump while the compressor shaft is being turned to help lubricate the surfaces of the shaft seal. For cool compression, there is no pre-lube pump, so the driveshaft must be turned by hand.
- Document all the dates in the Long Term Storage Log sheet to show that all the procedures have been completed.
- Notify Vilter Service and Warranty Department when the compressor is started.

NOTE

The Long Term Storage Log (on Page 3-4) is an interactive form. You can fill it electronically and print the page as your record.

Compressor Motor

The following are general recommendations. Refer to specific motor manufacturer instructions for storage recommendations.

- Where possible, motors should be stored indoors in a clean, dry area. The preferred condition shall be uniform temperature between 40°F (4.5°C) and 140°F (60°C) throughout the room maintained at least 10°F (5.5°C) above the dew point. Relative humidity should be at 50% or less.
- Remove the condensation drain plugs from those units equipped with them and insert silica-gel into the openings. Insert one-half pound bags of silica-gel (or other desiccant material) into the air inlets and outlets of drip-proof type motors.

NOTE

Bags must remain visible and tagged, so they will be noticed and removed when the unit is prepared for service.

- If the motors are stored outside, they should be covered completely to exclude dirt, dust, moisture, and other foreign materials and animals. However, do not wrap the motor tightly. This will allow the captive air space to breathe, minimizing formation of condensation. The motor should also be protected from flooding or harmful chemical vapors.
- If the motor is movable, it is suggested that the entire motor be encased in a strong, transparent plastic bag. Before sealing this bag, attach a moisture indicator to the side of the motor and place several bags of silica-gel desiccant around the motor inside the bag. Replace the desiccants when the moisture indicator shows that the desiccant has lost its effectiveness.

NOTE

Make sure that none of the desiccants is in contact with the heater elements.

- Whenever the motor cannot be sealed, space heaters must be installed to keep the motor at least 10°F above the ambient temperature.
- Whether indoors or outdoors, the area of storage should be free from excessive ambient vibration which can cause bearing damage.
- Inspect the rust preventative coating on all external machined surfaces, including shaft extensions. Re-coat the surfaces with a rust preventative material if needed.
- Rotate motor and compressor shafts several revolutions (approximately 6) per month to eliminate flat spots on the bearing surfaces. For motors utilizing anti-friction bearings, the shaft should be rotated once every 30 days by hand at 30 RPM for 15 seconds in each direction. Bearings should also be re-lubricated at 2-year intervals using the grease specified on the motor lubrication nameplate.
- For info regarding bearing lubricating and insulation testing, please refer to motor manufacturer's instructions.

NOTE

To claim a warranty, a full record of the above requirements will need to be submitted to Vilter. This will include Log Records and Supporting Pictures.

Long Term Storage Log

Company: _____

Sales Order Number: _____

Serial Number: _____

Name (Please Print): _____

Initial: _____

Date (MM/DD/YYYY): _____

PSIG

Nitrogen Pressure - Current

PSIG

Nitrogen Pressure - Recharged (If pressure is low, identify and fix leak prior to recharging, see Compressor Unit Leak Check procedure in Section 5 of the compressor manual)

Nitrogen Leak Location (Briefly explain nature of leak):

Compressor Shaft (Rotate shafts at least 6 revolutions)

Motor Shaft (Rotate shafts at least 6 revolutions)

Motor Bearings Greased

Air Cooled Oil Cooler Fan Rotated (If equipped)

Bare Metal Surfaces (Check all bare metal surfaces for rust and ensure they are covered with rust inhibitor)

Desiccants (Are desiccants still effective? If not, replace. Check control panel, motor, pneumatic controllers and valves)

Cover Bags/Tarp (Ensure bags and tarps are not torn and are sealed over components correctly, replace if damaged)

Valves (Stop valves are in closed position so the compressor unit is isolated. All other valves, except those venting and draining to atmosphere are to be open)

Space Heater & Panel Components (Ensure space heater is energized and panel components are rust-free)

If the compressor/unit is stored in a building: then is it heated and insulated to prevent condensation of moisture and freezing of Equipment?

YES

NO

If the compressor/unit is stored outside, please check Cover Bags/Tarp (Ensure bags and tarps are not torn and are sealed over components correctly, replace if damaged)

YES

NO

Compressor has been placed in operation as of:

DATE: _____

Foundation

Vilter™ Single Screw compressor units are low vibration machines. Under most conditions, no elaborate foundation is necessary. However a sound foundation maintains motor alignment and proper elevation, and is therefore required. Provided are recommendations for the foundation and anchoring of the compressor unit. The Vilter™ foundation supports the entire operating weight of the unit and is suitable for years of continuous duty. Included are specifications for concrete, rebar, aggregate, anchors and grout.

Considerations Prior To Starting

Consult professionals, such as building inspectors, structural engineers, geotechnical engineers and/or construction contractors prior to starting. Below are a few points to consider:

Site Characteristics

- Soil information
- Site drainage
- Wind data
- Seismic zone
- Ingress and egress
- Power and power lines

Site Layout

- Plant elevations, grading, drainage and erosion
- Accessibility to compressors for service
- Location of surrounding buildings
- Property lines and roadways
- Power
- Fire safety

Safety

NOTE

Always check with a safety engineer before proceeding.

- Arrange equipment with adequate access space for safe operation and maintenance
- Wherever possible, arrange equipment to be served by crane. If not feasible, consider other handling methods
- Follow the local building codes to establish proper ventilation

- Make all valves and devices safely accessible
- Use special bright primary color schemes to differentiate service lines
- Provide lightening protection for outdoor installations
- Relief valve venting

Foundation Materials

Materials needed to build the foundation are forms, concrete, sand, rebar, wire, grout, anchor bolts, expansion board and shims. A set of concrete forms will need to be acquired; generally, these can be rented or constructed from dimensional lumber. There should be enough 4,000 psi concrete with one inch aggregate to build the foundation. Also, there should be enough sand to provide a base of compacted sand four inches thick for the foundation to rest on, see Figure 3-2 - Concrete Pad with Compressor Unit Dimensions - Side View. The rebar required is ASTM 615, grade 60, sizes #4 and #6. Wires will also be needed to tie the rebar together. The recommended grout is Masterflow 648CP high performance non-shrink grout to provide at least a 1" thick pad under each foot. The recommended anchors are 5/8" Diameter HILTI HAS SS threaded rod for outdoor installations or HAS-E rods for indoor installations. Anchor bolts shall have a five inch projection and 12-3/8" embedment. The required adhesive is HIT-ICE/HIT/HY 150 anchoring system. There should be enough one inch expansion boards to go around the perimeter of the foundation. Finally there should be enough shim stock and extra anchor bolt nuts to level the compressor unit.

Building The Foundation

Use the Vilter™ General Arrangement (GA) and foundation drawings to help secure a building permit and foundation construction. The Vilter™ GA drawing has the necessary dimensions required to determine the overall foundation size and where to locate the compressor unit on the foundation. It also shows the dimensions required to form up the housekeeping piers that the compressor unit rests on. The Vilter™ foundation drawing lists the necessary information to construct a suitable foundation. It includes the rebar requirements and locations. It also shows anchor bolt locations, grouting and the concrete specifications. Using the Vilter™ GA drawing, Vilter foundation drawing and the information from site characteristics, site layout and safety studies will provide enough data to allow building the foundation to proceed.

The foundation is to be casted and permanently exposed against the earth. Therefore, if constructing on an existing floor, typically indoors, the floor will need to

Section 3 • Installation

Leveling and Grouting

The unit should be level in all directions. Wet the concrete pad according to the grout manufacturer's directions. Mix a sufficient amount of grout. The grout must be an expanding grout rather than shrinking to provide

a tighter bond. Follow the manufacturer's recommendations for setting, precautions, mixing, and grout placement, finishing and curing. The grout must be worked under all areas of the feet with no bubbles or voids. If the grout is settled with a slight outside slope, oil and water can run off of the base. Once the grout has cured, torque the anchor bolts as per HILTI instructions.




Figure 3-3. Concrete Pad with Compressor Unit Dimensions - Front View




Figure 3-4. Interior Foundation Isolation

Section 3 • Installation

Additional Information

Codes and Standards

Vilter™ followed the following codes and standards when designing your foundation:

- ACI
- ASTM
- ASCE 7
- IBC

Operation and Performance

The foundation was designed for:

- Outside environment severe exposure
- Ambient temperature -10 degrees F to 105 degrees F
- Unit weight 20,000 lbs
- RPM 3600
- Soil bearing capacity 1,500 lbs/sq.ft.
- Wind speed 120 MPH
- Exposure factor D
- Wind importance factor 1.15
- Concrete poured on and permanently cast against the earth

General Design Requirements

The compressor foundation is designed to:

- Maintain the compressor in alignment and at proper elevation.
- Minimize vibration and prevent its transmission to other structures
- Provide a permanently rigid support
- Provide sufficient depth to dampen vibrations.

NOTE

Vilter does not recommend utilizing any type of vibration absorption material under the feet of the compressor unit.




Figure 3-5. Foundation with Housekeeping Pads Dimensions - Top View

Section 3 • Installation




Figure 3-6. Housekeeping Pad Dimension Detail - Top View




Figure 3-7. Level Compressor Unit Using Top Surface of Spherical Washers




Figure 3-8. Concrete Pad Housekeeping Detail

Piping

CAUTION

The piping system should be designed to avoid CO₂ soild or liquid traps and reduce the risk of hydraulic pressure caused by thermal expansion due to the high expansion ratio of CO₂.

Refer to the ANSI/ASME B31.5 Code for Refrigeration Piping. All compressor oil supply and oil return piping has been completed at the factory. The necessary connections to be made to the screw compressor unit will vary depending on the type of oil cooling method purchased. Main line refrigerant suction and discharge connections are always necessary.

- Before installing piping, the compressor inlet and outlet ports should be inspected to ensure no dirt is present.
- Piping should be supported so that no piping loads are transmitted to the compressor casings.
- All piping should be inspected for cleanliness before installation. As each pipe is connected to the compressor, the coupling alignment should be checked to ensure that no alteration has taken place.
- If alignment has altered, the compressor is being strained and the piping supports must be adjusted.
- It is not sufficient merely to re-align the drive coupling, as this will not correct the cause of the strain.
- Care must be taken to avoid trapping the lines except for specific purposes. When traps are used, the horizontal dimensions should be as short as possible to avoid excessive oil trapping.
- Lines for ammonia systems must be of steel pipe with specially designed ammonia service fittings. Common pipe fittings must NEVER be used as they will not provide the same service. Steel pipe is generally used in large installations when joints are welded.

In making up joints for steel pipe, the following procedures should be followed:

- For threaded connections, all threads on the pipe and fitting should be carefully cleaned to remove all traces of grease or oil. Threads should then be wiped dry with a lintless cloth. Only thread filling compounds suitable for service should be used for making steel pipe joints. These compounds should be used sparingly, and on the pipe only. Do not put any on the first two threads to prevent any of the thread sealing compound from entering the piping system. Acetylene or arc welding is frequently used in making steel pipe

joints, however, only a skilled welder should attempt this kind of work. Take care to see no foreign materials are left in the pipes and remove all burrs formed when cutting pipe.

- It is important to avoid short, rigid pipe lines that do not allow any degree of flexibility. This must be done to prevent vibration being transmitted through the pipe lines to the buildings. One method of providing the needed flexibility to absorb the vibration is to provide long lines that are broken by 90° Ells in three directions.
- A second method would be to install flexible pipe couplings as close to the compressor unit as possible with connections running in two different directions, 90° apart. These flexible connections should be installed on both the high and low side lines of the compressor unit.
- Hangers and supports for coils and pipe lines should receive careful attention. During prolonged operation of the coils, they may become coated with ice and frost, adding extra weight to the coils. The hangers must have ample strength and be securely anchored to withstand the vibration from the compressor and adequately support the pipe lines.
- For CO₂ piping, the pipes can have smaller diameters and they will require a greater thickness to withstand the higher pressures.
- Glycol supply and drain connections, and equipment using glycol, should be installed so all the glycol may be drained from the system after the plant has been shut down in cold weather. These precautions will avoid costly damage to the equipment due to freezing.

This information is taken from ASHRAE 15-2022 and ANSI/ASME B31.5. The installing contractor should be thoroughly familiar with these codes, as well as any local codes.

CAUTION

Accumulated liquid in the suction header can damage the compressor if not drained. Always drain headers (suction and discharge headers) prior to start-ups. Failure to comply may result in damage to equipment.

Compressor Unit Discharge Piping

Vilter typically provides discharge components in one of two configurations:

Check Valve and Stop Valve Shipped Loose For Field Installation

For field-installed check valves, the ideal location and orientation is mounted on a horizontal pipe run near the condenser. Locating the check valve near the condenser minimizes potential for liquid build-up on top of the check valve. If this occurs, there's the possibility that liquid will flow back to the coalescing section of the separator on start-up. Locating the valve in horizontal piping minimizes the potential of valve chatter.

While the above recommendation most consistently minimizes operational issues, it is fairly common for the check valve and stop valve to be mounted immediately at the separator discharge. For this reason, Vilter sizes the check valve so that valve chatter is less likely—it is typically one or more pipe sizes smaller than the separator connection. If liquid return to the condenser is evident (seen as frost on the separator shell), it is important for the user/operator to take Steps to minimize the impact by providing heat and insulation on the discharge piping. If left unresolved, damage to the coalescing elements could occur.

Flange Loads

The ideal load applied to flanges of the compressor unit is zero. However, it's not practical to expect that no loads will be applied to unit connections. Thermal, dead, live, wind & seismic loads must be considered and even tolerated. Well supported external piping connected to the compressor will still result in some loads applying forces and moments in three axes to unit flanges.

The most important issue is the motor-compressor misalignment caused by external forces (F in lbf) and moments (M in ft-lbf) imposed by plant piping. In Figure 3-9 and Table 3-1, are the maximum allowable forces and moments that can be applied to compressor flanges when the compressor is mounted on an oil separator.

It must be noted that it is necessary to check for compressor shaft movement when the job is complete. In no case shall the attached piping be allowed to cause

more than 0.002" movement at the compressor shaft. If more than 0.002" movement is detected the piping must be adjusted to reduce the compressor shaft movement to less than 0.002". For example, the compressor shaft should not move more than 0.002" when piping is removed or connected to the compressor.

IMPORTANT – piping elements shall be supported per the requirements of ASME B31.5 or other local codes as applicable. See guidelines below, particularly with concern to minimize loads on check valves.

CAUTION

Accumulated liquid in the suction header can damage the compressor if not drained. Always drain headers (suction and discharge headers) prior to start-ups. Failure to comply may result in damage to equipment.

Table 3-1. Maximum Allowable Flange Loads

Nozzle Dia. (in.)	Fz (lbf)	Fy (lbf)	Fx (ft-lbf)	Mzz (ft-lbf)	Myy (ft-lbf)	Mxx (ft-lbf)
4	400	400	400	300	300	300
6	600	600	600	500	500	500
8	900	900	900	1000	1000	1000




Figure 3-9. Maximum Allowable Flange Loads

Section 3 • Installation

Electrical Connections

Single screw compressor units are shipped with all package mounted controls wired. The standard control power is 115 volts 60 Hertz, single phase. If a 115 volt supply is not available, a control transformer may be required. The power source must be connected to the control panel according to the electrical diagrams.

The units are shipped without the compressor motor starter. Field wiring is required between the field mounted starters and package mounted motors, see Field Wiring Instructions.

Additional control wiring in the field is also required. Dry contacts are provided in the control panel for starting the screw compressor motor. These contacts are to be wired in series with the starter coils. A current transformer is supplied along with the compressor unit, and is located in the motor junction box. This transformer is to be installed around one phase of the compressor motor starter. A normally open auxiliary contact from the compressor motor starter is also required.

Terminal locations for this wiring can be found on the wiring diagram supplied with this unit. Additional aspects of the electrical operation of the single screw units are covered in the start up and operation Section of this manual.

Field Wiring Instructions

NOTE

This procedure defines steps required to wire Vission 20/20 micro-controller for the following items: Compressor Motor Starter Auxiliary Contact, High Level Shutdown, Oil Separator Heater(s), Oil Pump Start and Compressor Starter.

Follow supplied wiring diagram for detailed wiring.

Refer to Figure 3-10

1. Control power of 115 VAC 50/60 HZ must be wired to left side of terminal blocks inside the Vission 20/20 cabinet. Line power (1B) shall be connected to 15-amp circuit breaker, CB1. Neutral (1N) is connected to any N terminal blocks. Number of line power feeds required to panel is dependent upon number supplied on compressor, see Figure 3-10.
2. An auxiliary contact from compressor motor starter is required. Connect isolated contact to terminal blocks 1 and 31.
3. A dry contact from control relay CR11 must be wired to compressor motor starter coil. This dry contact is wired to terminal blocks according to supplied drawing. Control power for this coil should come from a source, which will be de-energized with compressor disconnect.

4. A dry contact from control relay CR12 must be wired to oil pump motor starter coil. This dry contact is wired to two terminal blocks according to supplied drawing. Control power for this coil should come from a source, which will be de-energized with compressor disconnect.
5. An auxiliary safety cutout is available to shut down compressor package. A dry contact must be supplied and wired to terminal blocks 1 and 32. The jumper installed on terminal blocks must be removed to use this cutout. If contact is closed, it will allow compressor to run. If contact opens at any time, compressor will shut down.
6. Indication of compressor shutdown status is also available. There is an output on terminal blocks 18 and N where a relay coil can be wired. For output, an energized state represents a "safe" condition. A de-energized state indicates a loss of voltage to relay coil or a "failure" has occurred.
7. Line power for oil separator heaters are required to be wired from the starter panel, see Figure 3-11.

NOTE

There is a dot on one side of the current transformer. This dot must face away from the motor.

8. Current transformer supplied in compressor motor conduit box should be checked to ensure that motor leads of one leg are pulled through the transformer. Typically, a wye delta started motor should have leads 1 and 6 pulled through this transformer for a 6 lead motor. However, this should always be checked as different motors and starting methods will require different leads to be used.

NOTE

For Compressor unit using PLC micro-controller, please refer to the Single Screw Compressor PLC Operation Manual (35391CM) for details.

MCC & CUSTOMER CONTROL CENTER INTERCONNECT WIRING

RUN ALL WIRE CONNECTIONS DIRECTLY TO INTENDED COMPONENTS
DO NOT CONTROL WITH ANOTHER DEVICE
ALL WIRE NUMBERS THAT ARE THE SAME ARE NOT ALWAYS COMMON TO EACH OTHER
(REFERENCE DRAWING NUMBERS)




Figure 3-11. Example - Interconnect Wiring Diagram




Figure 3-12. Example - V-PLUS Wiring Diagram

Testing Refrigeration System For Leaks

CAUTION

Do not hydro test compressor unit. Failure to comply may result in damage to equipment.

CAUTION

The compressor unit along with other system units contain many components with various pressure ratings. Pressure relief protection provided considers the design pressure of a system components. Before replacing a pressure relief valve with a relief valve having a higher pressure setting, all system components must be evaluated for acceptability.

Vilter equipment is tested for leaks at the factory. One of the most important steps in putting a refrigeration system into operation is field testing for leaks. This must be done to assure a tight system that will operate without any appreciable loss of refrigerant. To test for leaks, the system pressure must be built up. Test pressures for CO₂ are listed in the IIAR CO₂ Industrial Refrigeration Handbook (ANSI/IIAR Standard CO₂-2021).

Before testing may proceed, several things must be done.

First, if test pressures exceed the settings of the system, relief valves or safety devices, remove those and plug the connection during the test.

Secondly, all valves should be opened except those leading to the atmosphere. Then, open all solenoids and pressure regulators by the manual lifting stems. All bypass arrangements must also be opened.

CO₂ Systems

A CO₂ system will tend to be more prone to leaks due to the higher working pressures and the smaller molecule size, and therefore its leak detection should become a regular maintenance procedure. For a charge size of above 661 lbs, for example, the recommendation would be to perform the leak detection procedure about 4 times a year.

An oil stain will be a visual indicator of a CO₂ leak, but there are also leak detection sprays available in the market (such as Weicon's or Bulleye's), infrared handheld leak detectors (such as D-TEK CO₂), and ultrasonic leak detectors of several brands.

Step 1: Test The System At A Test Pressure

Only dry nitrogen or anhydrous CO₂ may be used to raise the pressure in the CO₂ system to the proper level for the test. The gas may be put into the system through the charging valve or any other suitable opening.

Adjust the pressure regulator on the bottle to prevent over-pressurization. Do not exceed the pressure rating on the vessel with the lowest pressure rating.

When the proper pressure, 30 psig for CO₂ system, is attained, test for leaks with a soap mixture described as below.

Take a mixture of four parts water to one part liquid soap, and add a few drops of glycerin to it. This makes a good solution. Apply this mixture with a one-inch round brush at all flanges, threaded joints, and welds.

After all leaks are found and marked, relieve the system pressure and repair the leaks. The pressure should be bled off in 10 – 15 psig increments from the lowest part of the system to help expel any residual water in the system.

Never attempt to repair welded joints while the system is under pressure.

Repair all visible leaks and recheck the system.

Step 2: Test The System At The Design Pressure

Charge a small amount CO₂ into the system and pressurize the system to its respective design pressure. Use a leak detection spray or leak detector around all joints and connections.

If any leaks are observed during this test, they must be repaired and rechecked before the system can be considered tight and ready for evacuation.

Evacuating The System

CAUTION

Ensure compressor unit has been charged, and the compressor primed, with the correct amount of oil prior to initial refrigerant charging. Failure to comply may result in damage to equipment.

A refrigeration system operates best when only refrigerant is present. Steps must be taken to remove all air, water, vapor, and all other non-condensables from the system before charging it with refrigerant. A combination of moisture and refrigerant, along with any oxygen in the system, can form acids or other corrosive compounds that corrode internal parts of the system.

To properly evacuate the system, and to remove all non-condensables, air and water vapor, use a high vacuum pump capable of attaining a blanked off pressure of 50 microns or less. Attach this pump to the system and allow it to operate until system pressure is reduced somewhere below 1000 microns. Evacuation should not be done unless the room temperature is 60°F or higher.

Attach vacuum gauge(s), reading in the 20 to 20,000 micron gauge range, to the refrigerant system. These gauge(s) should be used in conjunction with the high vacuum pump. The reading from the gauge(s) indicates when the system has reached the low absolute pressure required for complete system evacuation.

Connect the high vacuum pump into the refrigeration system by using the manufacturer's instructions. Connect the pump both to the high side and low side of the system, to insure system evacuation. Attach the vacuum gauge to the system in accordance with the manufacturer's instructions.

A single evacuation of the system does not satisfactorily remove all of the non-condensable, air and water vapor. To do a complete job, a triple evacuation is recommended.

When the pump is first turned on, bring system pressure to as low a vacuum level as possible, and continue operation for 5 to 6 hours.

Stop the pump and isolate the system. Allow the unit to stand at this vacuum for another 5 to 6 hours. After this time, break the vacuum and bring the system pressure up to 0 psig with dry nitrogen.

To begin the second evacuation, allow the pump to operate and reduce the pressure again to within 50 to 1000 microns. After this reading is reached, allow the pump to operate 2 or 3 hours. Stop the pump and let the system stand with this vacuum. Again using dry nitrogen, raise the system pressure to zero.

For the third evacuation, follow the previous procedure with the pump operating until system pressure is reduced below the 1000 micron level. Run the pump for additional 6 hours and hold the system for approximately 12 hours at low pressure. After this, again break the vacuum with dry nitrogen and allow the pressure in the system to rise slightly above zero pounds (psig). Install new drier cartridges and moisture indicators. Charge the system once more below the 1000 micron level and use the refrigerant designed for the system.

When properly evacuating the system as outlined above, the system is dry, oxygen-free and free of non-condensables. The piping should not be insulated before the evacuation process is started. If moisture is in the system before evacuating, it condenses in low places and freezes. If this happens, it can be removed by gently heating the trap farthest away from the vacuum pump. This causes the ice to melt and water to boil. Water vapor collects in the next trap towards the vacuum pump. This process should be repeated until all pockets of water have been boiled off, and the vacuum pump has had a chance to remove all the water vapor from the system.

Notice on Using Non-Vilter Oils

CAUTION

Do not mix oils. Failure to comply may result in damage to equipment.

NOTICE

Vilter does not approve non-Vilter oils for use with Vilter compressors. Use of oils not specified or supplied by Vilter will void the compressor warranty.

Due to the need for adequate lubrication, Vilter recommends only the use of Vilter lubricants, designed specifically for Vilter compressors. Use of oil not specified or supplied by Vilter will void the compressor warranty.

Please contact your local Vilter representative or the Home Office for further information.

Unit Initial Oil Charging and Priming

WARNING

Avoid skin contact with oil. Wear rubber gloves and a face shield when working with oil. Failure to comply may result in serious injury or death.

NOTICE

Failure to follow these instructions will result in bearing damage and compressor seizing and will void any and all warranties that may apply.

NOTICE

Do not put oil when unit is under vacuum. Use an oil pump to charge oil.

Typically, the compressor unit is shipped from Vilter with no oil charge. The normal operating level is between the two sight glasses on the oil separator, see Figure 3-13. Refer to supplied GA drawing for unit specific oil charge requirement.

For regular oil charging and draining procedures, see Section 5.

Tool Required

- Oil Pump, Maximum 2-3 GPM with Motor approved for Division 1 or Division 2 and with ability to overcome suction pressure (VPN A40849A).




Figure 3-13. Oil Operating Levels

Section 3 • Installation

Unit Initial Oil Charging

(Reference Figure 3-15)

1. At initial start up, compressor unit must be off and depressurized prior to initial oil charging.
2. Using a properly selected oil pump, connect oil pump to oil separator drain valve (10) (for oil separator drain valve location, see Figure 3-14).
3. Open oil separator drain valve (10) and fill oil separator (1) to Maximum NON-Operating Level. (See Figure 3-13).
4. Once Maximum NON-Operating Level has been reached, shut off oil pump, close oil separator drain valve (10) and remove oil pump.
5. If equipped with remote oil cooler, refer to Priming Compressor Units Equipped with Remote Oil Cooler procedure (see Appendix G).

Priming Oil Lines and Compressor (Unit With Oil Pump)

Continue with the following steps to prime the oil lines and compressor:

6. Make sure valves on oil circuit are in the open position. In this case, make sure valves (2), (3), (5), (6) and (7) are in the open position.
7. Energize compressor unit. Vision 20/20 will energize oil heaters.
8. Run oil pump (4) for 15 seconds only.
9. Wait minimum of 30 minutes to allow oil to drain from compressor (8).
10. If compressor unit is not being started right away, repeat steps 6 to 9 prior to starting.




Figure 3-14. Oil Drain Valve




Figure 3-15. Priming Oil Lines and Compressor (With Oil Pump)

Section 3 • Installation

Unit Initial Oil Charging without Compressor Oil Pump – For CO₂ Subcritical HPLD Units Only

(Reference Figure 3-16)

1. Compressor unit must be off and fully depressurized prior to the initial oil charging (follow proper Lockout tagout procedure).
2. Open Valves (6), (9), and (6a if Dual Oil Filters)
3. Close Valve (7), (7a if Dual Oil Filters) and all other valves (4), (11), (10), (8), and (5a if Dual Oil Filters)
4. Using a properly selected oil pump, connect oil

pump hose to oil filter drain valve (5). As a reference, Vilter oil pump is #A40849A (2 to 3 gpm)

5. Open oil filter drain valve (5) and pump around 5 gallons of oil into compressor (1)
6. Shut off oil pump
7. Close valve (6) and (6a if Dual Oil Filters)
8. Open valves (7), (8), and (7a if Dual Oil Filters)
9. Pump oil through oil cooler to separator (2)
10. When maximum NON-operating level has been reached (Separator (2) Sight Glass, see Figure 3-13 for location), shut off oil pump, close oil filter drain valve (5), and disconnect oil pump hose
11. Unit is now ready for plant Pre-Start up Safety Review (PSSR) before initial start.




Figure 3-16. Unit Initial Oil Charging without Compressor Oil Pump – For CO₂ Subcritical HPLD Units Only

System Refrigerant Charging

After the system is leak-free and evacuation has been completed, the entire operation of the refrigeration system should be inspected before charging.

A. Low Side Equipment

1. Fans on air handling equipment running.
2. Pumps on water cooling equipment running.
3. Proper location and attachment of thermostatic expansion valve bulb to suction line.
4. Correct fan and pump rotation.
5. Evaporator pressure regulators and solenoid valves open.
6. Water pumps and motors correctly aligned.
7. Belt drives correctly aligned and tensioned.
8. Proper voltage to motors.

B. Compressors

1. Proper oil level.
2. Voltage agrees with motor characteristics.
3. Properly sized motor fuses and heaters.
4. Direct drivers aligned and couplings tight.
5. All suction and discharge valves open.
6. All transducers and RTDs calibrated and reading correctly.

C. Condensers

1. Water available at water cooled condensers and supply line valve open.
2. Water in receiver of evaporative condenser and makeup water available.
3. Correct rotation of pump and fan motors.
4. Belt drives aligned and tensioned correctly.
5. Pump, fans and motors lubricated.

D. Controls

Controls should be at the initial set points. See microprocessor manual for further information.

Initial High Side Charging

WARNING

When working with refrigerants, ensure there is adequate ventilation and refrigerant vapor detectors as per ASHRAE standards. Failure to comply may result in serious injury or death.

WARNING

Avoid skin contact with any liquid refrigerant or oil. Wear rubber gloves and a face shield when working with liquid refrigerant or oil. Failure to comply may result in serious injury or death.

CAUTION

Ensure compressor unit has been charged with the correct amount of oil prior to initial refrigerant charging. Failure to comply may result in damage to equipment.

CAUTION

Do not apply flame or steam directly to drum, as this can produce dangerously high pressures inside drum. Failure to comply may result in damage to equipment.

There are two methods of charging refrigerant into the system, through the “high side” or through the “low side”. High side charging is usually used for initial charging as filling of the system is much faster. Low side charging is usually reserved for adding only small amounts of refrigerant after the system is in operation.

High side charging of refrigerant into the system is accomplished as follows:

1. Connect a full drum of refrigerant to the liquid charging valve. This valve is generally located in the liquid line immediately after the king or liquid line valve. Purge the air from the charging line.
2. Close the liquid line or king valve, if it is not already closed. Open the “Liquid” charging valve slowly to allow refrigerant to enter the system. The vacuum in the system will draw in the refrigerant.
3. It is important that during this operation air handling units be running and water is circulating through the chillers. The low pressures on the system can cause the refrigerant to boil at low temperature and possibly freeze the water if it is not kept circulating. Water freezing in a chiller can rupture the tubes and cause extensive damage to the system. It would be desirable to charge the initial amount of refrigerant without water in the shell and tube equipment to eliminate the possibility of freeze up.

Section 3 • Installation

4. After some refrigerant has entered the system, the compressor unit starting procedure may be followed, see Starting procedure in Section 4.
5. Continue charging refrigerant into the system until the proper operating requirements are satisfied. Then, close the liquid charging connection and open the liquid line valve allowing the system to operate normally. To check that enough refrigerant has been added, the liquid sight glass should show no bubbles, and there will be a liquid seal in the receiver. If these two conditions are not satisfied, additional refrigerant must be added.
6. When sufficient refrigerant has been charged into the system, close the charging and drum valves. Then remove the drum from the system.
7. During the charging period, observe the gauge carefully to insure no operating difficulties. Watch head pressures closely to make sure the condensers are functioning properly.
8. Since it is usually necessary to use several drums when charging a system, follow the procedures in steps 1 and 2 when attaching a new drum. After charging, the refrigerant drums should be kept nearby for several days as it is sometimes necessary to add more refrigerant as the system settles down.

Notice on Using Non-Vilter Oils

CAUTION

Do not mix oils. Failure to comply may result in damage to equipment.

NOTICE

Vilter does not approve non-Vilter oils for use with Vilter compressors. Use of oils not specified or supplied by Vilter will void the compressor warranty.

Due to the need for adequate lubrication, Vilter recommends only the use of Vilter lubricants, designed specifically for Vilter compressors. Use of oil not specified or supplied by Vilter will void the compressor warranty.

Please contact your local Vilter representative or the Home Office for further information.

WARNING

Software programming credentials shall only be made available by the supplier. The user will only have access to operational features established by the supplier. Failure to comply may result in serious injury or death.

Oil Inspection

WARNING

Avoid skin contact with any liquid refrigerant or oil. Wear rubber gloves and a face shield when working with liquid refrigerant or oil. Failure to comply may result in serious injury or death.

WARNING

Avoid skin contact with oil. Wear rubber gloves and a face shield when working with oil. Failure to comply may result in serious injury or death.

Operation

All operation (set-point adjustments, calibrations, monitoring) of the compressor unit is done through the micro-processor. For additional procedural information, refer to micro-processor manual (35391SC for Vision 20/20 Operating Manual or 35391CM for Compact Logix PLC Software Manual).

Inspect oil level through sight glasses on the oil separator, see Figure 4-1. Oil Operating Levels. Drain or fill oil as required. For oil draining and filling procedure, see Oil Charging and Oil Draining in Section 5.




Figure 4-1. Oil Operating Levels

Section 4 • Operation

Dual Oil Filters

On compressor units equipped with dual oil filters, only one filter should be in operation at a time.

NOTE

During operation, both oil filter outlet shut-off valves should be open. This will help minimize the sudden loss of oil pressure when switching between oil filters for servicing.

Refer to Oil Filter Replacement in Section 5 for further details.

Control System

Calibration

Equipped for automatic operation, the screw compressor unit has safety controls to protect it from irregular operating conditions, an automatic starting and stopping sequence, and capacity and volume ratio control systems.

Check all pressure controls with a remote pressure source, to assure that all safety and operating control limits operate at the point indicated on the microprocessor.

The unit is equipped with block and bleed valves that are used to recalibrate the pressure transducers. To use the block and bleed valves to recalibrate the pressure transducers, the block valve is shut off at the unit and the pressure is allowed to bleed off by opening the bleed valve near the pressure transducer enclosure. The transducer can then be calibrated at atmospheric pressure (0 psig), or an external pressure source with an accurate gauge may be attached at the bleed valve.

The discharge pressure transducer cannot be isolated from its pressure source. Hence it is equipped with only a valve to allow an accurate pressure gauge to be attached and the pressure transducer calibrated at unit pressure.

Recheck the transducers periodically for any drift of calibration, refer to Maintenance/Service Schedule Table in Section 5.

Starting, Stopping and Restarting The Compressor

For additional control information, refer to micro-processor manual (35391SC for Vision20/20 Operating Manual or 35391CM for Compact Logix PLC Software Manual).

WARNING

Software programming credentials shall only be made available by the supplier. The user will only have access to operational features established by the supplier. Failure to comply may result in serious injury or death.

Starting

Before the screw compressor unit can start, certain conditions must be met. All of the safety setpoints must be in a normal condition, and the suction pressure must be above the low suction pressure setpoint to ensure a load is present. When the “ON/OFF” switch or “Manual-Auto” button is pressed, the oil pump will start. When sufficient oil pressure has built up and the compressor capacity control and volume ratio slide valves are at or below 10%, the compressor unit will start.

NOTE

The amount of oil pressure that needs to be achieved before compressor start is at least 6 psig above the discharge pressure. For additional information on Low Oil Pressure at Start, see Troubleshooting Guide - General Problems and Solutions in Section 6.

If the compressor is in the automatic mode, it will now load and unload and vary the volume ratio in response to the system demands.

Stopping/Restarting

Stopping the compressor unit can be accomplished in a number of ways. Any of the safety setpoints will stop the compressor unit if an abnormal operating condition exists. The compressor unit “On-Off” or stop button will turn the compressor unit off as will the low pressure setpoint. If any of these conditions turns the compressor unit off, the slide valve motors will immediately energize to drive the slide valves back to 5% limit. The control motors will be de-energized when the respective slide valve moves back below 5%. If there is a power failure, the compressor unit will stop. If the manual start on power failure option is selected, restarting from this condition is accomplished by pushing the reset button to ensure positive operator control. If the auto start on power failure option is selected, the compressor unit will start up after a waiting period. With both options,

Section 4 • Operation

the compressor slide valves must return below their respective 5% limits before the compressor unit can be restarted.

NOTE

Wait a minimum of 20 minutes (to allow the compressor unit to equalize to suction pressure) between pre-lubing or pushing the start button.

Emergency Shutdown

Emergency shutdown is initiated by the following:

1. A shutdown or trip condition of a process variable while the system is in operation. If a process variable reaches a high-high or low-low shutdown set-point, the compressor unit will automatically stop. A shutdown alarm is also generated on the control panel HMI screen annunciating the specific process variable trip condition.
2. The Local Emergency Shutdown push button located on the side of the control panel enclosure. When the Local Emergency Shutdown push button is activated, the entire unit powers down. Also, the compressor capacity and volume slide valve will stay in their last position until the unit is powered up. Once recovery has been accomplished and the unit is to be re-powered, the Local Emergency Shutdown push button must be pulled out to power up the unit and controls.

Slide Valve Actuator Operation

The slide valve actuator is a gear-motor with a position sensor. The motor is powered in the forward and reverse directions from the main computer in the control panel. The position sensor tells the main computer the position of the slide valve. The main computer uses the position and process information to decide where to move the slide valve next.

The position sensors work by optically counting motor turns. On the shaft of the motor is a small aluminum “photochopper”. It has a 180 degree fence that passes through the slots of two slotted optocouplers. The optocouplers have an infrared light emitting diode (LED) on one side of the slot and a phototransistor on the other. The phototransistor behaves as a light controlled switch. When the photochopper fence is blocking the slot, light from the LED is prevented from reaching the phototransistor and the switch is open. When photochopper fence is not blocking the slot, the switch is closed.

As the motor turns, the photochopper fence alternately blocks and opens the optocoupler slots, generating a sequence that the position sensor microcontroller can

use to determine motor position by counting. Because the motor is connected to the slide valve by gears, knowing the motor position means knowing the slide valve position.

During calibration, the position sensor records the high and low count of motor turns. The operator tells the position sensor when the actuator is at the high or low position with the push button. Refer to the calibration instructions for the detailed calibration procedure.

The position sensor can get “lost” if the motor is moved while the position sensor is not powered. To prevent this, the motor can only be moved electrically while the position sensor is powered. When the position sensor loses power, power is cut to the motor. A capacitor stores enough energy to keep the position sensor circuitry alive long enough for the motor to come to a complete stop and then save the motor position to non-volatile EEPROM memory. When power is restored, the saved motor position is read from EEPROM memory and the actuators resume normal function.

This scheme is not foolproof. If the motor is moved manually while the power is off or the motor brake has failed, allowing the motor to free wheel for too long after the position sensor loses power, the actuator will become lost.

A brake failure can sometimes be detected by the position sensor. If the motor never stops turning after a power loss, the position sensor detects this, knows it will be lost, and goes immediately into calibration mode when power is restored.

Section 4 • Operation

Calibrate Slide Valve Actuators (For VSCC 291 - 601 Units Using Vission 20/20™)

Slide valve actuators must be installed prior to calibration. Refer to Slide Valve Actuator Installation procedure. The following steps pertain to calibrating one slide valve actuator. Repeat procedure to calibrate other slide valve actuator.

WARNING

After stopping the compressor, allow the compressor and surrounding components to cool down prior to servicing. Failure to comply may result in serious injury.

CAUTION

Do not calibrate in direct sunlight. Failure to comply may result in damage to equipment.

Both the capacity and volume slide actuators should be calibrated when one or more of these have occurred:

- Compressor unit starting up for the first time.
- A new actuator motor has been installed.
- There is an error code flashing on the actuator's circuit board - an attempt to recalibrate should be made.

- The range of travel is not correct and the command shaft travel is physically correct.
- The compressor is pulling high amperage, the calibration of the volume slide should be checked.
- An actuator does not unload below 5%, or an actuator that doesn't move.
- Something is not working properly such as the actuators, RTDs or transducers.

To calibrate optical actuators, continue with the following steps:

NOTE

If the compressor unit is starting up for the first time or a new actuator motor has been installed, leave the power cable and position transmitter cable disconnected until Step 6.

1. Stop compressor unit and allow to cool.
2. Remove screws securing actuator cover to actuator assembly. As a reference see Figure 4-2.

CAUTION

Wires are attached to the connector on the actuator cover. Handle actuator cover with care to prevent damage to wires. Failure to comply may result in damage to equipment.




Figure 4-2. Actuator Assembly

Section 4 • Operation

- Carefully lift actuator cover from actuator assembly and tilt towards connectors. Raise cover high enough to be able to press the blue calibration button and be able to see the red LED on the top of assembly.
- Logging on into the Vission 20/20™ with high-level access will prompt the Calibration buttons to appear, see Figure 4-3.




Figure 4-3. Slide Valve Calibration Screen (Vission 20/20)

Section 4 • Operation

5. On the main screen, press “Menu” then press the “Slide Calibration” button to enter the slide calibration screen, see Figure 4-4.
6. If the compressor unit is starting for the first time or a new actuator is installed, connect connectors of power cable and position transmitter cable to new actuator.




Figure 4-4. Menu Screen and Slide Calibration Button (Vission 20/20)

Section 4 • Operation

NOTE

If the “+” (increase) and “-” (decrease) buttons do not correspond to increase or decrease shaft rotation, swap the blue and brown wires of the “power cable” in the control panel. This will reverse the rotation of the actuator/command shaft, see Figure 4-5.

Capacity actuator wires are connected on terminals 13 & 14. Volume actuator wires are connected on terminals 15 & 16.

7. Press “+” or “-” to move the slide valve and check for the correct rotation, see Table 4-1.

NOTE

When the actuator is in calibration mode, it outputs 0V when the actuator is running and 5V when it is still. Thus, as stated earlier, the actuator voltage will fluctuate during calibration. After the actuator has been calibrated, 0V output will correspond to the minimum position and 5V to the maximum position.

8. Quickly press and release the blue push button on the actuator one time. This places the actuator in calibration mode. The red LED will begin flashing rapidly.


CAUTION

DO NOT CONTINUE TO ENERGIZE THE ACTUATOR MOTOR AFTER THE SLIDE HAS REACHED THE MECHANICAL STOP. Doing so may cause mechanical damage to the motor or shear the motor shaft key. When the slide has reached the mechanical stop position, press the button in the center of the photo-chopper to release the brake, and thereby release the tension on the actuator motor.

NOTE

The “Slide Calibration” screen on the Control Panel has a “Current” window, which displays the actuator output voltage. These values, (the % volume and the % capacity) displayed in the window are meaningless until calibration has been completed.

9. Use the “-” button on the Control panel to drive the slide valve to its minimum “mechanical stop” position. Release the “-” button when the slowing of the motor rotation and a winding sound from the actuator motor is noted.



Capacity Actuator
Wire connections
(13, 14)

Volume Actuator
Wire connections
(15, 16)




Figure 4-5. Wire Connections for Capacity and Volume Actuators

Section 4 • Operation

Table 4-1. Command Shaft Rotation Specifications*

Compressor Model	Command Shaft Rotation				No. of Turns/Rotation			Angle/Slide Travel		
	Capacity		Volume		Capacity			Volume		
	INC	DEC	INC	DEC	Turns	Degrees	Travel	Turns	Degrees	Travel
VSCC 291 VSCC 341 VSCC 451 VSCC 601	CW	CCW	CW	CCW	0.91	328	3.568"	0.52	187	2.045"

*The large gear on the command shaft has 50 teeth. The teeth are counted when moving the command shaft from the minimum stop position to the maximum stop position.

The manual operating shaft on the gear motor should be turned the opposite direction of the desired command shaft rotation.

The capacity and volume control motors are equipped with a brake. If it is necessary to operate the control motors manually, the brake must be disengaged. The brake can be disengaged by pushing on the motor shaft on the cone end. The shaft should be centered in its travel. Do not use excessive force manually operating the motor or damage may result.

Section 4 • Operation

10. Press and hold down on the photo-chopper shaft to disengage the brake slowly, releasing tension from the motor mount, see Figure 4-6. Use the “+” button to pulse the actuator to where the slide is just off of the mechanical stop and there is no tension on the motor shaft.
11. Quickly press and release the blue button on the actuator again. The red LED will now flash at a slower rate, indicating that the minimum slide valve position (zero position) has been set.
12. Use the “+” button on the Control panel to drive the slide to its maximum “mechanical stop” position. Release the “+” button when the slowing of the motor rotation and a winding sound from the actuator motor is noted.

NOTE

If the photo-chopper spins faster than 4800 RPM, the actuator will go into an over speed fault and recalibration will be required.

13. Press and hold down on the photo-chopper shaft to disengage the brake slowly, releasing tension from the motor mount. Use the “-” button to pulse the actuator to where the slide is just off of its mechanical stop and there is no tension on the motor shaft.

NOTE

After the blue button is pressed for the third time, an mV reading will be displayed in the Current field. Make sure the mV value is at least 150 to 200 mV higher than the max setpoint on the screen.


14. Quickly press and release the blue button on the actuator one more time. The red LED will stop flashing. The actuator is now calibrated and knows the minimum and maximum positions of the slide valve it controls.

Now the Capacity Channel is automatically calibrated based on the calibration settings made to the actuator.

CAUTION

Do not over tighten screws. Failure to comply may result in damage to equipment.

15. Gently lower the plastic cover over the top of the actuator to where it contacts the base and O-ring seal. After making sure the cover is seated properly, gently tighten the four #10 screws.
16. Repeat procedure to calibrate other slide valve actuator.



Press down on Photo-chopper to release tension from motor mount.

Figure 4-6. Photo-chopper

Compressor Control with Vission 20/20™ Micro-controller (No Slide Operation)

The Vission 20/20™ panel can provide control for a single screw compressor without slides as long as Analog Output Board #10 is present and selected in the Configuration screen, see Figure 4-7.

The “No Slide” operation will become active once the correct type of compressor and model has been chosen, see Figure 4-8.

The user must select either VSG/VSH or VSCC from the Compressor combo box in Screen 2 of the Configuration Menu, and then the Model from the next box.

The choice of this type of compressor will cause the refrigerant combo box to be grayed out.

Once the compressor has been selected, the Vission 20/20™ panel touchscreen will show an indicator of VFD speed percentage, and buttons to increase and decrease it.

For more information on VFD capacity control, please check the Vission 20/20™ Manual (35391SC).

WARNING

Software programming credentials shall only be made available by the supplier. The user will only have access to operational features established by the supplier. Failure to comply may result in serious injury or death.

Figure 4-7. Vission 20/20 Configuration Screen - I/O Configuration (Screen 8)





Figure 4-8. Compressor and Model Setup with Vission 20/20

Coalescing Oil Return Line Setup

Over time, oil will accumulate on the coalescing side of the oil separator. As a result, an oil return line with a shut-off valve, sight-glass, check valve and needle valve are installed between the coalescing side and compressor to return this oil back to the compressor.

To adjust the return flow, proceed with the following procedure:

NOTE

Do not fully open the needle valve unless directed by Vilter™ Technical Support. Leaving the needle valve fully open will reduce efficiency of the compressor unit.

1. Open shut-off valve on coalescing side of oil separator, see Figure 4-9.
2. While the unit is in operation, crack open needle valve and observe oil flow through sight-glass.
3. Slowly open needle valve more until a small amount of oil is seen in the sight-glass.

NOTE

The sight-glass should never be full with oil.

4. Periodically check oil in the sight-glass and ensure that there is flow.




Figure 4-9. Coalescing Oil Return Line

Section 4 • Operation

Suction Equalizing Line Setup

The suction equalizing line allows system pressure to equalize to suction pressure during shutdown periods. The line is connected before the suction stop/check valve to after the suction strainer, see Figure 4-10.

NOTE

Valve adjustment depends on size of oil separator and how quickly system pressure should equalize to suction pressure. The larger the oil separator the longer system pressure will take to equalize to suction pressure.

1. To open valve, turn counterclockwise. To close valve, turn clockwise.
2. Fully close valve to a stop.
3. Turn valve to fully open position while counting number of turns to fully open. Note total number of turns.
4. Adjust valve to be half open. Close valve to half of the number of total turns.
5. If suction pressure needs to equalize slower, turn valve towards closed position.
6. If suction pressure needs to equalize faster, turn valve towards open position.





Figure 4-10. Suction Equalizing Line and Valve

Oil Cooling

Vilter™ single screw compressors have several options when it comes to oil cooling, such as plate-type cooler (using refrigerant, glycol or water) and liquid injection, (single or dual) controlled by Vission 20/20's settings.

For liquid injection, low, medium and high ports are available, as are dual ports: high/medium or medium/low. See Table 4-2 for the panel's toggle switch's position depending on compressor size and tubing positions, and Figure 4-11 for possible variations of the liquid injection configuration.

VSCC 128 - 243



VSCC 291 - 601




Figure 4-11. Liquid Injection Variations

Section 4 • Operation

Dual Oil Filter Setup For Oil Filters with Filter Head Assemblies

It is very important to correctly setup units equipped with dual oil filters, especially for oil filters that have filter head assemblies. Otherwise, oil pressure readings will be shown incorrectly.

To setup dual oil filters, proceed with the following steps:

NOTE

Inlet Oil Pressure Transducer should only read oil pressure from active oil filter.

1. Decide which oil filter will be active/in use.
2. Open inlet and outlet oil filter shut-off valves to active oil filter.
3. Open inlet oil pressure shut-off valve for active oil filter.
4. Close outlet oil filter shut-off valve to inactive oil filter.
5. Close inlet oil pressure shut-off valve for inactive oil filter.




Figure 4-12. Dual Oil Filter Setup for Oil Filters with Manifold Heads

Maintenance and Service Schedule

Follow this table for maintaining and servicing the compressor unit at hourly intervals.

Table 5-1. Maintenance/Service Schedule

Group	Inspection / Maintenance	Service Interval (Hours)													
		200	5,000	10,000	20,000	30,000	40,000	50,000	60,000	70,000	80,000	90,000	100,000	110,000	120,000
Oil Circuit	Oil Change ⁽¹⁾	-	R	-	R	-	R	-	R	-	R	-	R	-	R
	Oil Analysis ⁽²⁾	-	S	S	S	S	S	S	S	S	S	S	S	S	S
	Oil Filters ⁽³⁾	R	R	R	R	R	R	R	R	R	R	R	R	R	R
	Oil Strainers	I	I	I	I	I	I	I	I	I	I	I	I	I	I
Compressor Unit	Coalescing Filter	-	-	-	-	R	-	-	R	-	-	R	-	-	R
	Coalescing Drain Line	I	I	I	I	I	I	I	I	I	I	I	I	I	I
	Suction Screen	I	I	I	I	I	I	I	I	I	I	I	I	I	I
	Liquid Line Strainers	I	I	I	I	I	I	I	I	I	I	I	I	I	I
	Coupling Alignment and Integrity	I	I	I	I	I	I	I	I	I	I	I	I	I	I
	Motor (Compressor)	See Motor Manual for proper lubrication procedures and service intervals.													
Control Calibration	Transducers	I	I	I	I	I	I	I	I	I	I	I	I	I	I
	RTDs/ TTs	I	I	I	I	I	I	I	I	I	I	I	I	I	I
	Slide Valve Motors (If Applicable)	Slide valve calibration should be inspected monthly. Inspections can be performed through the control panel. If a Non-Movement Alarm appears, calibrate immediately.													
Compressor	Compressor ^(*)	-	I	-	I	-	I	-	I	-	I	-	I	-	I
	Inspect for Back Spin ⁽⁴⁾	Inspect Every 10,000 Hours or As Needed													
	Inspect for Leak	Check Monthly													
	Shaft Seal Replacement	When oil leak over 15 drops per hour													
I – Inspect S – Sampling R – Replace															

Notes:

*: Inspections include: gaterotor inspection (backlash measurement, shelf clearance and gaterotor float), end play measurement (main rotor & gaterotor), slide valve inspection (if applicable). Please see “Compressor Inspection” under Section 5 for detailed instructions.

- The oil should be changed at these intervals unless oil analysis results exceed the allowable limits. The frequency of changes will depend on the system cleanliness.
- Oil analysis should be done at these intervals as a minimum; the frequency of analysis will depend on system cleanliness.
- The oil filter(s) on a minimum must be changed at these intervals or annually if not run continuously. However, the oil filter(s) must be changed if the oil filter differential exceeds the given limit or oil analysis requires it.
- When shutting off the compressor, normally there is a back spin of the compressor motor shaft in the opposite direction. The backspin of 4 or 5 revolutions are normal to fill the suction cavity with high pressure gas from the Oil Separator. More than this will reflect a faulty suction check valve or fully open bleed line around the suction check valve

Section 5 • Maintenance/Service

Preventive Maintenance, Checks and Services

Careful checking of a refrigeration system for leaks and proper operation of all components upon installation will start the system on its way to a long life of satisfactory service. To ensure the desired trouble-free operation, however, a systematic maintenance program is a prerequisite. The following PMCS is suggested in addition to the Maintenance/Service Schedule.

NOTE

After any maintenance work, the workplace should be cleaned and free from any hazards.

Daily

1. Check oil levels.
2. Check all pressure and temperature readings.
3. Check micronic oil filter inlet and outlet pressures for excessive pressure drop. Change filter when pressure drop exceeds 45 psi or every six months, whichever occurs first. For proper procedure for changing micronic oil filter and for charging oil into the system, see Operation Section.
4. Clean strainers each time filter cartridge is replaced.
5. Check compressor sound for abnormal noises.
6. Check shaft seals for excessive oil leakage. A small amount of oil leakage (approximately 6 to 15 drops per hour) is normal. This allows lubrication of the seal faces.

Weekly

(Items 1 thru 6 above plus 7 thru 9)

7. Check the refrigeration system for leaks with a suitable leak detector.
8. Check oil pressures and review microprocessor log and log sheets.
9. Check refrigerant levels in vessels.

Monthly

(Items 1 thru 9 above plus 10 thru 13)

10. Grease all motors and bearings. Follow manufacturer's instructions on lubrication.
11. Check calibration and operation of all controls, particularly safety controls.
12. Check oil cooler for any evidence of corrosion, scaling or other fouling.

13. Operate compressor capacity and volume ratio controls through their range both automatically and manually.

Trimonthly

(Approximately 2000 operating hours)

- A. Check movement of compressor rotor at drive coupling end to determine bearing float, see Compressor Shaft Bearing Float Inspections.

Annually

(Items 1 thru 13 and "A" above plus 14 thru 31)

14. Check entire system thoroughly for leaks.
15. Remove all rust from equipment, clean and paint.
16. Grease valve stems and threads for the valve caps.
17. Flush out sediment, etc. from water circuits.
18. Clean all oil strainers.
19. Clean suction strainer – compressors.
20. Check motors and fans for shaft wear and end play.
21. Check operation and general condition of microprocessor and other electrical controls.
 - Check fuses in the Vission 20/20 or PLC panel.
 - Check for loose wiring connections in the Vission 20/20 or PLC panel.
 - Check relay and contact operation for relays in the Vission 20/20 or PLC panel.
 - Verify set points in the Vission 20/20 or PLC.
22. Clean all water strainers.
23. Check drains to make sure water will flow away from equipment.
24. Drain and clean entire oil system at receiver drain. Recharge with new clean moisture free oil. For proper procedure for changing micronic oil filter and charging oil into the system, see Start-Up and Operation Section.
25. Check compressor coupling. For integrity and alignment.
26. Check the oil pump coupling for integrity.
27. Check the calibration of the microprocessor pressure transducers and RTD's for accuracy.
28. Check mounting bolts for compressor and motor.
29. Verify the operation of the suction and discharge check valves.
30. Check setup of soft starts and VFDs.
31. Check oil heater operation.

Compressor Unit Isolation For Maintenance/Service (Compressors with Slide Valves)

WARNING

Avoid skin contact with any liquid refrigerant or oil. Wear rubber gloves and a face shield when working with liquid refrigerant or oil. Failure to comply may result in serious injury or death.

WARNING

When working with refrigerants, ensure there is adequate ventilation and refrigerant vapor detectors as per ASHRAE standards. Failure to comply may result in serious injury or death.

WARNING

At shutdown, open any other valves that may trap liquids to prevent serious injury and/or damage to equipment.

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

NOTICE

Recover or transfer all refrigerant vapor in accordance with local ordinances before opening any part of the package unit to atmosphere.

The compressor unit must be isolated and depressurized to atmosphere prior to servicing.

1. Shut down the compressor unit, refer to Stopping/Restarting procedure in Section 4.
2. Turn motor and oil pump starter disconnect switches into the OFF position. Lock-out/tag-out disconnect switches.
3. If suction equalizing valve is not open, open it to allow oil separator pressure to vent to low-side system pressure, see Figure 5-1. Close valve when complete.
4. Isolate the compressor unit by closing all valves to the house system. Lock-out/tag-out valves.

CAUTION

When servicing the SOI valve, always drain out refrigerant before disassembling the valve. This must be done via the access port on the side of the valve.

NOTE

If drain valves are installed on suction and discharge headers, open these valves too to remove build up of liquid during shut-down periods.

5. Open any other valves that may trap gas or liquid. Lock-out/tag-out valves.
6. Recover and/or transfer all vapors per local/state codes and policies.
7. Servicing the compressor unit can proceed at this point. After servicing, ensure to perform a leak check, see Compressor Unit Leak Check procedure.




Figure 5-1. Discharge Bleed Valve, Suction Equalizing Line and Valve

Recommendations when Servicing (Compressors without Slide Valves)

When working on the compressor, care must be taken to ensure that contaminants (i.e. water from melting ice, dirt and dust) do not enter the compressor while it is being serviced. It is essential that all dust, oil or ice that has accumulated on the outside of the compressor be removed before servicing the compressor.

After servicing the compressor, all gaskets, O-rings, roll pins and lock washers must be replaced when reassembling the compressor.

Preparation of Unit For Servicing

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

- A) Shut down the unit, open the electrical disconnect switch and pull the fuses for the compressor motor to prevent the unit from starting. Put a lock on the disconnect switch and tag the switch to indicate that maintenance is being performed.

WARNING

Be cautious when isolating sections of CO₂ piping. CO₂ has a very steep pressure curve, and as sections containing CO₂ warm up, pressures can rise dramatically & well beyond system design.

WARNING

When working with LFG, NG or other dangerous or flammable gases, ensure there are adequate ventilation and vapor detectors. Refer to national fire and building codes. Failure to comply may result in serious injury or death.

WARNING

Avoid skin contact with any condensate or oil. Wear rubber gloves and a face shield when working with condensate or oil. Failure to comply may result in serious injury or death.

- B) Isolate the unit by manually closing the discharge Stop valve. Allow the unit to equalize to suction pressure before closing the Suction Bypass. After the unit has equalized to suction pressure and suction valve closed, use an acceptable means to depressurize the unit that complies with all Local, State and Federal Ordinances.

WARNING

At shutdown, open any other valves that may trap liquids to prevent serious injury and/or damage to equipment.

NOTICE

Recover or transfer all gas vapor in accordance with local ordinances before opening the compressor unit to the atmosphere.

- C) Remove drain plugs from the bottom of compressor housing and the discharge manifold. Drain the oil into appropriate containers.

Compressor Unit Leak Check After Servicing

The compressor unit must be checked for leaks after servicing to ensure a tight system. For additional leak testing information, refer to ASME B31.5 Refrigeration Piping and Heat Transfer Components code.

CAUTION

Do not hydro test compressor unit. Failure to comply may result in damage to equipment.

1. If servicing the compressor unit was completed, proceed to Step 2. Otherwise, isolate the compressor unit from the house system, see Compressor Unit Isolation procedure.
2. Open all shut-off valves, check valves, control valves and solenoid valves in the system to be tested.
3. If equipped with a three-way pressure relief valve, make sure the valve stem is in the mid position (but only during testing).
4. Slowly pressurize compressor unit through suction oil charging port with dry nitrogen.
5. Using appropriate soap solution, check for leaks on joints and connections of the serviced component.
6. If leaks are found, depressurize system and fix leaks. Repeat steps 3 and 4 until all leaks are fixed.
7. Evacuate from suction oil charging port.
8. Close all valves previously opened in the system. Remove tags as per the local lock-out/tag-out procedure.
9. Turn the motor and oil pump disconnect switches to the ON position.
10. Return compressor unit to service.

Oil System Components

Oil Sampling

WARNING

When working with LFG, NG or other dangerous or flammable gases, ensure there are adequate ventilation and vapor detectors. Refer to national fire and building codes. Failure to comply may result in serious injury or death.

WARNING

Improper selection or application of fluid diagnostic products can cause serious injury or damage. The user is solely responsible for making the final selection of products to ensure that the overall system performance and safety requirements are met. These include reviewing fluid compatibility with materials and seals.

WARNING

Avoid skin contact with any condensate or oil. Wear rubber gloves and a face shield when working with condensate or oil. Failure to comply may result in serious injury or death.

DANGER

Sampling often releases hot fluid under high velocity/pressure.

1. Hot fluid can cause severe burn injuries.
2. Skin penetration from high-pressure fluid can occur, causing severe injury, gangrene and/or death. If this happens, immediately contact an experienced medical practitioner.
3. Hot fluid escaping to the atmosphere can ignite if it comes into contact with an ignition source. This can lead to severe property damage.

Recommendations

1. Make sure you're aware of the risks associated with the fluid being sampled or worked with. Check with the manufacturer.
2. If you have not been trained to sample, service, repair, or troubleshoot a pressurized fluid system, especially a hydraulic system, you are at risk of suffering an accident. Seek the proper training before proceeding.

Section 5 • Maintenance/Service

Installation of The Oil Sampler Valve

1. Lubricate the threads (1/4"-18 NPT) with Teflon tape.
2. Tighten to the max. torque 25 ft-lbs (34 N-m). Use 11/16" open wrench. Avoid over tightening.

Pre-Sampling

Use the Vilter Oil Analysis Kit (VPN 3097A) to collect an oil sample for analysis, see Figure 5-2.

Once the sample has been taken, the label must be filled out and pasted on the bottle, and both must be placed inside the mailing tube and sealed with the pre-addressed mailing label.

Below are a few points to remember when taking a sample:

- Sample running compressor units, not cold units. Sample after minimum 30 minutes of compressor operating time.
- Sample after the oil filter.
- Sample according to the sampling procedure below.
- Ensure sampling valves and devices are thoroughly flushed prior to taking a sample.
- Ensure samples are taken as scheduled in the Maintenance and Service Schedule.
- Send samples to the oil analysis lab immediately after sampling, do not wait 24 hours.



Figure 5-2. Oil Analysis Kit (VPN 3097A)

Sampling Procedure

THE SAMPLING PRESSURE RANGE IS LIMITED BETWEEN 5 TO 750 PSI (0.03 – 5.17 MPa). IF THE OPERATING PRESSURE IS ABOVE 750 PSI (5.17 MPa), THE OIL SAMPLING MUST BE DONE WHEN THE COMPRESSOR IS NOT RUNNING AND ENSURE THE SYSTEM PRESSURE IS WITHIN THE 5 TO 750 PSI (0.03 – 5.17 MPa) SAMPLING RANGE.

A 1/4" NPT oil sampling valve is provided either in the oil filter canister cover or in the piping after the filter (See Figure 5-3 or 5-4(a) according to application).

1. Unthread the oil sampling valve cap. For valve #3709A, you also need to turn the knurled locknut clockwise, see Figure 5-4 (b).

NOTE

DO NOT remove the valve from the piping or filter housing.

2. Remove the cap of the oil analysis bottle and position it carefully under the valve spout. (Make sure the valve spout is rotated to the downward position) **SLOWLY AND VERY CAREFULLY** press the "PUSH BUTTON" with your finger to open the valve, and release the button to close it, see Figure 5-5.


WARNING

If the valve is opened too rapidly, a foamy pressurized jet of oil will gush out and splash outside the container.



Figure 5-3. Oil Sampler Valve (VPN #3708A)
For Gas Compression Applications

(a) Oil Sampler Valve for Ammonia and Other Refrigerants Applications



(b) Valve shown ready for oil sampling



(c) Valve shown in lockout position



Figure 5-4. Oil Sampling Valve (VPN #3709A) For Ammonia and Refrigerant Compressors

Button being pressed, valve open



Button released, valve closed



Figure 5-5. Operating the Oil Sampling Valve

Section 5 • Maintenance/Service

3. In most cases there will be foam in the oil, so you must fill the bottle up to the top and then wait for the foam to dissipate. Repeat this step as many times as necessary (around 4 to 6 times) until the clear oil level reaches $\frac{3}{4}$ full, see sequence in Figure 5-6.
4. After all the foam dissipates, tighten the sample bottle cap.
5. Tighten the oil sampling valve cap.
6. For valve #3709A only: back seat the knurled lock-nut by turning it counter-clockwise. This is to prevent any accidental release, see Figure 5-4 (c).
7. Attach the filled sampling information label to the bottle and mail the sample out to the oil analysis lab immediately.

NOTE

Missing information from the sampling label may result in longer turnaround time as the laboratory will need to request the info before the sample can be tested.

Oil Sample Analysis Report

NOTE

A copy of the oil analysis report is also sent to Vilter. See Appendices for a sample of the oil analysis report.

An oil analysis report will show the physical properties of the oil, such as:

- Water content
- Viscosity
- Acid number
- Particle count
- Antioxidant level
- Wear metals
- Contaminating/additive metal



Figure 5-6. Stages of the Oil Sample Taking Process

Oil Draining

WARNING

Avoid skin contact with any liquid refrigerant or oil. Wear rubber gloves and a face shield when working with liquid refrigerant or oil. Failure to comply may result in serious injury or death.

WARNING

When working with refrigerants, ensure there is adequate ventilation and refrigerant vapor detectors as per ASHRAE standards. Failure to comply may result in serious injury or death.

WARNING

Do not drain oil from drain valve while the compressor unit is running. Shutdown the unit and allow pressures to equalize to suction pressure prior to draining. Failure to comply may result in serious injury.

The compressor unit must be shut down prior to draining due to high pressures in the oil system, see Compressor Unit Isolation procedure.

Draining can be performed through the drain valve located underneath the oil separator, see Figure 5-7.

Draining of the remote oil cooler can be performed at the remote oil cooler drain valves. If equipped with lower level drains on the supply and return lines, these too can be utilized for draining.




Figure 5-7. Oil Strainer Drain Valve and Oil Separator Drain Valve

Oil Charging

WARNING

When working with LFG, NG or other dangerous or flammable gases, ensure there are adequate ventilation and vapor detectors. Refer to national fire and building codes. Failure to comply may result in serious injury or death.

CAUTION

Do not add oil to the coalescent side of the oil separator. Failure to comply may result in damage to equipment.

Normal oil level operating range must be maintained for optimum performance and to prevent damage to equipment. See Figure 4-1 for normal operating levels. There are a couple of ways to maintain oil, while the compressor unit is in operation and during shutdown.

Tool Required

- Oil Pump, Maximum 2-3 GPM with Motor approved for Division 1 or Division 2 and with ability to overcome suction pressure.

Charging During Operation

During operation, if the oil level is low, add oil to the operating compressor through the suction oil charging valve, see Figure 5-8. Pump oil into the compressor until the oil level reaches the normal operating level. Watch this level carefully to maintain proper operation. Never allow the oil to reach a level higher than the Maximum Operating Level, since this may impair the operation and efficiency.

1. Using a properly selected oil pump, connect oil pump to suction oil charging valve.
2. Open suction oil charging valve and fill oil separator to Normal Operating Level.
3. Once the Normal Operating Level has been reached, shut off the oil pump and close the valve. Disconnect and remove oil pump.

Charging During Shutdown

During shutdown, if oil is to be added, charging can be performed through the drain valve located underneath the oil separator, see Figure 5-7. During shutdown, oil can be added to the Maximum Non-Operating Level. For shutdown procedure, see Compressor Unit Isolation procedure.

1. Using a properly selected oil pump, connect oil pump to oil separator drain valve.
2. Open oil separator drain valve and fill oil separator to Maximum NON-Operating Level.
3. Once Maximum NON-Operating Level has been reached, shut off oil pump, close oil separator drain valve and remove oil pump.




Figure 5-8. Suction Oil Charging Valve

Filter Element Replacement

WARNING

When working with refrigerants, ensure there is adequate ventilation and refrigerant vapor detectors as per ASHRAE standards. Failure to comply may result in serious injury or death.

WARNING

When working with LFG, NG or other dangerous or flammable gases, ensure there are adequate ventilation and vapor detectors. Refer to national fire and building codes. Failure to comply may result in serious injury or death.

Change the oil filter as outlined in the Maintenance and Service Interval, see Table 5-1. Maintenance & Service Interval.

NOTE

Ensure to check the oil pressure drop and record it daily.

If the compressor unit is equipped with only a single oil filter, the compressor unit must be shut down prior to servicing, see Stopping/Restarting procedure in Section 4.

If the compressor unit is equipped with dual oil filters, then one oil filter can be isolated and serviced one at a time during operation.

See Table 5-2 for the parts required for an oil filter replacement, with their part numbers.

Removal

NOTE

Both outlet shut-off valves should be open. If the outlet valve is closed for the oil filter that is not in operation, slowly open the outlet shut-off valve until fully open. This will help reduce a sudden pressure drop when switching oil filters for servicing.

If equipped with dual oil filters, open inlet shut-off valve for non-operating oil filter to put it into operation, see Figure 5-9.

1. To isolate oil filter for servicing, close inlet and outlet shut-off valves for that oil filter.

NOTE

To reduce unwanted oil splash from a vent or drain valve, connect a hose to the valve port and direct the gas and oil into a drain pan.

2. Slowly release pressure in the oil filter canister by opening the vent valve. Allow pressure to equalize to atmosphere.

NOTICE

Dispose of used oil in an appropriate manner following all Local, State and Federal laws and ordinances.



3. Using a drain pan, open drain valve and allow the oil to completely drain from the oil filter canister.

NOTE

Note orientation of components to aid in installation.

Table 5-2. Oil Filter Replacement Parts Required

KIT	Oil Filter	Oil Filter Element	Element Type
KT819A	3677A	3007C	Single/Dual



Outlet Shut-off Valve

Inlet Shut-off Valve

Drain Valve

Figure 5-9. Oil Filter Inlet, Drain and Shut-Off Valves

Section 5 • Maintenance/Service

4. Use a proper tool to turn the canister knob (at filter bottom) anti-clockwise to unscrew the canister from the filter head. See Figure 5-10.
5. Remove filter element from oil filter canister.
6. Thoroughly clean the interior of the oil filter canister, and the connection area of head assembly.
7. Remove (Canister-to-head) O-ring from inside of filter head. Discard O-ring.

Installation

NOTE

Ensure oil filter element on the outlet side is fully seated on the outlet pipe when installed.

1. Lubricate new O-ring with clean system oil.
2. Install O-ring on inside of filter head.
3. Install oil filter element into head in orientation noted during removal. Make sure filter element is fully seated.
4. Install oil filter canister to the filter head by hand, then tighten canister knob with a wrench.
5. Using dry nitrogen gas, pressurize oil filter canister through vent valve and check for leaks.
6. Close the vent valve and drain valve.
7. Open outlet shut-off valve for the oil filter that is not in operation.
8. Repeat for second oil filter if equipped, as required.




Figure 5-10. Filter Assembly (VPN 3677A Oil Filter Housing Shown)

Switching Oil Filters For Maintenance (Reference Figure 5-11)

When switching oil flow from one filter to the other for maintenance, proceed with the following steps:

1. Slowly open inlet oil filter shut-off valve to oil filter that will be active.
2. Slowly open inlet oil pressure shut-off valve for oil filter to allow oil pressure to be read from oil filter that is now active.
3. Slowly open outlet oil filter shut-off valve to oil filter that is now active.
4. Slowly close inlet and outlet oil filter shut-off valves for oil filter that is to be serviced.
5. Slowly close oil pressure shut-off valve for oil filter that is to be serviced. Remove plug from oil filter head assembly to aid in oil removal.
6. Continue with steps in Removal or Installation of Filter Element Replacement section (see previous pages).




Figure 5-11. Dual Oil Filter (3677A Oil Filter Housings Shown)

Oil Pump Strainer Servicing

To clean the oil pump strainer, proceed with the following steps.

NOTICE

Dispose of used oil in an appropriate manner following all Local, State and Federal laws and ordinances.

WARNING

At shutdown, open any other valves that may trap liquids to prevent serious injury and/or damage to equipment.

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

WARNING

Avoid skin contact with any condensate or oil. Wear rubber gloves and a face shield when working with condensate or oil. Failure to comply may result in serious injury or death.

1. Shut down the compressor unit, refer to Stopping/Restarting procedure in Section 4.
2. Turn disconnect switches to the OFF position for the compressor unit and oil pump motor starter, if equipped.

3. Close shut-off valves located before the strainer, at the oil filter inlet(s), oil cooler inlet and oil cooler outlet.
4. Position drain pan under drain valve.
5. Open strainer drain valve and allow oil to completely drain, see Figure 5-12.
6. Remove bolts securing strainer cover to strainer. Remove strainer cover, gasket and element. Retain gasket.
7. Inspect gasket for damage, replace as required.
8. Wash element in solvent and blow it with clean air.
9. Inspect element for damage, replace as required.
10. Clean strainer cavity with clean lint-free cloth.
11. Install in reverse order of removal. For torque specifications, see Table A-3 in Appendix A.
12. Close strainer drain valve.
13. Open shut-off valves.
14. Check replaced components for leaks.
15. Turn disconnect switches to the ON position for the compressor unit and oil pump motor starter, if equipped.
16. Start compressor unit.





Figure 5-12. Oil Pump Strainer and Drain Valve

Oil Separator Coalescing Filter Replacement

WARNING

When working with refrigerants, ensure there is adequate ventilation and refrigerant vapor detectors as per ASHRAE standards. Failure to comply may result in serious injury or death.

WARNING

Avoid skin contact with any condensate or oil. Wear rubber gloves and a face shield when working with condensate or oil. Failure to comply may result in serious injury or death.

WARNING

Use appropriate lifting devices and additional personnel when lifting heavy components. Ensure lifting devices are capable of lifting the weight of the component. Use lifting points (i.e. bolt holes designated for lifting eye bolts) that are provided on the component. Failure to comply may result in serious injury.

NOTE

For coalescing oil filters (11-7/8 in. O.D.), a tubing (3/4 in. O.D. x 6 ft. long) can be used to aid in removal and installation of the element.

Removal

1. Isolate the compressor unit, see Compressor Unit Isolation procedure.
2. If required, install lifting eyes on oil separator manhole cover, see Figure 5-13.
3. Secure appropriate lifting device to oil separator manhole cover.
4. Remove all bolts except top four bolts securing oil separator manhole cover to oil separator vessel.
5. Adjust lifting device as needed to hold weight of oil separator manhole cover.
6. Remove remaining four bolts and oil separator manhole cover from oil separator vessel.
7. Remove nuts, flat washer and cover plate securing coalescing oil filter to hold-down rod.
8. With assistance of second person, remove coalescing filter from oil separator vessel.
9. Repeat steps 7 and 8 to remove additional coalescing filters, as required.

Installation

10. Install tubing over hold-down rod. Position tubing as far back as possible.
11. With assistance of second person, position coalescing element over tubing and through hole of centering strap.
12. Push coalescing filter into vessel until fully seated on pipe stub.
13. Remove tubing.
14. Position cover plate and flat washer on hold-down rod on end of the coalescing filter.
15. Install nut to secure flat washer and cover plate to coalescing filter. Tighten nut to 25 ft-lbs.
16. Install second nut to prevent first nut from moving.
17. Repeat steps 10 to 16 for installing additional coalescing filters.
18. Position oil separator manhole cover on oil separator vessel.
19. Install bolts to secure oil separator manhole cover to oil separator vessel.
20. Tighten bolts, see Table A-3 in Appendix A.
21. Perform Compressor Unit Leak Check procedure.




Figure 5-13. Oil Separators, Manhole Covers and Coalescing Filter Assemblies

Oil Separator Heater Cartridge Replacement

Parts Required

- **Heater Cartridges with loose wires**
 - Heater Cartridge, 1000W, 480V (VPN 3555A)
 - Heater Cartridge, 500W, 120V (VPN 3116A)
 - Heater Cartridge, 1000W, 120V (VPN 3116B)
 - Heater Cartridge, 750W, 120V (VPN 3116E)
 - Heater Cartridge, 1250W, 120V (VPN 3116J)
 - Heater Cartridge, 1000W, 220V (VPN 3116K)
- **Heater Cartridges with Turck connectors**
 - Heater Cartridge, 750W, 120V (VPN 3116C)
 - Heater Cartridge, 500W, 120V (VPN 3116D)
 - Heater Cartridge, 1250W, 120V (VPN 3116F)
- Anti-Seize, High Temperature (-65 °F to 2400 °F)


Removal

1. Isolate the compressor unit, see Compressor Unit Isolation procedure.
2. Drain oil from oil separator, see Oil Draining procedure.
3. For heater cartridges with Turck connectors, see Step 4. For heater cartridges with loose wires, see steps 5 to 9.

Heater Cartridges with Turck Connectors:

4. Disconnect Turck connector.

Heater Cartridge WITHOUT Turck Connector



Heater Cartridges with Loose Wires:

5. Remove junction cover to gain access to heater cartridge wires.

NOTE

Note location of wires to aid in installation.

6. Disconnect wires.
7. Remove cable connector.
8. Remove cable and wires from junction.
9. Remove junction from heater cartridge.
10. Remove heater cartridge from thermowell.

Installation

11. Apply anti-seize to threads of heater cartridge.
12. Install heater cartridge in thermowell.
13. For heater cartridges with Turck connectors, see Step 14. For heater cartridges without Turck connectors, see steps 15 to 19.

Heater Cartridges with Turck connectors:

14. Connect Turck connector.

Heater Cartridges with loose wires:

15. Install junction on heater cartridge.
16. Route cable and wires through junction.
17. Connect wires as noted during removal.
18. Install cable connector.
19. Install junction cover.

Heater Cartridge WITH Turck Connector




Figure 5-14. Heater Cartridges

Pressure Relief Valve

The purpose of a pressure-relief valve is to vent to the atmosphere any temporary excessive overpressure that could be present inside a vessel. As such, it is intended for a one-time over-pressure operation.

Once the valve has discharged, it attempts to re-seat itself to minimize the refrigerant loss, but it still must be replaced as soon as possible since debris may have settled on the seat during discharge, and because setting or seat tightness may have been altered during the occurrence. A relief valve must be replaced after 5 years of service in application, even if it has never discharged.

Service and Maintenance

The tamper-resistant pressure-relief valves are accurately set from factory and don't require any field adjustments. However, a few maintenance tips must be kept in mind:

- An effort should be made to protect the valve from dirt and moisture.
- Avoid trapped ice build-up between valves and other equipment.
- Visually inspect the relief valve once a year, to detect corrosion or accumulation of scale and for leaks.

Replacement

Even when simply replacing an existing valve, a review of requirements per current local and national code is advisable.

WARNING

Avoid skin contact with any liquid refrigerant or oil. Wear rubber gloves and a face shield when working with liquid refrigerant or oil. Failure to comply may result in serious injury or death.

WARNING

When working with refrigerants, ensure there is adequate ventilation and refrigerant vapor detectors as per ASHRAE standards. Failure to comply may result in serious injury or death.

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious

Do not install valves in a refrigerated space unless precautions are taken to prevent moisture migration into the valve body or the relief vent line.

- Ensure that both the valve and related piping have been isolated from the refrigeration system before attempting the replacement. Pump out pressure to zero.
- Vent the relief valve to a safe outdoor location in an approved manner, away from people and building openings.
- When putting into service a dual pressure-relief system, the new three-way valve stem should be positioned so that only one valve is exposed to pressure.
- Apply thread sealing compound only to external pipe threads and use a small amount to avoid getting compound inside the valve.
- Use brackets or hangers to support the pipe and prevent the valve from being overly stressed, and don't put undue stress on it by using it to stretch or align pipe.
- Do not discharge valves prior to installation or when pressure testing. Never attempt to reset or change the valve setting.

While the valve can be either front seated (front port is closed) or back seated (back port is closed, see Figure 5-15), the back seated position is recommended because it takes pressure off the packing and reduces the possibility of packing leaks.

When leak testing a dual pressure-relief system, the three-way valve stem of the pressure relief valve should be in the mid position. Refer to Compressor Unit Leak Check procedure.




Figure 5-15. Three-way Dual Shut-off Pressure Relief Valve (Back Seated)

Lovejoy Quick Flex Standard Coupling Installation

Please complete the following steps to install QUICK FLEX couplings (See Figure 5-16 and Figure 5-17).

You should have the following pieces before starting the job:

- Two hubs (See Figure 5-16 and Table 5-4 for dimensions)
- One insert (See Figure 5-22 and Table 5-5 for dimensions)
- One cover with included hardware (See Figure 5-25 and Table 5-5 for dimensions).



Figure 5-16. Standard Coupling with High-Speed Cover




Figure 5-17. Standard Coupling Cutaway - with Blue Insert

Installation

WARNING

Failure to observe the following warnings could cause serious injury or death.

Contact with moving parts and/or rotating shafts poses a risk of serious injury. Proper guards in accordance with OSHA and American Society of Mechanical Engineers standards must be installed on all power transmission equipment. Power transmission equipment should not be started if proper guarding is not in place. Observe all required lock out/tag out procedures when servicing power transmission equipment.

1. Check the bore size of the coupling halves and the shafts. Ensure that they are the correct bore size to fit the application.
2. If the coupling does not fit easily, clean and deburr the shafts.
3. Slide on the high-speed cover:
It should be placed on the driven shaft. If space does not permit, then it can be mounted on the drive shaft. If cover uses a snap ring, slide the snap ring down the shaft, then slide the cover onto shaft with the larger opening facing the shaft separation.
4. Install the first hub. It should be mounted so the end of the shaft is flush with surface "A" as shown in Figure 5-18. It is acceptable for the shaft to extend past "A" as long as it is not past the teeth shown as "B."




Figure 5-18. Proper Shaft-to-Hub Engagement

Section 5 • Maintenance/Service

5. Install the second hub with the insert in place. This will set the hubs at the minimum hub gap (GMin) dimension, ensuring proper clearance. For specific GMin and GMax dimensions see Table 5-4.

NOTE

Shaft should penetrate to base of teeth and hubs should be set at GMin. Otherwise, the coupling may not deliver maximum torque.
8. Install the High-speed Cover:
Slide the cover over the hub and insert until fully rested against the shoulder of the hub. QF100 use standard snap rings to hold the cover in place (See Figure. 5-26). Use the included hardware to secure the cover
6. Tighten both hubs securely to the shafts.
7. Check coupling for misalignment (See Figure 5-19 and Table 5-3) and align as necessary.

Table 5-3. QUICK FLEX Standard Coupling Misalignment Tolerances

Coupling Series	Radial Misalignment Tolerance	Axial Misalignment Tolerance	Angular Misalignment Tolerance
	mm in	mm in	
QF100	0.0508	0.0508	2°
	0.002	0.002	




Figure 5-19. Types of Misalignment

Standard Coupling with High-Speed Cover




Figure 5-20. High Speed Cover




Figure 5-21. Standard Coupling with High-Speed Cover

Table 5-4. QUICK FLEX Standard Coupling with High Speed Cover Dimensions

Coupling Series	Max. Bore Size	Max. RPM	Cont. Torque ¹	A	C	D1	D2	D3	F	G _{Min}	G _{Max}	H	L1	P	X
	mm in		Nm in-lbs	mm in	mm in	mm in	mm in	mm in	mm in	mm in	mm in	mm in	mm in	mm in	mm in
QF100	75	4800	3177	179	90	177	108	150	62	4	5	86	44	75	55
	3		28115	7.07	3.55	7.00	4.25	5.92	2.46	0.18	0.21	3.40	1.76	2.96	2.19

Notes-

1 indicates: When used with blue insert.

2 indicates: Weights shown are approximate weights of complete coupling assemblies including two pilot-bore hubs, cover and insert.

QUICK FLEX Insert

Table 5-5. QUICK FLEX Insert Dimensions

Coupling Series	L	M	N	Wt.
	mm in	mm in	mm in	kg lbs
QF100	77.5	163.6	51.3	0.7
	3.05	6.44	2.02	1.5




Figure 5-22. High Speed Cover

Storage of Components

Lovejoy suggests the following storage guidelines for its coupling components

(Hereinafter referred to as “products”):

- Unless directed otherwise by Lovejoy, products should be kept in their original packaging until they are ready to be placed into service.
- Do not remove or alter any labels or stencil markings on the packaging.
- Products should be stored in such a way that the packaging is not pierced, crushed, or otherwise damaged.
- After a product is removed from its packaging, it should be placed into service as soon as possible.
- When removing a product that is not individually packaged from a bulk pack container, the container should be resealed immediately after the product is removed.
- The relative humidity should be maintained below 60 percent and the surfaces should be dry.
- The storage area should be kept free from airborne contaminants such as, but not limited to, dust, dirt, harmful vapors, etc.
- Extreme conditions of any kind should be avoided. In as much as Lovejoy is not familiar with a customer’s particular storage conditions, these guidelines are strongly suggested. However, the customer may very well be required by circumstance or applicable government requirements to adhere to stricter storage requirements. Upon receipt of a product shipment, ensure that the product is not removed from its packaging until it is ready for mounting so that it does not become corroded or contaminated. Product should be stored in an appropriate atmosphere in order that it remains protected for the intended period. Any questions concerning storage should be directed to your local sales office.

Drive Coupling Hub (Form-Flex BPU) Installation

On all single screw units, the coupling assembly is shipped loose and will have to be installed and aligned on site. This is to allow a check of proper electrical phasing and direction of motor rotation. The motor and compressor have been aligned from the factory with the coupling hubs already installed. Using a dial indicator for aligning is recommended.

NOTE

Drive coupling type and size can be determined by the information on the compressor nameplate when ordering; Order Number and Compressor Model Number.

To install the coupling, proceed with the following steps:

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

1. Ensure disconnect switches are in the OFF position for the compressor unit and oil pump motor starter, if equipped.
2. If hubs are already installed on motor shaft and compressor shaft, proceed to Drive Center Member Installation and Alignment procedure.
3. If coupling assembly is already assembled, the lock nuts are not torqued. Remove lock nuts and bolts securing hubs to disc packs. Remove both hubs. Leave the disc packs attached to center member.
4. Clean hub bores and shafts. Remove any nicks or burrs. If bore is tapered, check for good contact pattern. If bore is straight, measure bore and shaft diameters to ensure proper fitting. The keys should have a snug side-to-side fit in the keyway with a small clearance over the top.

NOTE

If hub position on shaft does not allow enough room to install bolts, install bolts and disc pack before mounting hub on shaft.

Hubs come in two different types, straight bore and tapered bore. Tapered bore hubs have additional hardware. Typically, a compressor will have a tapered shaft and therefore use a tapered bore hub.

Straight Bore Hubs

5. For straight bore hubs, install key in keyway of shaft.
6. Install hub on shaft. If installing straight bore hubs on motor and compressor shafts, allow 1/16" gap between the outer face of the hub to the outer face of the shaft for both hub installation. This will allow some play when installing the spacer. If installing a straight bore hub and a taper bore hub, allow a 1/8" gap between the outer face of the straight bore hub to the outer face of the straight shaft, see Table 5-6.
7. Install clamping bolts in hub.
8. Tighten clamping bolts, see Table 5-7.
9. Install set screw in hub to secure key.
10. Tighten set screw, see Table 5-7. Repeat steps for second straight bore hub.

Tapered Bore Hubs

11. For tapered bore hubs, do not use Anti-seize because this will allow the hub to slide on farther than without, and you may not be able to get it removed. Install key in keyway of shaft.
12. Install hub on shaft.
13. If lock washers are being used, install hub cap, lock washers and bolt on shaft.
14. If locking tab is being used, install hub cap, locking tab and bolt on shaft.
15. Tighten bolt and draw hub up shaft to a stop.

Coupling Size	Shaft Gap for Tapered Compressor & Straight Motor Shaft Combination	Shaft Gap for Straight Compressor & Straight Motor Shaft Combination	Distance Between Hub Faces
BP38U	6.25" (158.75 mm)	5.125" (130.18 mm)	5.00" (127 mm)
BP41U			
BP47U			
BP54U			
BP54U			
BP56U			

Table 5-6. Shaft and Hub Distances

Table 5-7. Hub Clamp Bolt and Set Screw Torque Specifications

Coupling Series/Size	Clamping Bolt			Set Screw	
	# Bolts	Size-Pitch	Torque ft-lbs (Nm)	Size	Torque ft-lbs (Nm)
BH38U	4	1/4-28	12 (16)	3/8	10 (13)
BH41U	4	5/16-24	23 (31)	3/8	10 (13)
BH47U	4	3/8-24	49 (66)	1/2	20 (27)
BH54U	4	7/16-20	78 (106)	1/2	20 (27)
BH56U	4	1/2-20	120 (163)	5/8	40 (54)
DP42	4	1/2-20	120 (163)	1/2	20 (27)

16. If locking tab is being used, bend locking tabs in gap towards shaft and around bolt.
17. Install set screw in hub cap to secure key in keyway of shaft.
18. Tighten set screw, see Table 5-7.

Drive Center Member Installation and Alignment

NOTE

Always adjust motor to the compressor. The compressor is aligned to the frame.

19. Adjust motor position as needed to obtain a distance of 5" between both hub faces.
20. Soft Foot. The motor must sit flat on its base (+/- 0.002"). Any soft foot must be corrected prior to center member installation.

NOTE

If the driver or driven equipment alignment specification is tighter than these recommendations, the specification should be used. Also, be sure to compensate for thermal movement in the equipment. The coupling is capable of approximately four times the above shaft alignment tolerances. However, close alignment at installation will provide longer service with smoother operation. The flex disc pack is designed to an optimal thickness and is not to be used for axial adjustments.

21. *Axial Spacing.* The axial spacing of the shafts should be positioned so that the flex disc packs are flat when the equipment is running under normal operating conditions. This means there is a minimal amount of waviness in the flex disc pack when viewed from the side. This will result in a flex disc pack that is centered and parallel to its mating flange faces. Move the motor to obtain the correct axial spacing, see Table 5-8 and Figure 5-23.




Figure 5-23. Hub Distance (Axial Spacing)

Table 5-8. Disc Pack Installation Torque Specifications

Coupling Size	Lock Nut Size	Tightening Torque ft-lbs (Nm)
BP38U	5/16-24	22 (30)
BP41U	7/16-20	55 (75)
BP47U	9/16-18	120 (163)
BP54U	9/16-18	120 (163)
BP56U	9/16-18	120 (163)




Figure 5-24. Angular Alignment and Parallel Offset

22. *Angular Alignment.* Rigidly mount a dial indicator on one hub or shaft, reading the face of the other hub flange. Rotate both shafts together, making sure the shaft axial spacing remains constant. Adjust the motor by shimming and/or moving so that the indicator reading is within 0.002" overall, see Figure 5-24.
23. *Parallel Offset.* Rigidly mount a dial indicator on one hub or shaft, reading the other hub flange outside diameter. Indicator set-up sag must be compensated for. Rotate both shafts together. Adjust the equipment by shimming and/or moving so that the indicator reading is within 0.002" overall, see Figure 5-24.

With the coupling in good alignment the bolts will fit through the holes in the flanges and the disc packs more easily.

NOTE

All bolt threads should be lubricated. A clean motor oil is recommended. On size 226 and larger, a link must be put on bolt first. Remove the disc pack alignment bolt. Proceed to mount the second disc pack to the other hub in the same way. Ensure that the beveled part of the washer is against the disc pack.

24. Install bolts and locking nuts to secure both disc packs to center member.
25. Tighten locking nuts.

26. If room is required to install center member, adjust hub position accordingly. If both the motor and compressor hubs are straight bores, adjust either hubs. If one hub is tapered and the other is straight, adjust the straight bore hub.
27. Use additional supports supporting center member. Install bolts and locking nuts to secure center member to compressor hub.
28. Tighten locking nuts.
29. Position hubs, ensure distance between face of both hubs is 5".

NOTE

If there is waviness with the disc pack installed, adjust distance accordingly until disc pack is straight.

30. Install bolts and locking nuts to secure disc pack to motor hub.
31. Tighten locking nuts, see Table 5-8.
32. Perform hot alignment. Run compressor unit and allow to warm up completely.
33. Power down compressor unit and re-check alignments. Loosen motor mounting nuts to add shims or to adjust alignments as required.
34. Install coupling guard.

Drive Coupling Hub (Form-Flex BPU) and Center Member Removal

To remove coupling assembly, proceed with the following steps:

WARNING

At shutdown, open any other valves that may trap liquids to prevent serious injury and/or damage to equipment.

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

NOTE

Drive coupling type and size can be determined by the information on the compressor nameplate when ordering; Order Number and Compressor Model Number.

1. Shut down the compressor unit, refer to Stopping/Restarting procedure in Section 4.
2. Turn disconnect switches to the OFF position for the compressor unit and oil pump motor starter, if equipped.
3. Allow compressor, motor and surrounding components to cool prior to servicing.
4. Remove coupling guard.
5. Remove lock nuts and bolts securing disc pack to hub on compressor shaft.
6. If additional room is required to remove the center member, loosen clamping bolts on straight bore hub(s).
7. Move straight bore hub on shaft as required to allow center member removal.
8. Remove lock nuts and bolts securing disc pack to hub on motor shaft. Remove center member.
9. For straight bore hubs, remove clamping bolts and hub from shaft.
10. For tapered bore hubs, remove bolt, lock washers, large washer and hub from shaft.

Drive Coupling (Type C Sure-Flex) Replacement

Drive couplings that are the Type C Sure-Flex type, are always installed with a C-flange between the compressor and motor. The coupling assembly alignments are built into the design and therefore, should not require alignment.

NOTE

Drive coupling type and size can be determined by the information on the compressor nameplate when ordering; Order Number and Compressor Model Number.

Removal

To remove Type C Sure-Flex coupling, proceed with the following steps:

WARNING

At shutdown, open any other valves that may trap liquids to prevent serious injury and/or damage to equipment.

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

1. Shut down the compressor unit, refer to Stopping/Restarting procedure in Section 4.
2. Turn disconnect switches to the OFF position for the compressor unit and oil pump motor starter, if equipped.
3. Allow compressor, motor and surrounding components to cool prior to servicing.
4. Remove C-flange access cover.

NOTE

Mark locations of hubs prior to removal.

5. Loosen set screw in motor hub securing key in keyway.
6. Loosen clamping bolts securing hub to motor shaft.
7. Pry hub up motor shaft for space to remove coupling sleeve.
8. Remove coupling sleeve from hub.
9. Remove hub and key from motor shaft.
10. Loosen set screw in compressor hub securing key in keyway.

Section 5 • Maintenance/Service

11. Loosen clamping bolts securing hub from compressor shaft.
12. Remove hub and key from compressor shaft.

Installation

13. Install key and hub on compressor shaft as noted during removal.
14. Install set screw in compressor hub to secure key in keyway, see Table 5-9.
15. Install clamping bolts to secure hub on compressor shaft. Tighten clamping bolts, see Table 5-9.
16. Install key and hub on motor shaft as noted during removal. Allow gap to install coupling sleeve.
17. Install coupling sleeve on hubs. Position hub on motor shaft on coupling sleeve as noted during removal.
18. Install set screw in compressor hub to secure key in keyway. Tighten set screw, see Table 5-9.
19. Install clamping bolts to secure hub to motor shaft. Tighten clamping bolts, see Table 5-9.

Table 5-9. Clamping Bolts and Set Screw Torque Specifications

Coupling Size	Type C ft-lbs (Nm)	
	Clamping Bolts	Key Set Screw
6	13 (18)	13 (18)
7	13 (18)	
8	23 (31)	
9	23 (31)	
10	50 (68)	
11	50 (68)	

Coupling Guard Replacement

NOTE

Coupling guards may differ slightly but this replacement procedure can be used to remove and install them. The coupling guard assembly described in this procedure is VPN A27435C.

WARNING

The design, construction, mounting and opening of coupling guards should be performed following proper local codes. Failure to comply may result in serious injury or death.

Removal

Reference Figure 5-23.

1. Shut down compressor unit, see Compressor Unit Isolation for Maintenance/Service procedure.
2. Remove eight screws (1) and flat washers (2) securing upper guard (7) to lower guard (8).
3. Remove three screws (1) and flat washers (2) securing upper guard (7) to ring mounting guard (5). Remove upper guard.
4. Remove two screws (1) and flat washers (2) securing lower guard (8) to ring mounting guard (5). Remove lower guard.
5. Remove eight fasteners (6) from lower guard (8).

6. Remove four nuts (4), screws (1) and flat washers (2) securing ring mounting guard (5) to four support brackets (3). Remove ring mounting guard.
7. Remove five fasteners (6) from ring mounting guard (5).
8. Remove four screws (9), lock washers (10) and flat washers (11) securing support brackets (3) from compressor. Remove support brackets. Discard lock washers.

Installation

9. Install four flat washers (11), new lock washers (10) and screws (9) to secure support brackets (3) to compressor. Do not fully tighten.
10. Install five fasteners (6) to ring mounting guard (5).
11. Install four screws (1), flat washers (2) and nuts (4) to secure ring mounting guard (5) to four support brackets (3).
12. Tighten nuts (4) and screws (9).
13. Install eight fasteners (6) to lower guard (8).
14. Install two flat washers (2) and screws (1) to secure lower guard (8) to ring mounting guard (5).
15. Install three flat washers (2) and screws (1) to secure upper guard (7) to ring mounting guard (5).
16. Install eight flat washers (2) and screws (1) to secure upper guard (7) to lower guard (8).
17. Return compressor unit to service.




Figure 5-25. Coupling Guard Assembly (VPN A27435C shown)

Compressor Replacement

Notify Vilter™ prior to performing a compressor replacement. See Warranty instructions in Section 7.

Removal

To replace a compressor on a unit, proceed with the following steps:

NOTICE

Dispose of used oil in an appropriate manner following all Local, State and Federal laws and ordinances.

1. Shut down and isolate the compressor unit, see Compressor Unit Isolation for Maintenance and Service procedure.

NOTE

Note location of cables to aid in installation.

2. Disconnect all cables from sensors on compressor and actuators.
3. Remove coupling guard, see Coupling Guard Replacement procedure.
4. Remove drive coupling, see appropriate Drive Coupling Replacement procedure.
5. Remove center member, see Drive Coupling Removal procedure.

NOTE

Use appropriate supporting equipment to support and keep motor, C-flange and compressor leveled.

6. If equipped with C-flange, remove bolts securing C-flange to compressor.
7. Using appropriate drain pan, drain oil by removing drain plugs from under compressor housing and discharge manifold. Allow oil to completely drain.
8. Remove all oil lines from the compressor.
9. Support suction line with appropriate supporting equipment.
10. Remove nuts and bolts securing suction strainer/check valve assembly to suction stop valve and compressor.
11. Using appropriate lifting device, remove suction strainer/check valve assembly from compressor.
12. Remove nuts and bolts securing discharge pipe to compressor and oil separator, see Figure 5-26.
13. Remove discharge pipe and gaskets from compressor and oil separator.
14. Remove nuts, flat washers, lock washers and studs securing compressor to frame.
15. Remove any additional lines and/or components to allow removal of compressor as required.




Figure 5-26. Compressor Replacement and Hardware Assembly

Section 5 • Maintenance/Service

NOTE

Refer to Bareshaft Compressor Lifting Points and Weights Section for appropriate lifting hole sizes, weights and lifting points.

16. Install appropriate lifting eyes on top of compressor.
17. Using appropriate lifting device and additional personnel, remove compressor from frame.
18. Remove shims and spherical washers from compressor mounting locations.
19. Inspect shims and spherical washers for damage, replace as required.

34. Install all lines to compressor.
35. Install all cables to sensors on compressor and actuator.
36. Perform leak check, see Compressor Unit Leak Check procedure.

Installation

20. Install shims and spherical washers on compressor mounting locations, see Figure 5-26.
21. Install appropriate lifting eyes on top of compressor.
22. Using appropriate lifting device, position compressor on compressor mounting locations on frame.
23. Loosely install studs, lock washers, flat washers and nuts to secure compressor to frame until alignment is correct.
24. Check compressor for soft foot. Add or remove shims as required until measurements are within ± 0.002 ".
25. Tighten nuts to secure compressor to frame, refer to Table A-1 or Table A-2 in Appendix A.
26. If equipped with C-flange, install bolts to secure C-flange to compressor. Tighten bolts, refer to Table A-1 or Table A-2 in Appendix A.
27. Install drive coupling, see appropriate Drive Coupling Replacement procedure.
28. Install center member, see Drive Center Member Installation and Alignment procedure.
29. Install coupling guard, see Coupling Guard Replacement procedure.
30. Install nuts and bolts to secure discharge pipe to oil separator and compressor.
31. Tighten nuts on 'discharge pipe-to-compressor flange' first, then tighten nuts on 'discharge pipe-to-oil separator flange', refer to Table A-1 or Table A-2 in Appendix A.
32. Install nuts to secure suction strainer/check valve assembly to compressor and suction stop valve.
33. Tighten nuts on 'suction strainer/check valve assembly-to-compressor' first, then tighten nuts on 'suction strainer/check valve assembly-to-suction stop valve', refer to Table A-1 or Table A-2 in Appendix A.

Bareshaft Compressor Lifting Points and Weights

Table 5-10. Bareshaft Compressor Component Weights

Models	Component Weights				
	Gaterotor Bearing Housing	Gaterotor Bearing Housing Cover	Discharge Manifold	Main Compressor Assembly ONLY	Gaterotor Cover
128-243	14 lbs (6.35 kg)	9 lbs (4.08 kg)	160 lbs (72.57 kg)	1095 lbs (498 kg)	26 lbs (11.79 kg)
291-601	19 lbs (9 kg)	11 lbs (5 kg)	125 lbs (57 kg)	1105 lbs (502 kg)	46 lbs (21 kg)

Table 5-11. Bareshaft Compressor Component Lifting Hole Sizes

Models	Component Lifting Hole Sizes				
	A	B	C	D	E
	Discharge Manifold (Side)	Discharge Manifold (Top)	Main Compressor Assembly ONLY (Discharge)	Main Compressor Assembly ONLY (Suction)	Gaterotor Cover
128-243	1/2 - 13 UNC -2B		1/2 - 13 UNC -2B	1/2 - 13 UNC -2B	-
291-601	5/8-11 UNC -2B	5/8-11 UNC -2B	5/8-11 UNC -2B	5/8-11 UNC -2B	3/8-16 UNC -2B




Figure 5-27. Bareshaft Compressor Lifting Points and Component Weights

Bare Shaft Compressor Center of Gravity (Models 128-243)




Figure 5-28. Bare Shaft Compressor Assembly Center of Gravity (Models 128-243)

Table 5-12. Bare Shaft Compressor Weights

COMPRESSOR MODEL	VSG128	VSG145	VSG160	VSG180	VSG204	VSG222	VSG243
Weight	1095 LBS	1095 LBS	1095 LBS	1090 LBS	1090 LBS	1090 LBS	1090 LBS

Bareshaft Compressor Center of Gravity (Models 291-601)




Figure 5-29. Bareshaft Compressor Assembly Center of Gravity (Models 291-601)

Center of gravity may differ slightly between models 291-601. Adjust main lift point within the range to keep bareshaft compressor as leveled as possible when lifting.




Figure 5-30. Bareshaft Compressor Center of Gravity - Discharge Manifold and Main Compressor Assembly (Models 291-601)

Suction Tee Strainer Replacement (For Compressors VSCC 128 - 243)

The below procedure references tool A24061A which is shown in Figure 5-31 on the next page.

NOTE

Always ensure compressor unit is locked out/ tagged out and depressurized before working on the compressor.

1. With gaterotor side cover removed re-install two bolts (item 102).
2. Install both support pillars (items 103) into the lifting holes of the main compressor frame.
3. Install support plate (item 104) using two nuts (item 105). Torque to 68ft-lbs
4. Install two u-bolts (item 107) into the support plate (item 104) but do not tighten nuts.
5. Slide cantilever beam (item 106) through u-bolts such that the un-capped end sticks approximately 18" from the support pillar toward the suction tee (see dimensional view on drawing). Tighten the nuts on the u-bolts to 8ft-lbs.
6. Slide the lifting eye (item 108) over the uncapped end of the beam and tighten the end cap (item 109).
7. Attach the ratchet strap (item 101) to the opposite end of the beam and bolts. Tighten the ratchet until there is tension on the strap.
8. Install hoist ring (item 111) into the lifting hole of the suction tee. Torque per value specified on the hoist ring.
9. Attach chain hoist (item 110) to the lifting eye on the cantilever beam.
10. Hook the other end of the chain hoist to the hoist ring on the suction tee.
11. Tighten the chain hoist until there is a small amount of tension on the hoist.
12. Remove socket head cap screws that attach the suction tee to the compressor and bolts/studs that connect the suction tee to the suction line/check valve.
13. Once all bolts/studs are removed, the suction tee can be lowered to the ground (take care of any oil that may be present in the suction tee).
14. Use a snap ring plier to remove the snap ring, then remove the old strainer.
15. Put in the new strainer and put back the snap ring.
16. Once ready to re-assemble, the chain hoist can then lift the suction tee back into place before being bolted down.

WARNING

Do not use this tooling to lift objects weighing more than 140 LBS




Figure 5-31. Tool (A24061A) To Handle Suction Tee Assembly

Compressor Inspection

Compressor Shaft Bearing Clearance Inspections

If clearance measurements are out of tolerance, contact Vilter Technical Support for further assistance.

CAUTION

When taking the measurements, do not exceed 300 to 500 lbs of force at point of contact or damage may result to the bearings.

Determine Maximum Applied Force


To determine maximum applied force, take maximum applied force at hub/shaft multiplied by length of A and divide by length B. This is the maximum force that should be applied on the lever.

$$(\text{Applied Force} \times A) / B = \text{Applied Force (Maximum)}$$

So, using a 36" (or 1 m) lever with pivot space of 6" (or 15 cm) would make the maximum applied force to be 60 lbf (or 235 N). Calculation is as follows:

$$(300 \text{ lbf} \times 6") / 30" = 60 \text{ lbf (Max. Applied Force)}$$

$$(1335 \text{ N} \times 15 \text{ cm}) / 85 \text{ cm} = 235 \text{ N (Max. Applied Force)}$$



As a quick reference, Table 5-13 shows maximum applied forces for 36" lever with 6" pivot for all compressor models.

Main Rotor Bearing Axial Clearance Inspection

To inspect bearing axial clearance, proceed with the following steps:

1. Remove center member, see appropriate Drive Coupling Replacement procedure.

2. Install dial indicator to the compressor frame and zero indicator, see Figure 5-32.
3. Place lever arm and fulcrum behind compressor coupling half and push the coupling towards the motor. Record measurement.
4. Re-zero indicator, now position the fulcrum on the motor and use the lever arm to push the input shaft towards the compressor. Record measurement.
5. Add both measurements. If measurement is out of allowable tolerance shown in Table 5-13, the bearing may need to be replaced. Contact Vilter™ Technical Support.





Figure 5-32. Bearing Axial Clearance Inspection

Section 5 • Maintenance/Service

Main Rotor Bearing Radial Clearance Inspection

6. Install dial indicator to the compressor frame and zero indicator, see Figure 5-33.

NOTE

Do not exceed maximum applied force. For maximum applied forces of all compressor models, see Table 5-13.

7. Place lever arm and fulcrum underneath hub and push hub upwards. Record measurement.
8. If measurement is out of allowable tolerance shown in Table 5-13, the bearing may need to be replaced. Contact Vilter™ Technical Support.




Figure 5-33. Bearing Radial Clearance Inspection

Table 5-13. Maximum Main Rotor Bearing Clearance

Compressor Model	Max. Axial Clearance in. (mm)	Max. Radial Clearance in. (mm)	Max. Force at Hub/Shaft lbf (N)	Max. Applied Force (36" Lever, 6" Pivot) lbf (N)
128, 145, 160, 180, 204, 222, 243	0.002 (0.051)	0.006 (0.152)	100 (444)	20 (89)
291, 341, 451, 601		0.007 (0.178)	150 (667)	30 (133)

Gaterotor Bearing Inspection

- 1. Position a one gallon (at least) plastic oil collection bin beneath the side cover. Carefully pry open the side cover to allow the oil to drain before finally removing the side cover.
- 2. To measure the gaterotor radial bearing clearance, position a dial indicator to the gaterotor shaft as shown in Figure 5-35 (a) and zero the indicator. Put a hand as shown and firmly move the shaft in the direction shown in Figure 5-34 (a). Record the measurement. See Table 5-14 for the maximum radial clearance value.
- 3. To measure the gaterotor axial bearing clearance, position a dial indicator on the gaterotor, as shown in Figure 5-34 (b).

- 4. To check axial bearing clearance use a lever arm pivoting on a bolt with a small block of wood against the gaterotor to protect it, as shown in Figure 5-34 (b). Record the measurement. See Table 5-14 for the maximum axial clearance value.

Table 5-14. Maximum Gaterotor Bearing Clearance

Compressor Models	Max. Axial Clearance in (mm)	Max. Radial Clearance in (mm)
All Sizes	0.002" (0.051 mm)	0.004" (0.102 mm)




Figure 5-34(a): Radial




Figure 5-34(b): Axial

Figure 5-34. Gaterotor Bearing Clearance

Gaterotor Inspection

A) Gaterotor - Main Housing Shelf Clearance

Follow these steps to check the clearance between the gaterotor and the shelf, which should be between 0.003" – 0.004", see Figure 5-35.

1. Place a 0.003" feeler gauge between the gaterotor teeth, as shown in Figure 5-36 (a) and 5-36 (b).

NOTE

Make sure the feeler gauge stays in the opening between the two teeth until it is on top of the shelf.

2. Without moving the feeler gauge, slowly rotate the gaterotor so that the feeler gauge tip stays between the gaterotor and the shelf. See Figure 5-36 (c).

CAUTION

Do not over rotate. If the rotor catches the feeler gauge, a piece can break and fall into the rotor

3. Gently pull the feeler gauge out in the direction shown in Figure 5-36 (d).

Check for 0.003-0.004" (0.076- 0.102 mm) clearance between gaterotor blade and shelf.






Figure 5-35. Gaterotor and Shelf Clearance


(a) Feeler Gauge Placement (Side View)



(b) Feeler Gauge Placement (Top View)



(c) Tip Of The Feeler Gauge Stays Between Gaterotor and Shelf While Rotating



(d) Feeler Gauge Must Be Pulled Out In This Direction




Figure 5-36. Gaterotor and Shelf Clearance Measurement Steps

Section 5 • Maintenance/Service

- If it is easy to pull out the feeler gauge, then increase the feeler gauge thickness by 0.001" and repeat above steps 1-3. If it is slightly tight to pull it out, then the clearance corresponds to the feeler gauge thickness.

NOTE

Replacement gaterotors are the same dimensionally as the gaterotors installed at the factory. Therefore, the same shims can be reused when replacement is needed to preserve the 0.003" – 0.004" clearance.

Clearance and Shims

Under 0.003"	0.003" – 0.004"	Over 0.004"
Remove shims (103 in Figure 5-55, 106 in Figure 5-48) to achieve 0.003" – 0.004"	Perfect!	Add shims (103 in Figure 5-55, 106 in Figure 5-48) to achieve 0.003" – 0.004"

B) Gaterotor Float Measurement

- Before doing any measurements, first conduct a visual check to see if there is any noticeable clearance between the gaterotor and its bushing, see Figure 5-37. If there is noticeable clearance, please contact Vilter Service Department.

NOTE

The number of bushings on a gaterotor can be anywhere from one to three.

- To measure the float between the gaterotor bushing and the support damper pin (see Figure 5-39), position a dial indicator at the tip of the support as shown in Figure 5-38. Hold the gaterotor in place, then gently move the support teeth back and forth with two fingers (and record measurement). Refer to Table 5-15 to find the maximum float value.

NOTICE

If clearance measurements are out of tolerance, contact Vilter Service Department for further assistance.

Table 5-15. Gaterotor Float

VSCC Model	Float in. (mm)
128, 145, 160, 180, 204, 222, 243	0.065 (1.651)
291 - 601	0.045 (1.143)




Figure 5-37. Visual Inspection Between Gaterotor and Bushing




Figure 5-38. Gaterotor Float Dial Location





Figure 5-39. Gaterotor Float

C) Gaterotor Backlash Inspection

Gaterotor Backlash is the clearance between the gaterotor teeth width and the main rotor groove.

Follow these steps to perform the gaterotor backlash inspection:

1. The Gaterotor should be aligned so that a tooth in the rotor is perpendicular to the Main Axis as shown in Figure 5-40. The tooth should be in the center axis of the housing.
2. A dial indicator with magnetic base can be used (Vilter part numbers 9994ARE or 9994ARJ for the dial indicator, and 9994ARD for the magnetic base). See Figure 5-41 for location.



Inside Tooth is Perpendicular to the Rotor

Figure 5-40. Alignment of Gaterotor




Figure 5-41. Location of Dial Indicator Magnetic Base

Section 5 • Maintenance/Service

- 3. Place the Dial Indicator as square as possible on the Gaterotor tooth as shown on Figure 5-42.




Figure 5-42. Placement of Dial Indicator

- 4. To measure the backlash (see Figure 5-43), move the gaterotor with two fingers back and forth rapidly several times while reading the dial indicator to see what the displacement range is. This displacement range will be the total backlash.

Contact Vilter Service Department if the measurement is above the ranges shown on Table 5-16.

Table 5-16. Backlash Range

Compressor Model	Normal Backlash
VSCC 128 thru 243	Up to 0.012" (Up to 0.305 mm)
VSCC 291 thru 601	0.008" to 0.012" (0.203 to 0.305 mm)

Fingers Positioning to Move the Gaterotor Back and Forth




Figure 5-43. Measuring Backlash

Important Notes

1. Backlash cannot be checked if:

- The gaterotor is damaged in any way.
- The clearance between the gaterotor and the shelf is too tight.

2. Make sure you check the backlash, not the float:

- The backlash is the clearance between the gaterotor teeth width and the rotor groove.
- The float is the amount of play between the gaterotor bushing and the damper pins.

Additional Inspections

In addition, visually inspect the main rotor and gaterotors for signs of abnormal wear due to dirt or other contaminants.

If some chipping is present on the edges of the gaterotor, this will not influence the compressor performance. If chipping is more than what's shown on Figure 5-44, take pictures and contact Vilter Service Department.

Post Inspection

After all the inspections are complete, the gaterotor cover, suction tee, coupling center member and coupling guard can be reinstalled and the unit can be evacuated and leak checked before starting.




Figure 5-44. Chipped Edge of Gaterotor

Gaterotor Assembly Replacement (For VSCC 291 - 601)

Table 5-17 lists the gaterotor tool sets needed to remove and install gaterotor assemblies.

Table 5-17. Gaterotor Tool Kits

Model	Tool Set VPN
VSCC 128-243	A25205G & A24061A
VSCC 291-601	A25205B

Removal

1. Remove center member, see appropriate Drive Coupling Replacement procedure.

NOTE

All parts must be kept with their appropriate side and not mixed when the compressor is reassembled.

2. Remove two upper bolts from side cover
3. Install guide studs in holes.

NOTE

There will be some oil drainage when the cover is removed.


4. Remove remaining bolts and side cover.
5. Turn main rotor so a driving edge of any one of the main rotor grooves is even with the back of the gaterotor support.

NOTE


The gaterotor stabilizer is designed to hold the gaterotor support in place and prevent damage to the gaterotor blade as the thrust bearings and housing is being removed.

Section 5 • Maintenance/Service

6. Insert gaterotor stabilizer. The side rails are not required on VSCC 291 thru 601. Refer to Figure 5-45.
7. Remove hex head bolts and socket head bolts from thrust bearing cover.
8. Re-install two bolts into the threaded jacking holes to assist in removing thrust bearing cover. Retain the shim pack.
9. Hold gaterotor support with a suitable wrench on the flats provided near the roller bearing housing.
10. Remove the inner retainer bolts and retainer.
11. To remove the thrust bearing housing, install thrust bearing removal and installation tool with smaller puller shoe. Turn the jacking screw clockwise. The thrust bearings and housing assembly will be pulled off the shaft and out of the frame.
12. Remove bolts from roller bearing housing.
13. Re-install two bolts into jack bolt holes provided in housing to aid in removal.
14. To remove the gaterotor support, carefully move support in the opposite direction of rotation and tilt roller bearing end towards the suction end of the compressor. The compressor input shaft may have to be turned to facilitate the removal of the gaterotor support. On dual gate compressor units, repeat the procedure for the remaining gaterotor support assembly.



For VSCC 291-601 compressors,
do not use side rails.



Position leading edge of main rotor groove flush
with or slightly below back of gaterotor support.





Figure 5-45. Gaterotor Assembly Removal
and Tools

Installation

15. Install gaterotor support by carefully tilting the roller bearing end of the gaterotor support towards the suction end of the compressor. The compressor input shaft may have to be rotated to facilitate the installation of the gaterotor support. Install gaterotor stabilizer. The gaterotor stabilizer (901) will hold the gaterotor support in place as the thrust bearing housing is being installed. If the gaterotor support is not restricted from moving, the gaterotor blade may be damaged. See Figure 5-46.
16. Install the roller bearing housing (112) with a new O-ring (141). See Figure 5-47.
17. Tighten bolts (152), see Table A-1 or Table A-2 in Appendix A.
18. When installing the thrust bearing housing (113), a new O-ring (142) must be used when the housing is installed, see Figure 5-47. Lubricate the outside of the housing and bearings with clean compressor oil to aid in the installation. Due to the fit of the bearings on the gaterotor shaft, the thrust bearing removal and installation tool with the pusher shoe must be used. Turn the jacking screw clockwise. This will push the thrust bearings onto the shaft and push the housing assembly into the frame. Install the inner retainer (115) and bolts (151) using Loctite® 242 thread locker. Tighten bolts, see Table A-1 or Table A-2 in Appendix A.
19. Set clearance between gaterotor blade and shelf.
20. Place a piece of 0.003"–0.004" shim stock between gaterotor blade and shelf.

NOTE

This measurement determines the amount of shims needed for the correct clearance.

21. Measure depth from top of compressor case to top of thrust bearing housing.
22. Use factory installed shim pack (106) and bearing housing cover (116) without the O-ring (143).

NOTE

Replacement blades are precisely the same dimensionally as blades installed originally at factory. Therefore, the same amount of shims will be required for replacement blades.




Figure 5-46. Gaterotor Assembly Removal




Figure 5-47. Gaterotor Assembly and Tools

23. Check the clearance between the entire gaterotor blade and the shelf, rotate the gaterotor to find the tightest spot. It should be between 0.003-0.004" (0.076-0.102 mm). Make adjustments, if necessary. It is preferable to shim the gaterotor blade looser rather than tighter against the shelf, see Figure 5-48.
24. After clearance has been set install a new O-ring (143) on bearing housing cover, install cover and tighten the bolts to the recommended torque value.
25. Install side cover with a new gasket. Tighten the bolts to the recommended torque value. The unit can then be evacuated and leak checked.

Check for 0.003"-0.004" (0.076mm- 0.102 mm) clearance between gaterotor blade and partition.





Figure 5-48. Gaterotor and Shelf Clearance

Gaterotor Removal and Installation (For VSCC 128 - 243)

Use Gaterotor Tool Set: A25205G and
A24061A

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

Removal

1. Prepare the compressor for servicing (please see Preparation of Unit for Servicing on Page 5-4 for procedure details). Use Tool Kit A24061A to remove suction tee. See Figure 5-50 for details.

NOTE

Each gaterotor assembly must be reassembled on the same side that it is disassembled from.

2. Position at least a one gallon plastic oil collection bin beneath the side cover. Carefully pry open the side cover to allow the oil to drain before finally removing the side cover.
3. Rotate the main rotor to the position indicated in Figure 5-49.




Figure 5-49. Rotor Position for Gaterotor/Support Assembly Removal




Figure 5-50. Gaterotor/Support Assembly Removal




Figure 5-51. Gaterotor Assembly

WARNING

Do not use this tooling to lift objects weighing more than 140 LBS




Figure 5-31. Tool (A24061A) To Handle Suction Tee Assembly

Section 5 • Maintenance/Service

Install the tool set as shown in Figure 5-52 by hand tightening the bolt (109) - this will hold the gaterotor support in place. Turn the jacking screw (105 in Figure 5-52) clockwise. The ball bearing housing assembly will be pulled off the gaterotor support. Remove entire tool set.

8. Remove O-ring (104-1 in Figure 5-51).
9. Make sure the rotor is in position as shown in Figure 5-49. Remove support assembly (101 in Figure 5-51) as shown in Figure 5-48.

NOTE

O-rings and Nord-Lock washers (114 in Figure 5-51) will need to be replaced each time.

Note on Tool

Make sure that gaterotor is not in contact with the housing shelf while installing and removing the bearing housing assembly.




Figure 5-52. Tool To Remove Bearing Housing Assembly




Figure 5-53. Tool To Install and Remove Bearing Housing Assembly

Section 5 • Maintenance/Service

Installation (Refer to Figure 5-49)

Torque values for screws:
- 110: 20 ft-lbs
- 112: 35 ft-lbs
- 113: 10 ft-lbs
- 111: 20 ft-lbs (use blue Loctite)

- The beveled side of the retaining ring (101.14) must face away from gaterotor, see Figure 5-56.
 - Make sure O-rings are placed in the proper grooves, see Figure 5-51.
 - Washer 114 has fine and coarse serrations, and those fine serrations must be facing out. See “NORD-LOCK Washers” on Page 5-69 for more details.
1. Install gaterotor support by carefully tilting the roller bearing end of the gaterotor support towards the suction end of the compressor, see Figure 5-49. The compressor input shaft may have to be rotated to facilitate the installation of the gaterotor support, see Figure 5-49.
 2. When installing the ball bearing housing (102), a new O-ring (104-1) must be used when the housing is installed, see Figure 5-51. Lubricate the outside of the housing and bearings with clean compressor oil to aid in the installation. Due to the way the bearings fit on the gaterotor support, the gaterotor tool set (A25205G) must be used. Assemble the tool set according to Figure 5-54 and 5-49 by hand tightening the bolt (109) - this will hold the gaterotor support in place. Evenly turn the jacking studs (102) clockwise. This will push the ball bearing housing onto the gaterotor support. Remove entire tool set.
 3. Install the inner retainer (109), washers (114) and bolts (111) using Loctite® 242 thread locker. Tighten bolts to 20 ft-lbs.
 4. Install the roller bearing housing (105) with a new O-ring (104-3).
 5. Tighten bolts (110) to 20 ft-lbs.
 6. Set clearance between gaterotor blade and shelf.
 7. Place a piece of 0.003”-0.004” shim stock between gaterotor blade and shelf.

NOTE

This measurement determines the number of shims needed for the correct clearance.

8. Measure depth from top of compressor case to top of ball bearing housing.

9. Use factory installed shim pack (103) and ball bearing housing cover (106) without the O-ring (104-2).

NOTE

Replacement blades are precisely the same dimensionally as blades installed originally at factory. Therefore, the same number of shims will be required for replacement blades.

Note on Tool

Make sure that gaterotor is not in contact with the housing shelf while installing and removing the bearing housing assembly.




Figure 5-54. Tool To Install Bearing Housing Assembly

Section 5 • Maintenance/Service

10. Check the clearance between the entire gaterotor blade and the shelf, rotate the gaterotor to find the tightest spot. It should be between 0.003-0.004" (0.076-0.102mm). Make adjustments, if necessary. It is preferable to shim the gaterotor blade looser rather than tighter against the shelf, see Figure 5-55.
11. After clearance has been set install a new O-ring (104-2) on ball bearing housing cover, install cover (106), and tighten the bolts (112 and 113) to the recommended torque values.
12. Install side cover with a new gasket. Tighten the bolts to the recommended torque value. The unit can then be evacuated, and leak checked.

Torque values for screws:
- 110: 20 ft-lbs
- 112: 35 ft-lbs
- 113: 10 ft-lbs
- 111: 20 ft-lbs (use blue Loctite)




Figure 5-55. Check the Clearance Between the Gaterotor and Shelf

Gaterotor Disassembly (For VSCC 128 - 243)

Gaterotor Blade Removal

1. Remove the retaining ring (101.14) and washer (101.13) from the assembly, see Figure 5-55.
2. Lift gaterotor blade assembly (101.12) off the gaterotor support (101.11).
3. Check damper pin and bushing for excessive wear. Replace if required (see Page 5-41 for gaterotor float details).

Gaterotor Blade Installation

1. Install bushings (101.12b) in gaterotor blade (101.12a) from the back side of the blade. Be sure bushing is fully seated and torqued to 5 ft-lbs. using red Loctite (271), see Figure 5-57.
2. Place blade assembly (101.12) on gaterotor support (101.11). Locate bushing over pin, see Figure 5-56.
3. After the gaterotor and support are assembled, there should be a small amount of rotational movement between the gaterotor and support.
4. Install washer (101.13) and retaining ring (101.14).

NOTE

Retaining ring (101.14) must be installed with bevel side facing away from the gaterotor, see Figure 5-56.




Figure 5-56. Gaterotor and Support Assembly




Figure 5-57. Gaterotor Top Face Identification

Gaterotor Ball Bearing Removal

1. Remove bolts (102.4) from the outer retainer (102.3), see Figure 5-58.
2. Remove ball bearing outer retainer (102.3).
3. Using a press, remove ball bearings (102.2) from housing (102.1).

Gaterotor Ball Bearing Installation

1. Install three ball bearings (102.2) in the housing (102.1) so the first two bearings are back to back, and the second and third bearings are face to face (the larger sides of the inner races are placed together, as shown in Figure 5-58. A light application of clean compressor lubricating oil should be used to ease the installation of the bearings into the housing.
2. Center the bearing outer retainer (102.3) on housing (102.1), use Loctite® 242-thread locker and evenly tighten the bolts (102.4) to the recommended torque value (4 lb-ft), see Figure 5-58.




Figure 5-58. Gaterotor Ball Bearing

Gaterotor Roller Bearing Removal

1. Remove the snap ring (107), which retains the roller bearing in the bearing housing, see Figure 5-59.
2. Remove the baffle washer (108) and the roller bearing (101.3b) from the bearing housing (105).
3. Remove the retaining ring (101.2) from the gaterotor support (101.1). Use a bearing puller to remove the roller bearing inner race (101.3a) from the gaterotor support (101.1).

Gaterotor Roller Bearing Installation

1. Match up the part numbers on the inner race and outer race of the bearing (101.3a & 101.3b).
2. Install the outer race (101.3b) into the bearing housing (105). Install baffle washer (108) with inner bevel facing the bearing rollers (101.3b). Install the snap ring retainer (107) in the housing. The bevel on the snap ring must face away from the roller bearing.
3. Heat Roller bearing inner race (101.3a) to 250°F, then quickly install on gaterotor support (101.1). Once cool, install retaining ring (101.2).




Figure 5-59. Gaterotor Roller Bearing Assembly

Gaterotor Disassembly (For VSCC 291 - 601)

1. To perform gaterotor disassembly, remove gaterotor from compressor, see Gaterotor Assembly Replacement procedure.

Gaterotor Blade Removal

2. Remove the snap ring and washer from the gaterotor assembly. Lift gaterotor blade assembly off the gaterotor support, see Figure 5-60.
3. Check damper pin and bushing for excessive wear. Replace if required.






Figure 5-60. Gaterotor Blade Assembly

Gaterotor Blade Installation

4. Install damper pin bushing (120) in gaterotor blade (111) from the back side of the blade. Be sure bushing is fully seated.
5. Place blade assembly on gaterotor support. Locating damper over pin.
6. Install washer (119) and snap ring (130) on gaterotor assembly. The bevel on the snap ring must face away from the gaterotor blade. After the gaterotor blade and support are assembled, there should be a small amount of rotational movement between the gaterotor and support.



Snap ring bevel must be positioned away from the blade on gaterotor.




Figure 5-61. Gaterotor Blade Installation

Gaterotor Thrust Bearing Removal

See Figure 5-63

7. Remove retaining ring from gaterotor support.
8. Remove bearings from support.
9. Remove bearing retainer from inner race.




Figure 5-62. Gaterotor Thrust Bearing

Gaterotor Thrust Bearing Installation

10. Install thrust bearings (126) in the housing so the bearings are face to face. The larger sides of the inner races are placed together. A light application of clean compressor lubricating oil should be used to ease the installation of the bearings into the housing.
11. Center the bearing retainer ring on housing, use Loctite® 242-thread locker and evenly tighten the bolts to the recommended torque value, see Figure 5-63.




Figure 5-63. Thrust Bearing Installation

Compressor Shaft Seal Replacement

Shaft Seal Assembly

The shaft seal is made up of a mating ring and a carbon or silicon carbide (SC) component.

The mating ring is the rotating part of the seal and is installed against the shaft shoulder. It has a drive notch on one end which aligns with the drive pin inserted in the shaft.

Carbon or SC component is the stationary part of the seal and is installed into the shaft seal housing using an O-ring.

The shaft seal housing with the stationary part is assembled in the compressor main housing using an O-ring, see Figure 5-64.

The shaft seal needs to be carefully handled and installed to function properly. Please see Figure 5-65 for details.




Figure 5-64. Shaft Seal Assembly

Handling Seal Face with Care

- Avoid touching seal faces as much as possible during installation.
- Be sure to always keep seal faces face-up, rather than face-down, see image on the right.



Figure 5-65. Handling Seal Face with Care

Section 5 • Maintenance/Service

Compressor Shaft Seal Replacement

Shaft Seal Removal

(See Table 5-18 and Figure 5-66)

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

NOTE

There will be a small amount of oil drainage as the shaft seal housing is removed.

1. Remove bolts (281) securing shaft seal housing (218) to compressor.
2. Insert two bolts (281) into threaded jacking holes to assist in removing shaft seal housing (218).
3. Remove silicon carbide rotating face (219.6) & O-ring (219.7) from shaft.
4. Remove spring holder (219.8) from shaft.
5. Remove oil seal (230) from shaft seal housing (218).
6. Remove retaining ring (219.5) from seal housing.
7. Flip the seal housing over and carefully tap the stationary silicon carbide piece (219.3), retainer (219.4), and O-ring (219.2) out of the seal housing using brass drift and hammer.
8. Remove O-ring (260).

NOTE

VSCC compressors are designed using some of the following shaft seals, see Table 5-18 for their VPN and pressure ranges.

Table 5-18. Some of the Shaft Seals

Shaft Seal	Pressure (PSI)		O-ring Material
	Static	Dynamic	
25985Y	1800	1350	Fluoroelastomer
25985YA	1800	1350	EPDM
25985YF	1800	1350	FFKM




Figure 5-66. Shaft Seal Breakdown (25985Y, 25985YA, and 25985YF)

Section 5 • Maintenance/Service

Prior to Shaft Seal Installation

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

NOTE

Care must be taken when handling the cup assembly and mating ring when installing. See Figure 5-65 for Handling Seal Face with Care.

Suggestion

A spray bottle filled with clean compressor oil may be used to lubricate the faces of the seals without touching the seal.

Follow these steps to verify the integrity of a shaft seal:

1. Check lead chamfer and outer diameter of shaft for deep scratches that may potentially damage the O-ring on the inner diameter of the shaft seal, see Figure 5-67.
2. Check lead chamfer and inner diameter of shaft seal housing for burrs and/or deep scratches that may potentially damage the O-ring on the outer diameter of the shaft seal, see Figure 5-68.
3. Clean compressor shaft and shaft seal cavity in compressor housing.
4. Apply clean compressor lubricating oil to the compressor shaft in mating ring seating area, see Figure 5-69.

NOTE

Once these steps have been performed, the installation procedure will depend on the shaft seal model of the compressor, so check the section relevant to yours.




Figure 5-67. Shaft with Pin




Figure 5-68. Shaft Seal Housing




Figure 5-69. The Alignment of Compressor Shaft and Mating Ring

Shaft Seal Installation

(See Table 5-18 and Figure 5-66)

NOTE

Follow the “Prior to Shaft Seal Installation” steps before starting this procedure.

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

NOTE

Care must be taken when handling the cup assembly and mating ring when installing. See Figure 5-65 for Handling Seal Face with Care.

Suggestion

A spray bottle filled with clean compressor oil may be used to lubricate the faces of the seals without touching the seal.

CAUTION

Do not wipe or touch the face of the mating ring (219C) where the face meets the carbon component of the stationary assembly (219B).

1. Apply clean compressor lubricating oil to inside area of spring holder (219.8), rotating Silicon carbide piece (219.6) and O-ring (219.7).
2. Carefully fit spring holder (219.8) onto shaft until it is fully seated against shoulder on compressor shaft. Be sure to align slot in spring holder (219.8) with drive pin on compressor shaft, see Figure 5-69.

- ### CAUTION
- Ensure the spring holder (219.8) is fully seated against the shoulder of the compressor shaft. If the spring holder (219.8) is not fully seated against the shoulder, the carbon component of the stationary assembly (219B) will be damaged when the shaft seal housing (218) is installed.
3. Place O-ring (219.7) inside rotating silicon carbide piece (219.6) and carefully assemble onto shaft. You should feel some resistance in sliding this onto the shaft shoulder.
 4. Install a new oil seal (230) in seal housing (218).
 5. If necessary, Install anti-rotation pin (219.1a) in hole in shaft seal housing (218).
 6. Install O-ring (219.2) into shaft seal housing.
 7. Install stationary silicon carbide piece (219.3) in shaft seal housing with anti-rotation pin (219.1b) aligned 180 degrees away from the pin (219.1a) in Step 4. You should feel some resistance to fit the stationary piece into the O-ring.
 8. Fit the retainer (219.4) over the stationary piece while aligning the slots on the anti-rotation pins.
 9. Install retaining ring (219.5) into groove in shaft seal housing.
 10. Install a new O-ring (260) on the seal housing (218), making sure the O-ring is placed in the O-ring groove and not the oil gallery groove. Lubricate both seal faces with clean compressor lubricating oil.
 11. Carefully install the seal housing (218) on the compressor shaft, evenly tightening the bolts (281) to the recommended torque values (36 ft-lbs).
 12. Install the coupling and coupling guard. The unit can then be evacuated and leak checked.




Figure 5-66. Shaft Seal Breakdown (25985Y, 25985YA, and 25985YF)

Slide Valve Actuator Assembly Replacement

To replace slide valve actuator assembly, proceed with the following steps:

Removal

WARNING

At shutdown, open any other valves that may trap liquids to prevent serious injury and/or damage to equipment.

WARNING

Follow local lock-out/tag-out procedure. Compressors must be depressurized before attempting to do any work on them. Failure to comply may result in serious injury, death and/or damage to equipment.

NOTE

This procedure is applicable to both capacity and volume slide valve actuator assemblies. See Figure 5-71.

1. Shut down the compressor unit, refer to Stopping/Restarting procedure in Section 4.
2. Turn disconnect switches to the OFF position for the compressor unit and oil pump motor starter, if equipped.
3. Allow compressor, motor and surrounding components to cool prior to servicing.
4. Disconnect connectors from actuator.

NOTE

Note orientation of components to aid in installation.

5. First remove E-clips, then remove Locking Retainers, next loosen and remove Grooved Bolts and Washes that securing actuator assembly to actuator mount. See Figure 5-71 for parts details.
6. Remove actuator assembly from actuator mount.

Installation

CAUTION

When installing the slide valve actuator assembly, loosen locking collar down the shaft. Do not use a screwdriver to pry locking collar into position.

7. Position actuator assembly on mount as noted in removal.
8. Install washers and grooved bolts to secure actuator assembly to actuator mount, torque them to 6 lb-ft. Then install locking retainers. Last push E-clips into grooved bolt heads. Refer to Actuator Installation Using Anti-Rotation Bolts (see next page) for details.
9. Tighten screws, see Table A-1 or Table A-2 in Appendix A.

CAUTION

If installing new actuator, do not connect connectors of power cable or position transmitter cable to new actuator once installed. Connecting connectors to new actuator will occur during calibration procedure. Failure to comply may result in damage to equipment.

10. Leave connectors disconnected to actuator assembly.
11. Calibrate actuator assembly, see Slide Valve Calibration procedure in Section 4 or Appendix F.




Figure 5-70. Mounting for Command Shaft D Style

Section 5 • Maintenance/Service

Actuator Installation Using Anti-Rotation Bolts


Tools Needed: A 7/16" open wrench or torque wrench with 7/16" crowfoot wrench adapter.

Part #: The parts come with the actuator. Retrofit kit # is 25972R (Includes 4 sets of bolts, washers, retainers & E-clips).

1. Install the Grooved Bolt and Washer and torque them to 6 lb-ft. See Figure 5-71 (a).

NOTE

It may be necessary to adjust the bolt position so that one of the bolt edges is parallel to line A and B, then the retainer will drop-on easily. If required, tighten bolt further for this alignment.



2. Position Locking Retainer over Grooved Bolt, with the shallow curved edge toward the center of the command shaft housing. See Figure 5-71 (b).

NOTE

The locking retainer hex hole is offset 3° so flipping it over gives it new positioning.



3. Push E-Clip into Grooved Bolt Head. Once E-clip is on make sure it rotates back and forth freely. This will ensure E-Clip is completely seated. See Figure 5-71 (c).






Figure 5-71. Actuator Installation Using Anti-Rotation Bolts


Slide Valve Command Shaft Assembly Replacement

Removal

NOTE

The following steps can be used to remove or install either the capacity or volume command shaft assemblies.

1. Shut down and isolate compressor unit, see Compressor Unit Shutdown and Isolation procedure.
2. Remove actuator, see Actuator Assembly Replacement procedure.
3. Remove four socket head cap screws (457) and Nord-Lock washers (477) securing the command shaft assembly to the discharge manifold.
4. The command shaft and mounting plate may now be removed from the compressor.



Installation

5. Install a new O-ring (446) into the groove on the compressor discharge manifold. You may use clean compressor lubricating oil on the O-ring.
6. Install the command shaft onto the compressor discharge manifold. Ensure that the command shaft tongue is engaged in the cross-shaft slot inside the compressor discharge manifold. Rotate the command shaft assembly so that the vent holes point downward. This will prevent water and dust from entering the vent.
7. Secure the command shaft assembly to the discharge manifold using the four socket head cap screws and Nord-Lock washers and apply the proper torque.
8. Perform leak check, see Compressor Unit Leak Check procedure.




Figure 5-72. Command Shaft Assembly Replacement

Liquid Injection Control Valve Station (Danfoss ICF 20-40 Valve Station)

For liquid injection control operation, refer to . For additional information regarding setup, installation, programming and troubleshooting, refer to Appendices.

The liquid injection control valve station (ICF) consists of these parts (Danfoss part acronyms are shown in parentheses):

- Shut-off Valves (ICFS), Inlet and Outlet
- Solenoid Valve (ICFE) with Manual Stem (ICFO)
- Motorized Valve Assembly (ICM valve assembly with ICAD motor actuator)
- Strainer (ICFF) with Drain Valve

For parts and service kits, refer to Tables 5-19 and 5-20.




Figure 5-73. Danfoss ICF 20-40 Valve Station (Liquid Injection Control)

Table 5-19. Coils for Solenoid Valves (ICFE)

VILTER™ PART NO	VOLTAGE	Hz	HOLDING	CONNECTION	PILOT LIGHT
3389DA	110-120VAC	60	14W	DIN	
3389DB	110-120VAC	60	14W	DIN	GREEN
3389DC	110VAC	60	12W	TERMINAL BOX	GREEN
3389DD	220VAC	60	12W	TERMINAL BOX	GREEN
3389DD1	220VAC W/110VAC LED BOX	60	12W	-	LED

Table 5-20. Parts for Motorized Valve Station (ICF)

VILTER™ PART NO	DESCRIPTION
3389EA	ICAD 600 MOTOR ACTUATOR W/10M CABLES
3389EE	ICAD 900 MOTOR ACTUATOR W/10M CABLES
3389AE1	CABLES, 10M FOR ICAD ACTUATOR
3389AE2	TOP COVER FOR ICAD ACTUATOR
3389EB	CONTROLLER EKC 347, LIQUID LEVEL
3389FD	MODULE B66 FUNCTION (FOR ICF VALVE STATION)
3389FA	MAGNETIC TOOL FOR ICM VALVE MANUAL OPERATION 20,25, AND 32
3389FC	MAGNETIC TOOL FOR ICM VALVE MANUAL OPERATION 40, 50, AND 65
3389FB	ICM 20 SERVICE KIT (VALVE SEAT)
3389FE	ICM 25 SERVICE KIT (VALVE SEAT)
3389FF	ICM 32 SERVICE KIT (VALVE SEAT)






Main Rotor Assembly

Due to the procedures and tools involved in the disassembly and reassembly, the main rotor assembly must be performed by qualified individuals. Please consult the factory if maintenance is required.

Torque Specifications

Refer to the following table for torque specifications.

Table 5-21. Torque Specifications (ft-lbs) (For Compressors Only)

TYPE BOLT	HEAD MARKINGS	NOMINAL SIZE NUMBERS OR INCHES									
		#10	1/4"	5/16"	3/8"	7/16"	1/2"	9/16"	5/8"	3/4"	7/8"
SAE GRADE 2 COARSE (UNC)			5	10	18	29	44	63	87	155	150*
SAE GRADE 2 COARSE (UNC)			8	16	28	44	68	98	135	240	387
SAE GRADE 5 FINE (UNF)				16							
SAE GRADE 2 COARSE (UNC)			11	22	39	63	96	138	191	338	546
SOCKET HEAD CAP SCREW (ASTM A574) COARSE (UNC)		5	13	26	46	73	112	155	215	380	614
Notes:	1) Torque values on this sheet are not to override those given on the individual drawings.										
	2) When using loctite, the torque value on this sheet are only accurate if bolts are tightened immediately after loctite is applied.										
	* The proof of strength of Grade 2 bolts is less for sizes 7/8 and above and therefore the torque values are less than smaller sizes of the same grade.										

**Table 5-22. SA193 B7/SA320 L7 Bolts / Studs – Torque Requirements
Per ASME Codes: B31.5 and B31.3**

Nominal Bolting Diameter	Nominal Torque (ft.lbs.)	Maximum Torque (ft.lbs.)	Torque (ft.lbs) Using Flexitallic Gasket
3/8"	17	20	25
7/16"	19	22	28
1/2"	20	25	30
5/8"	40	50	60
3/4"	65	83	100
7/8"	100	133	160
1"	120	204	245
1-1/4"	150	454	500

Notes:

1. The above torque values apply unless otherwise specified on drawing.
2. Bolting to be tightened incrementally in a diametrically staggered pattern to the nominal torque value.
3. If necessary, torque can be increased in 10% increments; do not exceed the maximum torque values.
4. For other materials please consult Vilter Engineering Department for torque values.


Using A Torque Wrench Correctly



Torque Wrenches

USING A TORQUE WRENCH CORRECTLY INVOLVES FOUR PRIMARY CONCERNS:

- A. A smooth even pull to the break point is required. Jerking the wrench can cause the pivot point to break early leaving the bolt at a torque value lower than required. Not stopping when the break point is reached results in an over torque condition.
- B. When more than one bolt holds two surfaces together there is normally a sequence that should be used to bring the surfaces together in an even manner. Generally bolting is tightened incrementally in a diametrically staggered pattern. Some maintenance manuals specify a tightening scheme. If so, the manual scheme shall be followed. Just starting on one side and tightening in a circle can cause the part to warp, crack, or leak.
- C. In some cases threads are required to be lubricated prior to tightening the bolt/nut. Whether a lubricant is used or not has considerable impact on the amount of torque required to achieve the proper preload in the bolt/stud. Use a lubricant, if required, or not if so specified.
- D. Unlike a ratchet wrench a torque wrench is a calibrated instrument that requires care. Recalibration is required periodically to maintain accuracy. If you need to remove a bolt/nut do not use the torque wrench. The clockwise/counterclockwise switch is for tightening right hand or left hand threads not for loosening a fastener. Store the torque wrench in a location where it will not be bumped around.



Nord-Lock® Washers

- A. The Nord-Lock® lock washer sets are used in many areas in the single screw compressors that require a vibration proof lock washer.
- B. The lock washer set is assembled so the coarse serrations that resemble ramps are mated together.
- C. Once the lock washer set is tightened down, it takes more force to loosen the bolt than it did to tighten it. This is caused by the washers riding up the opposing ramps.

Slide Valve Actuator Troubleshooting Guide

Table 6-1. Slide Valve Actuator Troubleshooting Guide (1 of 3)

Problem	Reason	Solution
The actuator cannot be calibrated.	Dirt or debris is blocking one or both optocoupler slots.	Clean the optocoupler slots with a cotton swab and rubbing alcohol.
	The photo-chopper fence extends less than about half way into the optocoupler slots.	Adjust the photo-chopper so that the fence extends further into the optocoupler slots. Make sure the motor brake operates freely and the photo-chopper will not contact the optocouplers when the shaft is pressed down.
	The white calibrate wire in the grey Turck cable is grounded.	Tape the end of the white wire in the panel and make sure that it cannot touch metal.
	Dirt and/or condensation on the position sensor boards are causing it to malfunction.	Clean the boards with an electronics cleaner or compressed air.
	The calibrate button is stuck down.	Try to free the stuck button.
	The position sensor has failed.	Replace the actuator.
	Push button is being held down for more than $\frac{3}{4}$ second when going through the calibration procedure.	Depress the button quickly and then let go. Each $\frac{3}{4}$ second the button is held down counts as another press.
The actuator goes into calibration mode spontaneously.	The white calibrate wire in the grey Turck cable is grounding intermittently.	Tape the end of the white wire in the panel and make sure that it cannot touch metal.
	A very strong source of electromagnetic interference (EMI), such as a contactor, is in the vicinity of the actuator or grey cable.	Increase the distance between the EMI source and the actuator. Install additional metal shielding material between the EMI source and the actuator or cable.
	There is an intermittent failure of the position sensor	Replace the actuator.

Table 6-1. Slide Valve Actuator Troubleshooting Guide (2 of 3)

Problem	Reason	Solution
The actuator goes into calibration mode every time power is restored after a power loss	The motor brake is not working properly.	Get the motor brake to where it operates freely and recalibrate.
	The position sensor's EEPROM memory has failed	Replace the actuator.
The actuator does not transmit the correct position after a power loss.	The motor was manually moved while the position sensor was not powered.	Recalibrate.
	The motor brake is not working properly.	Get the motor brake to where it operates freely and recalibrate.
	The position sensor's EEPROM memory has failed	Replace the actuator.
There is a rapid clicking noise when the motor is operating.	The photo-chopper is misaligned with the slotted optocouplers.	Try to realign or replace the actuator.
	The photo-chopper is positioned too low on the motor shaft.	Adjust the photo-chopper so that the fence extends further into the optocoupler slots.
	A motor bearing has failed	Replace the actuator.
The motor operates in one direction only	There is a loose connection in the screw terminal blocks.	Tighten
	There is a loose or dirty connection in the yellow Turck cable.	Clean and tighten
	The position sensor has failed.	Replace the actuator.
	There is a broken motor lead or winding	Replace the actuator.

Table 6-1. Slide Valve Actuator Troubleshooting Guide (3 of 3)

Problem	Reason	Solution
The motor will not move in either direction	The thermal switch has tripped because the motor is overheated	The motor will resume operation when it cools. This could be caused by a malfunctioning control panel. Consult the factory.
	Any of the reasons listed in “The motor operates in one direction only”	See above.
	The command shaft is jammed.	Free the command shaft.
	Broken gears in the gear-motor.	Replace the actuator.
	Blown relays or fuses.	Check and replace blown relays and/or fuse
The motor operates intermittently, several minutes on, several minutes off.	Motor is overheating and the thermal switch is tripping.	This could be caused by a malfunctioning control panel. Consult the factory.
The motor runs sporadically	Bad thermal switch.	Replace the actuator.
	Any of the reasons listed in “The motor operates in one direction only”	See above.
The motor runs but output shaft will not turn.	Stripped gears inside the gear rotor, or the armature has come unpressed from the armature shaft.	Replace the actuator.

Section 6 • Troubleshooting

Slide Valve Actuator LED Blink Codes

Slide Valve Actuators communicate problems discovered by internal diagnostics via LED blink codes. Only one blink code is displayed, even though it is possible that more than one problem has been detected.

Table 6-2. Slide Valve Actuator LED Blink Codes⁽¹⁾ (1 of 2)

Flash Pattern * = ON - = OFF	Meaning
* _ * _ * _ * _ * _ * _ * _	Calibration Step 1.
* _ _ * _ _ * _ _ * _ _	Calibration Step 2.
* _ _ * _ _ _ _ _ _ _ _ _ _	<p>This indicates a zero span. This error can only occur during calibration. The typical cause is forgetting to move the actuator when setting the upper limit of the span. If this is the case, press the blue button to restart the calibration procedure. This error can also occur if either or both of the slotted optocouplers are not working. If this is the case, the slide valve actuator will have to be replaced.</p> <p>The operation of the slotted optocouplers can be tested as follows:</p> <ol style="list-style-type: none"> 1. Manually rotate the motor shaft until the aluminum photo-chopper fence is not blocking either of the optocoupler slots. 2. Using a digital multimeter, measure the DC voltage between terminal 3 of the small terminal block and TP1 on the circuit board.⁽¹⁾ 3. The measurement should be between 0.1 and 0.2 Volts. 4. Next, measure the DC voltage between terminal 3 and TP2 on the circuit board. You should measure between 0.1 and 0.2 Volts.
* _ _ _ _ _ _ _ _ _ _	<p>This error means that the slide valve actuator is no longer transmitting accurate position information. The actuator should be recalibrated as soon as possible, after the cause of the over-speed is identified and corrected. This error will not clear until the actuator is re-calibrated.</p> <p>This code can be caused by:</p> <ol style="list-style-type: none"> 1. The motor speed exceeding the position sensor's ability to measure it at some time during operation. A non-functioning motor brake is usually to blame. 2. The actuator is being operated where strong infrared light can falsely trigger the slotted optocouplers, such as direct sunlight. Shade the actuator when the cover is off for service and calibration. Do not operate the actuator with the cover off.

(1) There are two versions of slide valve actuators, version A and B. Only version B is able to display LED blink codes. Slide valve actuator version B can be distinguished by only having a single circuit board as supposed to two circuit boards in version A.

(1) TP1 and TP2 are plated-thru holes located close to the slotted optocouplers on the board. They are clearly-marked on the board silkscreen legend.

Table 6-2. Slide Valve Actuator LED Blink Codes⁽¹⁾ (2 of 2)

Flash Pattern * = ON - = OFF	Meaning
* _ * _ * _ _ _ _ _ _ _ _ _ _	<p>The motor is overheated. The actuator motor will not run until it cools. Once the motor cools, the actuator will resume normal operation.</p> <p>Motor overheating is sometimes a problem in hot humid environments when process conditions demand that the slide valve actuators reposition often. Solutions are available; consult your Vilter™ authorized distributor for details.</p> <p>Another possible cause for this error is a stuck motor thermal switch. The thermal switch can be tested by measuring the DC voltage with a digital multimeter between the two TS1 wire pads.⁽²⁾ If the switch is closed (normal operation) you will measure 0 Volts.</p>
*****	<p>The 24V supply voltage is low. This will occur momentarily when the actuator is powered up and on power down.</p> <p>If the problem persists, measure the voltage using a digital multimeter between terminals 3 and 4 of the small terminal block. If the voltage is less than 24V, the problem is in the supply to the board. If the voltage is \geq 24V, replace the actuator.</p>
_*****	<p>The EEPROM data is bad. This is usually caused by loss of 24V power before the calibration procedure was completed. The actuator will not move while this error code is being displayed. To clear the error, calibrate the actuator. If this error has occurred and the cause was not loss of 24V power during calibration, possible causes are:</p> <ol style="list-style-type: none"> 1. The EEPROM memory in the micro-controller is bad. 2. The large blue capacitor is bad or has a cracked lead.
***** _ _ _ *	Micro-controller program failure. Please notify your Vilter™ authorized distributor.

(1) There are two versions of slide valve actuators, version A and B. Only version B is able to display LED blink codes. Slide valve actuator version B can be distinguished by only having a single circuit board as supposed to two circuit boards in version A.

(2) The TS1 wire pads are where the motor thermal switch leads solder into the circuit board. They are clearly marked on the board silkscreen legend and are oriented at a 45 degree angle.

Section 6 • Troubleshooting

Troubleshooting Guide - General Problems and Solutions with Oil Pump

Table 6-3. Troubleshooting Guide - General Problems and Solutions with Oil Pump (1 of 3)

Problem	Solution
Low Oil Pressure at Start	<ul style="list-style-type: none"> • After failing to start compressor with “Prelube Oil Pump Inhibit”, first allow Discharge pressure, Oil Filter In pressure and Out pressure to equalize. Then restart compressor. If compressor fails to start due to low oil pressure, continue troubleshooting with items below. • Reset Prelube Oil Pressure Setpoint in Alarms and Trip Setpoints screen to lowest recommended setpoints. • Check calibration of oil manifold transducer, discharge pressure transducer, and suction transducer. • Check for correct oil pump motor rotation and operation. • Ensure transducer isolation valves are open. • Verify that the correct transducer ranges are selected. • Check to see all oil line valves are open except the oil dump valve used to fill the lines and oil cooler. • Check oil strainer for dirt. • Check oil filter pressure drop. • Check “Prelube Oil Pressure Safety Changeover” setpoint is sufficient in Timers Screen. <ul style="list-style-type: none"> • Prelube Oil Pressure is Manifold Pressure minus Discharge Pressure.
Low Run Oil Pressure	<ul style="list-style-type: none"> • Check solutions in “Low Oil Pressure at Start”. • Check that there is proper discharge pressure ratio to create differential pressure, otherwise oil pressure can’t be maintained. Oil pressure is manifold oil pressure minus the suction pressure. It is a net pressure.
Oil flow or oil pressure problems	<ul style="list-style-type: none"> • Clean oil strainer screen. • Change oil filter, maybe plugged or collapsed. • Oil pump gears worn internally, excessive end-clearance. • Oil priming valve used on air-cooled cooler units is open. • Relief in-line check valve stuck open. • Pressure ratio too low, oil pump should be on.
Faulty pressure or temperature readings	<ul style="list-style-type: none"> • Check that the correct pressure or temperature range is selected in the Instrument Calibration menu. • Check cable connections at device, terminal strips, and PLC input card for correct wiring and shielding (RF noise). • Check calibration of RTDs and transducers.

Table 6-3. Troubleshooting Guide - General Problems and Solutions with Oil Pump (2 of 3)

Problem	Solution
Oil Loss Issues	<ul style="list-style-type: none"> Oil return line from coalescing side of oil separator to suction is closed, not open enough (3/4 turns should be sufficient), or plugged with debris. The check valve in the oil return line could be stuck closed or the flow is in the wrong direction. There may be water in the oil affecting the coalescing elements. Coalescent elements in need of replacement due to age or damage (water contamination). The operating conditions are not correct (too high of suction and/or too low discharge pressure). This creates increased gas flow which could make the oil separator too small. The suction or discharge check valve is not working correctly causing oil to escape when the unit stops. Viscosity of oil incorrect; send sample for testing. There is an oil leak somewhere in the system.
High oil temperature (Liquid injection)	<ul style="list-style-type: none"> Check for correct setting of all manual values. Check for correct operation of 3-way oil mixing valve. If you are controlling a step type oil cooler or a VFD oil cooler, verify the correct one is selected in the Configuration Screen and the amount of steps are entered in the Remote Oil Cooler Control Screen. Check the oil cooler and associated piping to make sure it is full of oil before starting. Check the oil strainer for debris and clean if necessary. Verify that the volume slide actuator is functioning correctly and that the correct compressor size (type) is selected. Check that all fans are working. Check for correct fan rotation on the oil cooler. Check that your operating conditions are within the “As Sold” design conditions.
Capacity/Volume Slide Actuator Alarms/Trips/ Symptoms:	<ul style="list-style-type: none"> Calibration method not correct. Actuator or Gear motor not working, or off on overload. Slide valve carriage assembly out of position, slides binding. Cross-shaft gears, broken pins. Command shaft broken. Slide valve rack or rack shaft damaged. Check balance piston movement. Reference Slide Valve Actuator Troubleshooting Guide. Check I/O fusing.

Section 6 • Troubleshooting

Table 6-3. Troubleshooting Guide - General Problems and Solutions with Oil Pump (3 of 3)

Problem	Solution
High Amp Draw	<ul style="list-style-type: none">• Check calibration at full load.• Check CT ratio entered in Vission20/20.• Check slide valve calibration, especially volume slide.
Vibration	<ul style="list-style-type: none">• Check that unit is leveled and secured to mounting pad or floor.• Check supported pipes (i.e. suction and discharge pipe) and make sure they are adequately supported.• Check for loose bolts and nuts.• Check condition of compressor and motor (i.e. alignments).
Excessive Motor Backspin	<ul style="list-style-type: none">• If there is more than normal motor backspin at shutdown, check suction check valve for proper operation.

Section 6 • Troubleshooting

Troubleshooting Guide - General Problems and Solutions for Units Without Oil Pump

Refer to the following tables for Troubleshooting Guide - General Problems & Solutions for Units Without Oil Pump.

Table 6-4. Troubleshooting Guide - General Problems and Solutions for Units WITHOUT Oil Pump (1 of 2)

Problem	Solution
Low Oil Pressure at Start	<ul style="list-style-type: none">• Check calibration of oil manifold transducer, discharge pressure transducer, and suction transducer.• Ensure transducer isolation valves are open.• Verify that the correct transducer ranges are selected.• Check to see all oil line valves are open except the oil dump valve used to fill the lines and oil cooler.• Check oil filter pressure drop.
Low Run Oil Pressure	<ul style="list-style-type: none">• Check solutions in “Low Oil Pressure at Start”.• Check that there is proper discharge pressure ratio to create differential pressure, otherwise oil pressure can’t be maintained. Oil pressure is manifold oil pressure minus the suction pressure. It is a net pressure.
Oil flow or oil pressure problems	<ul style="list-style-type: none">• Change oil filter, maybe plugged or collapsed.
Faulty pressure or temperature readings	<ul style="list-style-type: none">• Check that the correct pressure or temperature range is selected in the Instrument Calibration menu.• Check cable connections at device, terminal strips, and controller’s input card for correct wiring and shielding (RF noise).• Check calibration of RTDs and transducers.
Oil Loss Issues	<ul style="list-style-type: none">• Oil return line from coalescing side of oil separator to suction is closed, not open enough (3/4 turns should be sufficient), or plugged with debris.• The check valve in the oil return line could be stuck closed or the flow is in the wrong direction.• There may be water in the oil affecting the coalescing elements.• Coalescent elements in need of replacement due to age or damage (water contamination).• The operating conditions are not correct (too high of suction and/or too low discharge pressure) This creates increased gas flow which could make the oil separator too small.• The suction or discharge check valve is not working correctly causing oil to escape when the unit stops.• Viscosity of oil incorrect; send sample for testing.• There is an oil leak somewhere in the system.

Section 6 • Troubleshooting

**Table 6-4. Troubleshooting Guide - General Problems and Solutions for Units
WITHOUT Oil Pump (2 of 2)**

Problem	Solution
High oil temperature (liquid injection)	<ul style="list-style-type: none"> • Check for correct setting of all manual values. • Check for correct operation of 3-way oil mixing valve. • If you are controlling a step type oil cooler or a VFD oil cooler, verify the correct one is selected in the Configuration Screen and the amount of steps are entered in the Remote Oil Cooler Control Screen. • Check the oil cooler and associated piping to make sure it is full of oil before starting. • Verify that the volume slide actuator is functioning correctly and that the correct compressor size (type) is selected. • Check that all fans are working. • Check for correct fan rotation on the oil cooler. • Check that your operating conditions are within the “As Sold” design conditions.
Capacity/Volume Slide Actuator Alarms/Trips/ Symptoms:	<ul style="list-style-type: none"> • Calibration method not correct. • Actuator or Gear motor not working, or off on overload. • Slide valve carriage assembly out of position, slides binding. • Cross-shaft gears, broken pins. • Command shaft broken. • Slide valve rack or rack shaft damaged. • Check balance piston movement. • Reference Slide Valve Actuator Troubleshooting Guide. • Check I/O fusing.
High Amp Draw	<ul style="list-style-type: none"> • Check calibration at full load. • Check CT ratio entered in Vission 20/20. • Check slide valve calibration, especially volume slide.
Vibration	<ul style="list-style-type: none"> • Check that unit is leveled and secured to mounting pad or floor. • Check supported pipes (i.e. suction and discharge pipe) and make sure they are adequately supported. • Check for loose bolts and nuts. • Check condition of compressor and motor (i.e. alignments)
Excessive Motor Backspin	<ul style="list-style-type: none"> • If there is more than normal motor backspin at shutdown, check suction check valve for proper operation.

Warranty Claim Processing

This section explains how the warranty claim is processed and to help clear any questions that may arise prior to contacting customer service. For additional warranty information, refer to the Terms and Conditions of your order. Vilter™ contact information can be found on Page iii.

1. The warranty process starts with contacting a Vilter Service and Warranty (S&W) department representative. *Ensure to have the original Vilter sales order number for the equipment available to better assist you.*
2. Our Vilter S&W representative will confirm if the equipment is within the warranty time frame as described in the warranty statement.

If the equipment (Part/Compressor/Compressor Motor) is within the warranty time frame, proceed to the following section regarding the type of equipment:

Process For Returning Products Covered By the Warranty

STEP 1. To return a defective Product or part under this warranty, you will need to provide the Vilter™ compressor order number on all submitted documents.

For a parts warranty request, you will also need to provide:

- The Vilter™ serial number of the compressor;
- A detailed and accurate description of the issue;
- A valid purchase order for the new part(s)—you must pay the freight;
- One copy of Return Merchandise Authorization (RMA) sent to you for your records;
- One copy of RMA sent to you to include in the return shipment of parts back to Vilter™ for warranty consideration.

STEP 2. Return the parts (freight prepaid) to:

VILTER MANUFACTURING CORPORATION
5555 South Packard Avenue
Cudahy, WI 53110-8904

STEP 3. Upon receipt of the returned part(s), Vilter™ will complete a timely evaluation of the part(s).

STEP 4. You will be contacted with Vilter's decision once the final report is completed.

STEP 5. If approved, the approved warranty will be credited (excluding freight) to your account. Vilter™ will retain the returned part(s) for final disposition. If a warranty request is not approved, you will be provided with a written response and the parts will be held for 30 days. After such time, Vilter™ will dispose of the parts. If you wish to have the part(s) returned, you will need to contact Vilter™ and the part(s) will be returned freight collect.

Procedure For Parts Not Manufactured By Vilter™

Although Vilter™ does not provide any warranty for parts and products that are not manufactured by Vilter™, Vilter™ does pass through any manufacturer's warranty to you (to the maximum extent permitted by the manufacturer). Vilter™ will work with you in facilitating your warranty claim with the manufacturer.

To facilitate your warranty claim, please follow the following four steps:

STEP 1. Determine if the part or product is within the OEM's warranty.

STEP 2. If the defective part or product is not a motor, send a description containing the specifications of the part/product and the defect to:

Service.Vilter@Copeland.com

If the defective part or product is a motor or starter, please complete the form on the next page and return it to:

Service.Vilter@Copeland.com.

STEP 3. Vilter™ will communicate with you, if necessary, to ascertain additional information and will reasonably assist with the OEM to determine the part/product's warranty status.

1. Determination if motor is within the OEM warranty.
2. Please complete the following and return to Service.Vilter@Copeland.com, along with a picture of the motor's nameplate.
3. Vilter will assist with the motor OEM to determine the motor's warranty status.

--

- Note:** Motor warranty is a “pass thru warranty” as stated in Vilter Manufacturing’s standard warranty statement which means that the original motor OEM is the provider of the warranty. Vilter does assist with the expediting of the claim but any dispensation of warranty is provided solely by the motor OEM.
- Motor manufacturer warranty covers only repair or replacement of the motor. It does not cover removal and installation charges, incidental charges associated with the removal and installation process, loss of product or shipping to and from the manufacturer or approved shop. This is standard motor manufacturer warranty policy regardless of brand or application. If the end user requires additional information regarding warranty coverage, the individual motor manufacturer warranty terms can be found on their associated websites.

Section 7 • Warranty and Parts

STEP 4. For defective motor or starter claims, if the motor or starter falls within the OEM's warranty time frame:

- The motor or starter will need to be taken to a manufacturer approved shop for diagnosis. Vilter™ can help you locate motor shops in your area that are manufacturer approved. The shop will diagnose the root cause, submit a report to the OEM, and the motor OEM will make the determination of warranty coverage.
- If a warranty claim is approved, the OEM will either have the motor or starter repaired by the motor shop or send a new replacement motor to the site.

On-Site Service Support

If on site support is required, contact a Vilter S&W department representative to start this process.

Warranty does not cover labor or expenses.

1. A quote, a service rate sheet, and the service terms and conditions will be provided.
2. Submit a PO.
3. Schedule the service visit.

Remanufactured Bare Shaft Single Screw Compressor Process

These instructions are an overview of how the process works when a bare shaft compressor is in need of being remanufactured. This is to help clear any questions that may arise prior to contacting customer service.

The process begins by contacting Vilter's Customer Service Department. Vilter contact information can be found on Page iii.

- Request a "VSS/VSM Single Screw Compressor Rebuild Form".
- Submit the Rebuild Form and a Purchase Order (PO) for the inspection. A fee is required for the initial inspection and tear down report; contact Vilter Customer Service representative for the latest fee.
- A Return Material Authorization (RMA) number will be provided.
- Send the compressor to Vilter in the condition as stated on the Rebuild Form (i.e. no oil in the compressor). Charges may apply if conditions are not met.
- A report will be sent to you after the inspection has been completed explaining what level of rebuild is necessary along with the cost.

NOTE

Inspection and rebuild times will vary, contact Vilter Customer Service representative for further details.

- Submit a new PO for the amount that will be needed for the rebuild. The inspection cost will be waived upon receipt of the new PO. Make sure to provide your "Ship to Address" and "Billing Address".

Explanation of Rebuild Levels

Level 1

Compressor is in good condition. Replace bearings, gaskets, shaft seal and O-rings. All hardware is intended to be re-used (when possible). Parts are organized in part kit form.

Level 2

Compressor is in good condition, but requires new gate rotor blades. Replace all items in Level 1 plus new gate rotor blades and bushings.

Level 3

Current Reman Compressor requires complete rebuilding and re-conditioning to "as-new" condition. All the components listed in Level 2 are replaced plus all hardware, slide assemblies, pistons, and a main rotor (if damaged) and/or gate rotor supports.

NOTE

A Level 1 and Level 2 rebuild will include washing the housing and repainting over the current paint.
A Level 3 rebuild will include blasting all the current paint off before repainting.

Bare Shaft Compressor Description

Single Screw Bare Shaft Compressor features include:

- Cast grey iron frame with cast ductile iron discharge manifold and gate rotor covers with discharge connection horizontal.
- Standard drive shaft is straight.
- Standard slide assembly.
- Viton shaft seal O-rings.
- Crating with Purge & Gauge.
- Does not include hand wheels or slide valve motors.

Section 8 • Spare Parts List

How to Read a Parts List and Illustration

A parts list consist of the following information:

Item Number

Item number associated with the number shown in the parts illustration.

Description

A description of an item.

Model Number

Compressor type and size.

VPN

VPN stands for Vilter™ Part Number.

Quantity

A quantity used for respective model or series of models.

Assembly and Kit Information

For assembly and kit, included items are added in parenthesis after part description.

Example-

ITEM	DESCRIPTION	MODEL NUMBER	
		VSCC 451	
		QTY	VPN
100	SUPPORT ASSEMBLY (110 and 135B)	2	A25159BB
110	SUPPORT	2	25606A
135B	DOWEL PIN, LG, 0.4375" O.D.	2	25910A

VPN A25159BB - SUPPORT ASSEMBLY includes items (110 and 135B).

Terms and Abbreviation Used

Term	Description
SM	Small
LG	Large
O.D.	Outer Diameter
BRG	Bearing
HSG	Housing
VOL.	Volume
CAP.	Capacity
AR	As Required
QTY	Quantity
W/O	Without
W/	With

Important Notes

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor.

Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Additional note/information of part/item/quantity shown at the bottom of parts table.

Vilter™ Aftermarket Parts Contact Information

Phone: 1-800-862-2677

Fax: 1-800-862-7788

E-mail: Parts.Vilter@Copeland.com

Website: Copeland.com/Vilter or Vilter.com

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.


**Compressor Models
VSCC 128 - 243 (HPLD)
Recommended
Spare Parts List**

**Refer to the Custom Manual
Spare Parts Section for Specific Applications**

**Please have your Model # and Sales Order # available when ordering.
These are found on the compressor's Name Plate.**

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor.
Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

VSCC 128 - 243 Compressor Kits



Gaterotor Kits

Gaterotor Kits		
Compressor Model	With Bearings	Without Bearings
128	KT712ABAAF*	KT713ABAAF*
145	KT712ABBAF*	KT713ABBAF*
160	KT712ABCAF*	KT713ABCAF*
180	KT712ABDAF*	KT713ABDAF*
204	KT712ABEAF*	KT713ABEAF*
222	KT712ABFAF*	KT713ABFAF*
243	KT712ABGAF*	KT713ABGAF*

* Aflas

Shaft Seal Kit

All HPLD Models			
Application	Description	VPN	QTY
Shaft Seal #25985Y	Shaft Seal Kit	KT709BHPFAF	1
25985YF (FFKM)	Shaft Seal Kit	KT709NAHPFAAF	1

Compressor Gasket and O-Ring Kit


All HPLD Models			
Application	Description	VPN	QTY
All Gaskets and O-Rings	Gasket & O-Ring Kit 600	KT710MAF	1
	Gasket & O-Ring Kit 900	KT710MBAF	1

Tool Kit

All HPLD Models			
Application	Description	VPN	Qty
For Gaterotor Removal and Installation	Gaterotor Tool Kit	A25205G	1
	Suction Tee Tool Kit	A24061A	1


Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Suction Covers



Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Discharge Manifold




Discharge Manifold Components

MODELS VSCC 128 to VSCC 243			
ITEM	DESCRIPTION	VPN	QTY
102	O-RING 11.984 X 12.262 AFLAS VP103-90	3547AA	1
103	O-RING 3.484 X 3.762 AFLAS VP103-90	3547AB	2

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Housing



Housing Components

MODELS VSCC 128 to VSCC 243			
ITEM	DESCRIPTION	VPN	QTY
103	O-RING .796X1.074 AFLAS VP103-90	3547BN	3
104	PLUG 1/4-18NPTF FLUSH SEAL SOC HD	2606C	1
105	PLUG 5/16 HEX SAE FOR J1926 PORT AFLAS	3647A	1
106	PLUG 9/16 HEX SAE FOR J1926 PORT AFLAS	3647D	5

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

**Compressor Models
VSCC 291 - 601 (240MM)
Recommended
Spare Parts List**


**Refer to the Custom Manual
Spare Parts Section for Specific Applications**

NOTE

**Please have your Model # and Sales Order # available when ordering.
These are found on the compressor's Name Plate.**

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor.
Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Gaterotor



*For VSCC Models from 291 to 601

Valter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Section 8 • Spare Parts List

Gaterotor (VSCC 291 - 601, 1 of 2)

ITEM	DESCRIPTION	MODEL NUMBER							
		VSCC 291		VSCC 341		VSCC 451		VSCC 601	
		QTY	VPN	QTY	VPN	QTY	VPN	QTY	VPN
-	GATEROTOR BLADE AND BEARING REPLACEMENT KIT (111, 118, 120A, 120B, 121, 122, 123, 124, 125, 126, 130, 131, 141, 142, 143)	AR	KT712ZNAF	AR	KT712TNAF	AR	KT712ANAF	AR	KT712BNAF
-	GATEROTOR BLADE REPLACEMENT KIT (111, 118, 120A, 120B, 121, 122, 123, 124, 130, 141, 142, 143)	AR	KT713KAF	AR	KT713NAF	AR	KT713ANAF	AR	KT713BNAF
100	SUPPORT ASSEMBLY (110 & 135B)	2	A25159BDLB	2	A25159BCLB	2	A25159BBLB	2	A25159BALB
102	GATEROTOR SUPPORT ASSEMBLY (100, 111, 120B, 119, 130)	2	A25161BDLB	2	A25161BCLB	2	A25161BBLB	2	A25161BALB
105	GATEROTOR GASKET SET (118, 141, 142, 143)	2	A25164B	2	A25164B	2	A25164B	2	A25164B
106	SHIM PACK SET ((2) 121, (2) 122, (1) 123, (1) 124)	2	A25165B	2	A25165B	2	A25165B	2	A25165B
110	SUPPORT	2	27970C	2	27970B	2	27970D	2	27970A
111	GATEROTOR	2	25557D	2	25557C	2	25557A	2	25534A
112	SMALL BEARING HOUSING	2	25518D	2	25518D	2	25518D	2	25518D
113	LARGE BEARING HOUSING	2	25517A	2	25517A	2	25517A	2	25517A
114	RETAINER	2	25008A	2	25008A	2	25008A	2	25008A
115	RETAINER	2	25009A	2	25009A	2	25009A	2	25009A
116	BALL BEARING COVER	2	25258A	2	25258A	2	25258A	2	25258A
117	GATEROTOR COVER	2	25519A	2	25519A	2	25519A	2	25519A
118	GATEROTOR COVER GASKET	2	25259A	2	25259A	2	25259A	2	25259A
119	WASHER	2	25007A	2	25007A	2	25007A	2	25007A
120A	BUSHING, SMALL DOWEL PIN	2	25006A	2	25006A	2	25006A	2	25006A
120B	BUSHING, LARGE DOWEL PIN	2	25760A	2	25760A	2	25760A	2	25760A
121	SHIM 0.002"	AR	25010AA	AR	25010AA	AR	25010AA	AR	25010AA
122	SHIM 0.003"	AR	25010AB	AR	25010AB	AR	25010AB	AR	25010AB
123	SHIM 0.005"	AR	25010AC	AR	25010AC	AR	25010AC	AR	25010AC
124	SHIM 0.010"	AR	25010AD	AR	25010AD	AR	25010AD	AR	25010AD
125	ROLLER BEARING	2	2864T	2	2864T	2	2864T	2	2864T
126	BALL BEARING	4	2865BP	4	2865BP	4	2865BP	4	2865BP
130	RETAINING RING	2	2866A	2	2866A	2	2866A	2	2866A
131	RETAINING RING	2	2867A	2	2867A	2	2867A	2	2867A

Note - AR: As Required.

Section 8 • Spare Parts List

Gaterotor (VSCC 291 - 601, 2 of 2)


ITEM	DESCRIPTION	MODEL NUMBER							
		VSCC 291		VSCC 341		VSCC 451		VSCC 601	
		QTY	VPN	QTY	VPN	QTY	VPN	QTY	VPN
135A	DOWEL PIN, SM, 0.250" O.D.	2	2868B	2	2868B	2	2868B	2	2868B
135B	DOWEL PIN, LG, 0.4375" O.D.	2	25910A	2	25910A	2	25910A	2	25910A
140	O-RING 10.484 X 10.726 AFLAS VP101	2	3547R	2	3547R	2	3547R	2	3547R
141	O-RING ROLLER BEARING HOUSING	2	3547B	2	3547B	2	3547B	2	3547B
142	O-RING BALL BEARING HOUSING	2	3547D	2	3547D	2	3547D	2	3547D
143	O-RING BRG HSG COVER	2	3547C	2	3547C	2	3547C	2	3547C
150	HEX HEAD CAP SCREW (1/4- 20 NC X 1-1/4)	12	2796AJ	12	2796AJ	12	2796AJ	12	2796AJ
151	HEX HEAD CAP SCREW (5/16- 18 NC X 1-1/4)	6	2796B	6	2796B	6	2796B	6	2796B
152	HEX HEAD CAP SCREW (3/8- 16 NC X 1-1/4)	40	2796CJ	40	2796CJ	40	2796CJ	40	2796CJ
153	HEX HEAD CAP SCREW (1/4- 20 NC X 1)	32	2795E	32	2795E	32	2795E	32	2795E
160	SOCKET HEAD CAP SCREW	12	2795E	12	2795E	12	2795E	12	2795E

Note - AR: As Required.

Filter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Shaft Seal

Shaft Seal With Stationary Carbon Face




ITEM	DESCRIPTION	MODEL NUMBER	
		QTY	VSCC 291 - 601
			VPN
*	SHAFT SEAL AMM KIT (219, 230, & 260)	1	KT709A (Ø2.25")
*	SHAFT SEAL HALO KIT (219, 230, & 260)	1	KT781A
219	SHAFT SEAL	1	A
230	OIL SEAL	1	25040A
260	O-RING	1	2176F

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Main Rotor


ITEM		207	201
MODEL NUMBER	QTY	DESCRIPTION	
		SHIM PACK	ROTOR ASSEMBLY
VSCC 291	1	A25177B	A25226BL
VSCC 341	1	A25177B	A25226BE
VSCC 451	1	A25177B	A25226BB
VSCC 601	1	A25177B	A25226BA



*For VSCC Models from 291 to 601

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Slide Valve Cross Shafts and End Plate



*For VSCC Models from 291 to 601


Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Slide Valve Cross Shafts and End Plate

ITEM	DESCRIPTION	MODEL NUMBER	
		VSCC 291 - 601	
		QTY	VPN
221	SHAFT	2	25843A
222	GEAR	4	25027A
226	RACK CLAMP	2	25913A
227	RACK CLAMP	2	25913B
228	SPACER	2	25847A
267	DOWEL PIN	-	N/A
268	EXPANSION PIN	4	1193D
269	EXPANSION PIN	4	2981AA
270	PIPE PLUG	-	N/A
286	SOCKET HEAD CAP SCREW	8	2795F
297	SET SCREW	2	2060J
298	SET SCREW	2	2060H

Note: N/A: Not Applicable

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.




Slide Valve Carriage Assembly

ITEM	DESCRIPTION	MODEL NUMBER	
		VSCC 291 thru VSCC 601	
		QTY	VPN
300	CARRIAGE ASSEMBLY	2	A25179B
304	CAPACITY PISTON (340, 341, 350, 355)	2	A25183B
305	VOLUME PISTON (340, 342, 350, 355)	2	A25184B
307A	GASKET (345)	2	25900A
307B	GASKET SET (345, 378)	-	N/A
316	RACK	2	25024AH
323	RACK	2	25023AH
325	SHAFT	-	N/A
340	PISTON	-	N/A
341	CAPACITY PISTON SHAFT	-	N/A
342	VOLUME PISTON SHAFT	-	N/A
343A	COVER, SEPARATE VOL. & CAP.	4	25022A
343B	COVER, ONE PIECE CAST	2	25399D
344	COVER, SEPARATE VOL. & CAP.	-	N/A
345A	GASKET, SEPARATE VOL. & n/a CAP COVERS	4	25021A
345B	GASKET, ONE PIECE CAST COVER	2	25900A
346	GASKET, ONE PIECE CAST COVER	-	N/A
347	PISTON SLEEVE	-	N/A
350	PISTON RING SET	4	2953AA
355	EXPANSION PIN	4	1193PP
359	PIPE PLUG	6	2606D
360	LOCK WASHER (PAIR)	4	3004C
361	WASHER	4	13265B
363	NUT	8	2797A
366A	HEX HEAD CAP SCREW, SEPARATE VOL. & CAP. COVERS	24	2796N
366B	HEX HEAD CAP SCREW, ONE PIECE CAST COVER	24	2796B
367	HEX HEAD CAP SCREW	-	N/A
373	SOCKET HEAD CAP SCREW	-	N/A
374	LOCK WASHER (PAIR)	-	N/A
378	O-RING	-	N/A
380	RETAINER RING	-	N/A

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Actuator and Command Shaft




ITEM	DESCRIPTION	MODEL NUMBER	
		QTY	VSCC 291 thru VSCC 601
			VPN
400	COMMAND SHAFT ASSEMBLY	2	A25994B
401	SLIDE VALVE ACTUATOR	2	25972D
446	O-RING SEAL	2	3547F

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Miscellaneous Frame Components

VSCC Screw Compressor



* For VSCC Models from 291 to 601

Filter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Miscellaneous Frame Components



ITEM	DESCRIPTION	MODEL NUMBER	
		VSCC 291 - 601	
		QTY	VPN
-	GASKET & O-RING KIT	1	KT710AN
504A	FLANGE SET (513A, 514A, 545A)	1	A25190A
504B*	FLANGE SET (513B, 514B, 545B)	2	A25190B
504C*	FLANGE SET (513B, 514C, 545C)	-	N/A
506A	PLUG SET, ECONOMIZER (514C, 528, 545B)	1	A25243BE
506B	PLUG SET, ECONOMIZER (514A, 514C, 528, 545C)	-	N/A
511	DISCHARGE MANIFOLD	1	25502A
512	MANIFOLD GASKET	1	25503A
513A	FLANGE	1	25058ASW
513B	FLANGE	2	25058B
514A	GASKET	1	11323D
514B	GASKET	2	11323E
514C	GASKET	2	11323D
518	GASKET, SUCTION	1	25199C
519	GASKET, DISCHARGE	1	25199B
528	ECONOMIZER PLUG	2	25397G
530	O-RING	2	3547M
536	PIPE PLUG 3/4" MPT	-	N/A
540	DOWEL PIN	2	2868B
542	PIPE PLUG 3/4" MPT	-	N/A
545A	HEX HEAD CAP SCREW	2	2796GP
545B	HEX HEAD CAP SCREW	4	2796C
545C	HEX HEAD CAP SCREW	-	N/A
547	HEX HEAD CAP SCREW	8	2796C

Note: *: Optional

Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.


Miscellaneous Frame Components (Tubing and Fittings)

Gaster Bearing Supply Lines



VSCC 291 to 601

Seal Chamber Oil Line



VSCC 291 THRU 601

Slide Valve Balance Piston Equalizing Line

Filter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.


Miscellaneous Frame Components (Tubing and Fittings)

ITEM	DESCRIPTION	MODEL NUMBER	
		VSCC 291 to 601	
		QTY	VPN
555	ELBOW 1/4 ODT X 1/4 MPT 90° MALE	5	13375D
556	STRAIGHT 1/4 ODT X 1/4 MPT	1	13229D
557	TEE, RUNNING 1/4 OD X 1/4 MPT MALE	1	1509A
558	HEX BUSHING	1	13231AA
559	HEX BUSHING	-	N/A
560	ELBOW 3/8 ODT X 1/2 MPT 90° MALE	1	13375Z
561	ELBOW 3/8 OD X 1/4 MPT 90° MALE	1	13375F
562	PLUG	1	2606E
563	TEE 1/4 ODT X 1/4 ODT X 1/4 MPT BRANCH	-	N/A
564	TEE 1/4	-	N/A
565	TEE 1/4T X 1/4T X 1/4 FPT FEMALE	-	N/A
566	NIPPLE 1/4 X 2-1/2 PIPE	-	N/A
567	CONNECTOR 1/2-13 NC-2 X 1 SET	-	N/A
568	REDUCING BUSHING 1 X 1/4	-	N/A


Vilter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Replacement Tools

TO REMOVE
BEARING
HOUSING




TO INSTALL
BEARING
HOUSING



Position	Description
901	STABILIZER
102	BAR PULLER
103	PULLER SHOE
104	PUSHER SHOE
105	SCREW JACKING
106	STUD
107	STUD
108	SCREW
109	SCREW

FOR VSSG 291-601
COMPRESSORS, DO
NOT USE SIDE RAILS.



ITEM	DESCRIPTION	MODEL NUMBER	
		QTY	VSCC 291 THRU VSCC 601
			VPN
900	GATEROTOR TOOLS	1	A25205B
901A	GATEROTOR STABILIZER SET (901A, 901B, 901C)	1	A25698A
901B	GATEROTOR STABILIZER SET (901A, 901B, 901C, 901D)	1	N/A

Section 8 • Spare Parts List

Replacement Parts

COMPONENT	DESCRIPTION	VPN	QTY	WHERE USED
VSCC Units Horizontal Oil Separator	Oil Separator Defogger Element	2879A	2	24" Oil Separator
			3	30" Oil Separator
			4	36" Oil Separator
			5	42" Oil Separator
	Cover Gasket, 13"x12"	93559A	1	24" Oil Separator
			1	30" Oil Separator
	Cover Gasket, 16"x15"	93560A	1	36" Oil Separator
			1	42" Oil Separator
VSCC Units Oil Filter	Oil Filter Element	1833C	1	Single Element Filter Tank
			2	Dual Element Filter Tank
	Filter Tank Cover Gasket (Included with 1833C)	35197A	1	Single or Dual Element Filter Tank
VSCC Units Suction Strainer	Strainer Screen, 4" & 5"	2881A	1	4" & 5" Suction Strainer
	Strainer Screen, 6"	2881B	1	6" Suction Strainer
	Strainer Screen, 8"	2881C	1	8" Suction Strainer
	Strainer Cover Gasket	2555E	1	4" & 5" Suction Strainer
	Strainer Cover Gasket	2555F	1	6" Suction Strainer
	Strainer Cover Gasket	2555G	1	8" Suction Strainer
Safety Relief Valves	See unit order information			
Replacement Solenoid Valve Coils	Solenoid Coil, 115V/50 Hz., Yellow and Blue Leads	2650W	1	2650 Series Solenoid Valve, 115V/50 Hz.
	Solenoid Coil, 230V/50 Hz., Yellow Leads	2650X	1	2650 Series Solenoid Valve, 230V/50 Hz.
	Solenoid Coil, 120V/60 Hz., Blue Leads	2650Y	1	2650 Series Solenoid Valve, 120V/60 Hz.
	Solenoid Coil, 240V/60 Hz., Red Leads	2650Z	1	2650 Series Solenoid Valve, 240/60 Hz.
Haight Oil Pump	Bare 24 GPM Oil Pump Z56SO NEOPRENE HP	3022DUHPC & 2913E	1	24 GPM Oil Pump
	Replacement Shaft Seal	3022CU	1	24, 30, and 40 GPM Haight Oil Pumps
Liquid Injection	R-744 Thermostatic Expansion Valve**	TBD	1	R-744 Liquid Injection System**
	Power Head Assembly	2637A	1	2 thru 15 Ton Thermostatic Expansion Valve
	Power Head Assembly	2637B	1	20 thru 100 Ton Thermostatic Expansion Valve
	Solenoid Valve Coil	2650VA	1	KIT REPLACEMENT W/S8F W/ STRAINER

Notes -

** : W/O Flange, W/ EXT 10FT Y764






Filter parts get renewed from time to time, so be sure to ask if the part listed in your manual is still the best for your compressor. Parts that appear on diagrams might be shown separately for reference, but are sold as an assembly or kit only.

Appendix A • Torque Specifications



Torque Specifications

Refer to the following tables for torque specifications.

Table A-1. Torque Specifications (ft-lbs) (For Compressors Only)

TYPE BOLT	HEAD MARKINGS	NOMINAL SIZE NUMBERS OR INCHES									
		#10	1/4"	5/16"	3/8"	7/16"	1/2"	9/16"	5/8"	3/4"	7/8"
SAE GRADE 2 COARSE (UNC)			5	10	18	29	44	63	87	155	150*
SAE GRADE 2 COARSE (UNC)			8	16	28	44	68	98	135	240	387
SAE GRADE 5 FINE (UNF)				16							
SAE GRADE 2 COARSE (UNC)			11	22	39	63	96	138	191	338	546
SOCKET HEAD CAP SCREW (ASTM A574) COARSE (UNC)		5	13	26	46	73	112	155	215	380	614
Notes:	1) Torque values on this sheet are not to override those given on the individual drawings.										
	2) When using loctite, the torque value on this sheet are only accurate if bolts are tightened immediately after loctite is applied.										
	* The proof of strength of Grade 2 bolts is less for sizes 7/8 and above and therefore the torque values are less than smaller sizes of the same grade.										

**Table A-2. Torque Specifications for 17-4 Stainless Steel Fasteners (ft-lbs)
(For Compressors Only)**

TYPE BOLT/NUT	HEAD MARKINGS	NOMINAL SIZE NUMBERS OR INCHES									
		#10	1/4"	5/16"	3/8"	7/16"	1/2"	9/16"	5/8"	3/4"	
Hex & Socket Head Cap Screws		3	8	14	25	40	60	101	137	245	
Nut		-	8	-	25	-	-	-	-	-	

NOTE

Continue use of red loctite #271 (VPN 2205E) on currently applied locations. Use blue loctite #243 (VPN 2205F or 2205G) on all remaining locations.

Appendix A • Torque Specifications

Table A-3. SA193 B7/SA320 L7 Bolts / Studs – Torque Requirements
Per ASME Codes: B31.5 and B31.3

Nominal Bolting Diameter	Nominal Torque (ft.lbs.)	Maximum Torque (ft.lbs.)	Torque (ft.lbs) Using Flexitallic Gasket
3/8"	17	20	25
7/16"	19	22	28
1/2"	20	25	30
5/8"	40	50	60
3/4"	65	83	100
7/8"	100	133	160
1"	120	204	245
1-1/4"	150	454	500

Notes:

1. The above torque values apply unless otherwise specified on drawing.
2. Bolting to be tightened incrementally in a diametrically staggered pattern to the nominal torque value.
3. If necessary, torque can be increased in 10% increments; do not exceed the maximum torque values.
4. For other materials please consult Vilter Engineering Department for torque values.

Oil Analysis Report



Customer Name
Customer Address

PRODUCT ANALYSIS REPORT

No Action Required

Report Date:	3/4/2013
Report Number:	*****
Customer	Customer
Comp. Mfr.	Vilter
Oil Type	VILTER-717
Serial Number	****.***
Model Number	VSM-601
Hrs. on Fluid	6049
Hrs. on Machine	11239
Sample Date	Feb 21, 2013
Receive Date	Mar 01, 2013
I.D. #	*****

Evaluation:

The fluid is in good condition. Sample again in 6 months.

Physical Properties Results *

Sample Date (Lube Hours)	Feb 21, 2013 (6049)	Oct 19, 2012 (4809)	Jul 26, 2010 (5190)
Water by Karl Fischer (ppm)	19.5	147.7	41.4
Viscosity 40 C (cSt)	64.23	64.47	66.00
TAN Total Acid #	0.077	0.106	0.080
ISO Code	21/20/16	21/19/16	21/19/14

Spectrochemical Analysis

Wear Metals (ppm)			
Silver (Ag)	0	0	0
Aluminum (Al)	0	0	0
Chromium (Cr)	0	0	0
Copper (Cu)	0	0	0
Iron (Fe)	0	0	0
Nickel (Ni)	0	0	0
Lead (Pb)	0	0	0
Tin (Sn)	0	0	0
Titanium (Ti)	0	0	0
Vanadium (V)	0	0	0
Contaminant/Additive Metals (ppm)			
Barium (Ba)	0	0	0
Calcium (Ca)	0	0	0
Magnesium (Mg)	0	0	0
Molybdenum (Mo)	0	0	0
Sodium (Na)	0	0	0
Phosphorus (P)	0	0	0
Silicon (Si)	0	0	0
Zinc (Zn)	0	0	0

Thank you for this opportunity to provide technical assistance to your company. If you have any questions about this report, please contact us at 1-800-637-8628, or fax 1-989-496-2313 or email us at tslab@oil-services-lab.com

CC List

Accuracy of recommendations is dependent on representative oil samples and complete correct data on both unit and oil

* Property values should not be construed as specifications

Storage Guidelines For Vilter B and FL Type Lubricants

Vilter Type B and FL lubricants are ester-based fluids and are hygroscopic by nature. This means that they absorb water moisture from the surrounding environment. Compared to mineral based lubricants which are typically saturated with water at less than 100 PPM, ester based lubricants become saturated with water at approximately 2,500 PPM.

High water moisture levels cannot be tolerated in the refrigeration systems where ester based lubricants are utilized and require specific handling and storage guidelines, in addition to the normal precautions for system dehydration prior to system start-up.

All Vilter lubricants are manufactured to meet strict requirements to ensure minimal water moisture content as shipped. The following guidelines are provided for the end-user of the equipment as a means to minimize the water content of lubricants in storage.

Guidelines

- Use a suitable dehydration process for the complete refrigeration system to ensure that the system as a whole is completely dry and water free. This can be accomplished by the use of vacuum pumps and checked by a vacuum gauge to ensure that a suitable micron value has been reached, and maintained.
- Store all lubricant containers in a dry environment. Do not expose the lubricant to the atmosphere by opening the container until the compressor sump or separator is ready to be charged.

- Keep the lubricant in its original container. Some plastic containers allow water moisture to pass through the container itself.
- If possible, use container sizes appropriate to the compressor charge to avoid leaving partially filled containers open for long period of times. Vilter B Type lubricant is available in 5 and 55 gallon containers.
- Refrigeration systems using ester based lubricants will require suitable high capacity moisture filter/driers to maintain low total moisture content in the refrigerant and lubricant.

Compatibility and Misc.

- Vilter Type B lubricant has been extensively tested with many of the components in a refrigeration system. Elastomers, driers, etc. for use with HFCs have demonstrated no adverse effects when tested for hardness, swelling and brittleness.
- Vilter Type B lubricant cannot be used in conjunction with a mineral based oils are not miscible with HFCs. The performance of a refrigeration system is optimized when the lubricant is allowed to be miscible with the refrigerant to aid in the oil return to the compressor. If the oil used in an HFC refrigeration system does not provide oil return capability, the oil will tend to accumulate in the evaporator reducing the overall system capacity.
- CFC and HCFC refrigerants should not be used with Vilter Type B lubricant since these types of refrigerants greatly reduce the viscosity of ester based lubricants, resulting in inadequate compressor lubrication.

Table B-1 Oil Recommendations for Standard Warranty Coverage Single Screw Compressors Only

Vilter Oil Type	717	HCL-68	F-68	FL-100	B-68	HC-68
ISO Grade	68	68	68	100	68	68
@ 100°F (cSt)	77	75.7	65.67	76.4	71	67.2
Viscosity Index	100	132	79	115	108	168
Spec. Gravity	0.867	0.835	0.876	0.96	0.957	0.989
Density lbm/gal, 60°F	7.4	6.95	7.3	8.26	7.96	8.25
Flash Point - °F	440	525	295	558	505	425
Fire Point - °F	475	570	315	633	560	465
Pour Point - °F	-38.2	-67	-31	Pending	-45	-55
Floc Point - °F	-25	NA	-75	NA	NA	NA
Refrigerant Type	R-717	R-717, R-22, R-1270	R-22	R-22	R-134a, R-507; R-404A, R-407C R-410A	R-290

Table B-2 Cross Reference Index

VPN	Oil Type	Vilter Lube Type	Container Size	Applications
3098A	PAG	HC-68	5 gallon pail	R-290
3098B	PAG	HC-68	55 gallon drum	R-290
3099A	PAG	HC-100	5 gallon pail	Hydrocarbon
3143A	PAO-100	METHANE	5 gallon pail	Hydrocarbon/natural gas, Landfill gas, Turbine feed gas
3143B	PAO-100	METHANE	55 gallon drum	Hydrocarbon/natural gas, Landfill gas, Turbine feed gas
3143C	PAO-68	METHANE	5 gallon pail	Hydrocarbon/natural gas, Landfill gas, Turbine feed gas
3143D	PAO-68	METHANE	55 gallon drum	Hydrocarbon/natural gas, Landfill gas, Turbine feed gas
3143G	PAO-150	METHANE	5 gallon pail	Hydrocarbon/natural gas, Landfill gas, Turbine feed gas
3143H	PAO-150	METHANE	55 gallon drum	Hydrocarbon/natural gas, Landfill gas, Turbine feed gas
3143J	PAO-100	DIGESTER	5 gallon pail	Hydrocarbon/natural gas, Landfill gas, Turbine feed gas
3143K	PAO-100	DIGESTER	55 gallon drum	Hydrocarbon/natural gas, Landfill gas, Turbine feed gas
3339A	PAO	CO ₂ GAS	5 gallon pail	CO ₂ , CO
3339B	PAO	CO ₂ GAS	55 gallon drum	CO ₂ , CO
3636A	PAO	CO ₂	5 gallon pail	Gas streams containing moisture, CO ₂ , CO and/or H ₂ S
3636B	PAO	CO ₂	55 gallon drum	Gas streams containing moisture, CO ₂ , CO and/or H ₂ S
3643A	PAO	XG 105-100	5 gallon pail	Hydrocarbon/natural gas
3643B	PAO	XG 105-100	55 gallon drum	Hydrocarbon/natural gas
3653A	POE	POE-100	5 gallon pail	Air Compressor Lubricant
3653B	POE	POE-100	55 gallon drum	Air Compressor Lubricant

Vibration Measurements - Single Screw Compressor

Scope

The vibration criteria provided applies to broad-band vibration measurements taken on the bearings and housing of the Single Screw compressors under steady-state operating conditions within the nominal operating speed range in addition to the piping and tubing on the compressor unit. They relate to both acceptance testing and operational monitoring. The evaluation criteria is intended to apply to both continuous and non-continuous monitoring situations. The scope does not address the diagnostic evaluation of the condition of the roller element bearings. The criteria are applicable only for the vibration produced by the machine itself and not for vibration which is transmitted to the machine set from external sources. Information used in this chapter was taken from ISO Standard 10816-3, Mechanical Vibration – Evaluation of Machine Vibration by Measurements on Non-Rotating Parts – Part 3, First Edition, 1998.

Measurement Procedures and Operational Conditions

Measurement Equipment

The measurement equipment shall be capable of measuring broad-band rms vibration with flat response over a frequency range of at least 10 Hz to 1000 Hz. Depending on the vibration criteria, this may require measurements of displacement or velocity or combinations thereof.

Care should be taken to ensure that the measuring system is not influenced by environmental factors such as:

- Temperature variations;
- Magnetic fields;
- Sound fields;
- Power source variations;
- Transducer cable length;
- Transducer orientation.

Particular attention should be given to ensure that the vibration transducers are correctly mounted and that such mountings do not degrade the accuracy of the measurements.

Compressor Measurement locations

Measurements taken on the compressor will usually be taken on exposed parts that are normally accessible. Care shall be taken to ensure that measurements reasonably represent the vibration of the bearing housing and do not include any local resonances or amplification. The locations and directions of vibration measurements shall be such that they provide adequate sensitivity to the machine dynamic forces. Typically, this will require two radial measurement locations on each bearing cover on the gate rotor housing support and back plate (near the compressor shaft). Vertical and horizontal directions are preferred for Single Screw compressors. The specific locations and directions shall be recorded with the measurement.




Figure C-1. Compressor Bearing Vibration Measurement Location




Figure C-2. Main Rotor Cross-Section VSCC Compressors

Continuous and Non-continuous Monitoring

While it is common practice on large or critical machinery to have installed instrumentation for continuous on-line monitoring of vibration values at key measurement points, this is not necessarily carried out in industrial applications.

Changes in unbalance, bearing performance, alignment, etc. can be detected with sufficient reliability from periodic measurements with permanently installed or hand-held instruments. The use of computers for trend analysis and warning against malfunctions is also becoming more common.

Operational Conditions

Measurements shall be carried out when the compressor has reached normal steady-state operating temperatures and with the machine running under specified conditions. If the measured vibration is greater than the acceptance criteria allowed and an excessive background vibration is suspected, measurements should be made with the machine shut down to determine the degree of external influence. If the vibration with the machine stationary exceeds 25% of the value measured when the machine is running, corrective action may be necessary to reduce the effect of the background vibration.

Evaluation

There are two evaluation criteria used to assess vibration severity on various classes of machines. One criteria considers the magnitude of observed broad-band vibration; the second considers changes in magnitude, irrespective of whether they are increases or decreases.


Criterion 1: Vibration Magnitude

This criterion is concerned with defining limits for vibration magnitude consistent with acceptable dynamic loads on the bearings and acceptable vibration transmission into the environment through the support structure and foundation. The maximum vibration magnitude observed at each bearing or pedestal is assessed against the evaluation zones for the support class. The evaluation zones have been established from international experience.

The following evaluation zones are defined to permit a qualitative assessment of the vibration of a given machine and provide guidelines on possible actions.

- Zone A: The vibration of newly commissioned machines would normally fall within this zone.
- Zone B: Machines with vibration within this zone are normally considered acceptable for unrestricted long-term operation.
- Zone C: machines with vibration within this zone are normally considered unsatisfactory for long term continuous operation. Generally, the machine may be operated for a limited period in this condition until a suitable opportunity arises for remedial action.
- Zone D: Vibration values within this zone are normally considered to be of sufficient severity to cause damage to the machine.

Numerical values assigned to the zone boundaries are not intended to serve as acceptance specifications, which shall be subject to agreement between Vilter™ manufacturing and the customer. However, these values provide guidelines for ensuring that gross deficiencies or unrealistic requirements are avoided. In certain cases, there may be specific features associated with a particular machine which would require different zone boundary values (higher or lower) to be used.



NOTE: GATEROTOR RPM = $6/11 (.545) \times$ MAIN SHAFT RPM

Figure C-3. Gaterotor Cross-Section VSCC Compressors

Appendix C • Vibration Measurements - Single Screw Compressor

Evaluation Zone limits

The values for the zone boundaries given below are based on the maximum broad-band values of velocity and displacement when measurements are taken from two orthogonally oriented radial transducers. Therefore when using these tables, the higher of each of the values measured from the two transducers in each measurement plane should be used. When the maximum measured values of velocity and displacement are compared to the corresponding values in the table, the severity zone which is most restrictive shall apply.

Operational limits

For long-term operation, it is common practice to establish operational vibration limits. These limits take the form of ALARM and TRIP set points.

ALARM: To provide a warning that a defined value of vibration has been reached or a significant change has occurred, at which remedial action may be necessary. In general, if an ALARM situation occurs, operation can continue for a period while investigations are carried out to identify the reason for the change in vibration and define any remedial action.

TRIP: To specify the magnitude of vibration beyond which further operation of the machine may cause damage. If the TRIP value is exceeded, immediate action should be taken to reduce the vibration or the machine should be shut down.

Different operational limits, reflecting differences in dynamic loading and support stiffness, may be specified for different measurement positions and directions.

Table C-1. Vibration Zone Values

VIBRATION MEASUREMENTS – SINGLE SCREW COMPRESSOR*					
Support Class	ZONE	RMS Displacement		RMS Velocity	
		μmm	mils	mm/s	In/sec
	A	0-30	0-1.15	0-2.3	0-.09
	B	30-57	1.15-2.25	2.3-4.5	.09-.18
	C	57-90	2.25-3.55	4.5-7.1	.18-.28
	D	Above 90	Above 3.55	Above 7.1	Above .28

*RMS= 0.707 X peak (sine wave only)

Setting of ALARMS

The ALARM values may vary considerably, up or down, for different machines. The values chosen will normally be set relative to a baseline value determined from experience for the measurement position or direction for that particular machine.

It is recommended that the ALARM value should be set higher than the baseline by an amount equal to 25% of the upper limit for zone B. If the baseline is low, the ALARM may be below zone C.

Where there is no established baseline (for example with a new machine) the initial ALARM setting should be based either on experience with other similar machines or relative to agreed acceptance values. After a period of time, the steady-state baseline value will be established and the ALARM setting should be adjusted accordingly.

It is recommended that the ALARM value should not normally exceed 1.25 times the upper limit of zone B.

If the steady-state baseline changes (for example after a machine overhaul), the ALARM setting should be revised accordingly.

Setting of TRIPS

The TRIP values will generally relate to the mechanical integrity of the machine and be dependent on any specific design features which have been introduced to enable the machine to withstand abnormal dynamic forces. The values used will, therefore, generally be the same for all machines of similar design and would not normally be related to the steady-state baseline value used for setting ALARMS.

There may, however, be differences for machines of different designs and it is not possible to have clear guidelines for absolute TRIP values. In general, the TRIP value will be within zone C or D, but it is recommended that the TRIP value should not exceed 1.25 times the upper limit of zone C.

Vibration limits For Piping and Tubing

The piping and tubing on the compressor units must be supported with the appropriate brackets and supports to minimize the vibration levels. These brackets and supports should also be strategically placed to prevent the natural frequency from matching the normal operating speed. The typical goal is to have the natural frequency of an assembly to be at least 10% above or below the operating speed. In the case when a compressor is operated by a VFD (Variable Frequency Drive), there is a high probability that there will be an opportunity to match either the natural frequency of the assembly or its 2nd or 3rd order since the compressor's speed will vary within a large range of RPM's.

The compressor unit should first be operated at either the normal operating speed or if it utilizes a VFD, through the operating range of speed. Visual observations of the vibration levels of all the piping and tubing should first be observed. After this initial survey, the vibration measurement equipment should be individually mounted or attached to each specific piece of piping or tubing as required in the location of what is perceived as the maximum amplitude or worse vibration.

While there are references which specifically allow higher levels of vibration for piping, the goals for the vibration levels of the piping and tubing on the compressor unit should still utilize the same criteria outlined in this standard. If possible, the vibration levels should be within the zone boundaries of Zone B or better. These values will ensure that the stress levels in the piping and tubing are acceptable for continuous operation. These values provide guidelines for ensuring that gross deficiencies or unrealistic requirements are avoided. In certain cases, there may be specific features associated with a particular compressor unit which would require different zone boundary values.

For compressors that are operated at a fixed speed, brackets and supports may be added or moved to reduce the vibration levels of the specific component. If the compressor is operated utilizing a VFD, a skip frequency should be inputted into the controls to ensure the compressor passes through the harmonic and that it operates either below or above the operating speed that matches the natural frequency of the specific component. It is not unusual to have three or four skip frequencies within the normal operating ranges of a compressor utilizing a VFD.

Appendix D

Liquid Injection Valve Setup Instructions and ICM/ICAD Motorized Valve Quick Start Guide

Danfoss ICM/ICAD Valve Setup Instructions

The following items need to be setup in order for the valve to operate properly.

1. Press the “Circle” button on the valve. A value of “01” should be shown on the screen.
2. Press the “Circle” button. There should be a value of “1” shown. If not use the up/down arrows to change it to the correct value. Press the “Circle” button when done.
3. Press the “Up” arrow button. A value of “02” should be shown on the screen.
4. Press the “Circle” button. There should be a value of “1” shown. If not use the up/down arrow buttons to change it to the correct value. Press the “Circle” button when done.
5. Press the “Up” arrow button. A value of “03” should be shown on the screen.
6. Press the “Circle” button. There should be a value of “2” shown. If not, use the up/down arrow buttons to change it to the correct value. Press the “Circle” button when done.
7. Press the “Up” arrow button until a value of “04” is shown on the screen.
8. Press the “Circle” button. There should be a value of “50” shown. If not, use the up/down arrow buttons to change it to the correct value. Press the “Circle” button when done.
9. Press the “Up” arrow button until a value of “07” is shown on the screen.
10. Press the “Circle” button. There should be a value of “1” shown. If not, use the up/down arrow buttons to change it to the correct value. Press the “Circle” button when done.
11. Press the “Up” arrow button until a value of “10” is shown on the screen.
12. Press the “Circle” button. Press the up/down arrow button to change the value to “11”. Press the “Circle” button.
13. Press the “Up” arrow button until a value of “26” is shown on the screen.
14. Press the “Circle” button. Press the up/down arrow buttons to change the value to the correct valve that is on the unit. The value number is listed on the valve. The values and valves are as follows:
 - 0: No valve selected. Alarm A1 will become active.
 - 1: ICM20 with ICAD 600
 - 2: ICM25 with ICAD 600
 - 3: ICM32 with ICAD 600
 - 4: ICM40 with ICAD 900
 - 5: ICM50 with ICAD 900
 - 6: ICM65 with ICAD 900
15. Press the “Circle” button.

The valve is now ready to be used.

ENGINEERING
TOMORROW



Quick Start Guide

ICM/ICAD Motorized Valves
Installation, Programming, and Troubleshooting



- The ICM motorized valve is comprised of up to 4 components:
- the valve body – often referred to as the ICV body because it is used for ICM motor valves, ICS pilot operated valves and ICLX solenoid valves.
 - the function module – the flow regulating part of the valve
 - the top cover – on the ICM 20 through 65, the function module and top cover are one part
 - the ICAD motor actuator – the “brains” of the valve

ICM/ICAD overview

The combinations of valve and actuator are as follows:

Actuator	ICAD 600A	ICAD 1200A	Old ICAD 600*	Old ICAD 900*	Old ICAD 1200*
Valve Size	ICM 20	ICM 40	ICM 20	ICM 40	ICM 40
Valve Size	ICM 25	ICM 50	ICM 25	ICM 50	ICM 50
Valve Size	ICM 32	ICM 65	ICM 32	ICM 65	ICM 65
Valve Size		ICM 100			ICM 100
Valve Size		ICM 125			ICM 125
Valve Size		ICM 150			ICM 150

* ICAD 600, 900 and 1200 were discontinued at the end of 2014. ICAD 600A is a direct replacement of ICAD 600 and ICAD 1200A is a direct replacement of ICAD 900 or ICAD 1200.



Contents	Page
ICM/ICAD overview	1
Identifying ICM sizes	3
1 st and 2 nd generation ICAD differences	4
Installation	5
Wiring the ICAD actuator	7
Electrical data	7
ICAD Programming	11
Pre-start up checklist	13
Troubleshooting	
Overview	14
Service parameters	14
Alarms	14
Tips	15
Frequently asked questions	16

Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Identifying ICM sizes

All ICM sizes except ICM 20 have a stainless steel ID tag located around the valve stem on the top cover which the ICAD mounts on. When the ICAD is mounted it can be difficult to locate this. The sticker on the valve body of the large valves states ICM and the valve size because the body is shared between the ICM motor valves, ICS pilot operated valves and ICLX solenoid valves.


The ICM size is the same size as the ICM size which is needed during programming. ICM 20 only has a sticker on the side of the valve body to identify the size.

If the sticker is missing the size can be identified by the shape of the cone. The below figure shows how to identify the ICM 20 size by looking at the cone.

Different ICM 20 cone and orifice designs




ICM20-A33
A33 has a groove here for identification




ICM20-A (2nd gen.)
Introduced mid 2009



ICM20-A (1st gen.)
Discontinued mid 2009



ICM20-B66
Introduced Jan. 2011



ICM20-B



ICM20-C

Note:
The outside edges of the B66 cone has more of a cylindrical shape compared to the B cone which forms more of a conical shape.

ICM 20 orifice (valve seat)



ICM 20-A33
ICM 20-A (2nd gen.)



ICM 20-A (1st gen.), ICM 20-B,
ICM 20-B66, ICM 20-C





Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Differences between 1st and 2nd generation ICAD motor actuators

The 2nd generation ICAD was released in the beginning of 2010. The part numbers on the label for the 2nd generation start with 027H9... and the 1st generation part numbers started with 027H12... The cables of the 1st generation were mounted through cable glands located in the plastic top whereas the 2nd generation has the cables mounted on connectors located in the aluminum body.

Note: The wire colors are different between the two generations and the following is a table with the differences and pictures of old and new generation.


		1 st Generation ICAD	2 nd Generation ICAD
			
Power cable (3-wire)	+ 19-24 V d.c. fail safe supply	White (+)	Black (+)
	+ 24 V d.c.	Brown (+)	White (+)
	- 24 C d.c. (GND)	Green (-)	Brown (-)
Communication cable (7-wire)	Digital output (common alarm)	White (-)	Black (-)
	Digital output (ICM fully open)	Brown (-)	Brown (-)
	Digital output (ICM fully closed)	Green (-)	Red (-)
	GND - ground	Yellow (-)	Orange (-)
	Analog input (0/4-20 mA)	Grey (+)	Yellow (+)
	Analog input 0/2-10 V / Digital ON/OFF input	Pink (+)	Green (+)
	Analog output 0/4-20 mA	Blue (+)	Blue (+)



Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting


Installation

1. All ICM valves and ICAD motor actuators must be installed in horizontal pipelines with the motor actuator in an upright position.
2. Preparation of Valve Body
 ICM 20 (3/4") valves: both the integrated bonnet/function module and the separate valve seat must be removed from the valve body prior to welding. To remove the ICM20-A33 or ICM20-A valve seat use a 13mm socket and to remove the ICM20-B66, ICM 20-B or ICM20-C valve seat, use a 12 mm hex key.
 - ICM 25 to 65 (1" to 2-1/2") valves, the integrated bonnet and function module should be removed as shown in the figure.
 - ICM 100 to 150 (4" to 6") valves, the function module and bonnet are separate pieces and do not need to be removed prior to welding. However, some form of arc welding should be used to weld the valve into the piping and care should be taken to protect the valve stem from becoming contaminated.



Removing the bonnet/function module from the body of the ICM 25 to 65 valves.

No.	Part
1	Housing
2	Top cover / function module
2a	O-ring
2b	O-ring
2c	O-ring
4	Gasket
4a	Gasket
5	Bolts
11	Actuator
12	O-ring
13	O-ring
14	Seat





Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Installation (continued)

Care should be taken to protect the ICM function module when it is removed and stored during installation of valve body.

3. Weld the valve body in line making sure that the arrow on the valve body is pointing in the direction of flow.
 - For ICM 20 through 65, make sure that all debris is removed from valve body before bonnet/ function module is re-installed.
 - For the ICM 20, make sure that the removable orifice seat is re-installed in the valve body with the small o-ring between the orifice seat and the body. Use a 13mm socket to tighten the ICM20-A33 or ICM20-A valve seat to a torque of 6.5 ft-lbs (9 N-m). Use a 12 mm hex key to tighten the ICM 20-B66, ICM20-B or ICM20-C valve seat to a torque of 1.5 ft-lbs (2 Nm).
DO NOT OVERTIGHTEN THE REMOVABLE SEAT.
Make sure that the bonnet gasket is installed and in good condition.
 - For the ICM 25 through ICM 65, check that the two o-rings are installed on the function module and that the gasket located on the top of the valve body is installed and all are in good condition.
A light coating of refrigerant oil on the bonnet o-rings and the cover gasket will facilitate assembly of the valve.

4. Install the bolts and torque to the following specifications:

Valve Body	Nm	ft lbs
ICM 20	40	29
ICM 25	100	74
ICM 32	120	88
ICM 40	120	88
ICM 50	140	103
ICM 65	150	110
ICM 100 through 150	220	162

5. Install the ICAD Motor on the ICM valve:

The ICM valve must not be in its full opened position while the ICAD motor is calibrated with the valve (at a later step). Therefore, if the opening degree of the ICM valve was changed from the factory setting, it should be set to an opening degree between 0% and 75% using the manual magnet tool. To easily ensure correct positioning, turn the manual tool counter-clockwise until it is clear that it cannot be turned any further.

 - Make sure that the ICM adapter/valve stem and inner ICAD magnets are completely dry and free from any debris.
 - The ICM adapter O-ring (position 2c in the diagram on page 5) must be removed and Molycote 55 grease (supplied with ICAD motor) needs to be applied in the O-ring groove on the adapter and on the O-ring before it is re-installed on the ICM adapter.
The Molycote grease ensures a good seal between the ICAD motor and the ICM adapter to prevent moisture from entering the ICAD magnets.
 - Place the ICAD motor on the valve stem.
 - Push the ICAD motor completely down to the identification ring on the valve stem. Using a 2.5 mm hex key, tighten the set screws evenly so the ICAD motor is centered on the ICM valve stem. Torque the set screws to approximately 3 Nm (2.5 ft-lbs).

Appendix D • Liquid Injection Valve Setup Instructions and Quick Start Guide



Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Electrical data

Supply voltage is galvanically isolated from input and output wires

Supply Voltage
24 VDC + 10%/-15%

Fail Safe Supply
Min. 19 VDC

Load ICAD 600A 1.2 A
ICAD 1200A 2.0 A

ICAD 600A 1.2 A
ICAD 1200A 2.0 A

Analog Input – Current or Voltage

Current 0/4 – 20 mA
Load: 200Ω

Analog Output

0/4 – 20 mA
Load: ≤ 250 Ω

Voltage 0/2 – 10 VDC
Load: 10k Ω

Digital Input – Digital On/Off input by means of voltfree contact with gold-plated contacts recommended

Voltage Input Used

ON: contact impedance < 50 Ω

OFF: contact impedance > 100 k Ω

Digital Output: 3 pcs. NPN transistor output


External Supply: 5 – 24 VDC (same supply as for ICAD can be used but note that galvanically isolated system will be spoiled.

Output Load: 50 Ω

Load Max. 50 mA

Wiring the ICAD actuator

There are two cables which are connected to the ICAD motor with M12 connectors:



Communication connector / cable

Ref.	Color		Description
A	Black	–	Common Alarm
B	Brown	–	ICM fully open
C	Red	–	ICM fully closed
D	Orange	–	GND ground
E	Yellow	+	0/4 - 20 mA Input*
F	Green	+	0/2 - 10 V Input. Also used with GND (orange wire) as a digital input #1 for on-off operation or floating 3-point control
G	Blue	+	0/4 - 20 mA Output*

} Digital Output

Power connector/cable (3 wires)

I	Black	+	Fail safe supply Battery / UPS (uninterruptable power supply) 19 V d.c.
II	White	+	Supply voltage
III	Brown	–	24 V d.c.

* If using floating 3-point control (parameter i02=3) then wire colors yellow and blue are combined to make the 2nd digital input

Appendix D • Liquid Injection Valve Setup Instructions and Quick Start Guide




Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Wiring the ICAD actuator


Wiring diagram showing ICAD wired to a PLC or other type of third party electronics

Note: The ICAD supplies the power for the 4-20 mA feedback signal.



Wiring diagram showing ICAD wired to a Danfoss EKC controller

Note: For instructions on completely wiring an EKC controller, please see the relevant EKC controller manual.






Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Wiring the ICAD actuator continued

Wiring diagram showing ICAD wired to a Danfoss EKE controller

Note: For instructions on completely wiring an EKE controller, please see the relevant EKE controller manual.







Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Wiring the ICAD actuator continued


Wiring diagram showing ICAD wired with one digital input for ON/OFF solenoid valve operation
Note: The ICAD motor can be programmed to open or close when the relay is closed. See parameter i09 in programming section.



Wiring diagram for floating 3-point control (open-neutral-close)



Wiring diagram showing ICAD digital outputs wired with customer supplied auxiliary relays
NOTE: The same 24 V d.c. power that powers the ICAD can be used with the ICAD digital outputs to power auxiliary relays (or other small load devices) but the system will no longer be galvanically isolated.






Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

ICAD overview

1. All ICAD actuators are digital stepper motors. As the control signal changes ICAD will electronically count steps up or down from its previous position. The ICAD 600A, ICAD 1200 and 1200A have an optical encoder which will actually measure the steps to recalibrate while operating if needed. In all cases, the ICAD actuators will recalibrate every time that power is cut and then reconnected. Recalibration is also accomplished when the valve is driven closed, the ICAD will take an extra closing step to make sure it is completely closed and start counting from 0 again.
2. The ICAD actuators can also be put into manual mode by using parameter **i01**. Once the parameter has been selected and the manual mode entered, the valve can be opened and closed independent of the control signal. When in the manual mode, the display screen will flash the opening degree and continue to flash until the parameter is restored to its normal operation setting.
3. The ICAD actuator can be controlled with an analog input for modulating control, 1 digital input for open/close solenoid function or with 2 digital inputs for floating 3-point control (open-neutral-close). The speed of the ICAD can be altered (see parameters **i04** and **i14**).
4. The ICAD display will continuously display the ICM valve opening degree in % unless there is an alarm or the parameter list is being viewed. The display will also indicate **Mod** if being controlled by an analog input signal (modulating mode) or if being controlled by digital inputs the display will indicate **Low**, **Med** or **High** depending on the speed setting.
5. The ICAD actuator can be connected to a 24 V d.c. UPS (uninterruptable power supply) and can be programmed for a specific action in the event of a disruption to the normal power supply (see parameters **i07**, **i08** and **i12**). Please note that the UPS provides a discrete short term action in the event of a power failure. It cannot be used for normal operation.
6. The ICAD actuator also has an inverse function (see parameter **i13**). This feature allows the valve to either open or close on a rising analog signal.

Operation the ICAD menu

1. To access the ICAD actuator menu, press and hold the middle button (2) until the menu appears.



2. Once you are in the menu, use the UP (3) and DOWN (1) arrows to move through the list of parameters.
3. To display and/or change the value of the parameter, press the middle button (2) to view the current settings.
 - a) To change the value of a parameter, use the up or down arrow to establish the new value for that parameter.
 - b) Once the new value for the parameter has been selected, press the middle button to save the change and return to the menu.
4. Repeat this procedure for all parameters.
5. Exit from the parameter list by pressing and holding the middle button for 2 seconds or simply wait for the ICAD to return to the main display (approx. 20 seconds).



Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Programming the ICAD actuator

When the ICAD actuator is first powered on, the ICAD display will flash an A1 alarm. This alarm is a reminder that the ICM valve being moved by the ICAD has not been selected in parameter **i26**. Parameter **i26** is password protected and will not appear in the parameter list until the user enters the password in parameter **i10**. The password is "11" and will allow the user to access parameter **i26** where the appropriate valve size can be selected. Once the ICM valve size is selected (see page 3 on how to identify ICM size), the ICAD actuator will calibrate itself to that particular size and will then be ready to receive a control signal.

Description	ICAD parameter	Min	Max	Factory Setting	Stored	Unit	Password	Comments
OD (Opening degree)	-	0	100			%	-	ICM/ICMSTS valve Opening Degree (CVE pressure setting) is displayed during normal operation. Running display value (see i01 , i05).
Main Switch	i01	1	2	1	✓	-	No	Internal main switch 1: Normal operation 2: Manual operation. Valve Opening Degree will be flashing. With the down arrow and the up arrow push buttons the OD can be entered manually.
Mode	i02	1	2	1	✓	-	No	Operation mode 1: Modulating – ICM, ICMSTS & CVE positioning according to Analog Input (see i03) 2: ON/OFF - ICM only. Operating the ICM valve like an ON/OFF solenoid valve controlled via Digital Input. See also i09 . 3: Neutralzone / 3 point control - ICM only. Increase/Decrease Opening Degree by Digital Input. See fig. 9
AI signal	i03	1	4	2	✓	-	No	Type of AI signal from external controller 1: 0 – 20 mA 2: 4 – 20 mA 3: 0 – 10 V 4: 2 – 10 V
Speed In Modulating Mode Opening/closing speed In ON/OFF Mode Opening speed In Neutralzone/ 3 point control Opening speed = 10	i04	1	100	50/ 100	✓	-	No	Speed can be decreased. Max. speed is 100 % - Not active in manual operation (i01 = 2) For CVE the speed should not exceed 50 (factory setting) If i26 = 1 - 3 then factory setting = 100 If i26 = 4 - 10 then factory setting = 50 If the valve is opening and (i04 <= 33) or the valve is closing and (i14 <= 33) => Low is displayed. If the valve is opening and (33 < i04 <= 66) or the valve is closing and (33 < i14 <= 66) => Med is displayed. If the valve is opening and (i04 >= 67) or the valve is closing and (i14 >= 67) => High is displayed"
Automatic calibration	i05	0	2	0		-	No	Not active before i26 has been operated. Always auto reset to 0. CA will flash in the display during calibration, if Enter push button has been activated for two seconds 0: No Calibration 1: Normal forced calibration - CA flashing slowly 2: Extended calibration – CA flashing rapidly"
AO signal	i06	0	2	2	✓	-	No	Type of AO signal for ICM valve position 0: No signal 1: 0 – 20 mA 2: 4 – 20 mA
Failsafe	i07	1	4	1	✓	-	No	Define condition at power cut and fail safe supply is installed. 1: Close valve 2: Open Valve 3: Maintain valve position 4: Go to OD given by i12 "
Fail safe supply	i08	0	1	0	✓		Yes	Fail safe supply connected and enable of A4 alarm: 0: No 1: Yes
DI function	i09	1	2	1	✓		No	Define function when DI is ON (short circuited DI terminals) when i02 = 2 1: Open ICM valve (DI = OFF => Close ICM valve) 2: Close ICM valve (DI = OFF => Open ICM valve)
Password	i10	0	199	0		-	-	Enter number to access password protected parameters: i26 Password = 11
Old Alarms	i11	A1	A99	-		-	No	Old alarms will be listed with the latest shown first. Alarm list can be reset by means of activating down arrow and up arrow at the same time for 2 seconds.
OD at power cut.	i12	0	100	50	✓		No	Only active if i07 = 4 If fail safe supply is connected and power cut occurs, the valve will go to the specified OD.
Inverse operation	i13	0	1	0	✓		No	When i02 = 1 0: Increasing Analog Input signal => Increasing ICM Opening Degree 1: Increasing Analog Input signal => Decreasing ICM Opening Degree When i02 = 3 0: DI1 = ON, DI2 = OFF => Increasing valve Opening Degree. DI1 = OFF, DI2 = ON => Decreasing valve Opening Degree DI1 = DI2 = OFF => ICAD/ICM maintain current position DI1 = DI2 = ON => ICAD/ICM maintain current position 1: DI1 = ON, DI2 = OFF => Decreasing ICM Opening Degree DI1 = OFF, DI2 = ON => Increasing ICM Opening Degree DI1 = DI2 = OFF => ICAD/ICM maintain current position DI1 = DI2 = ON => ICAD/ICM maintain current position

Appendix D • Liquid Injection Valve Setup Instructions and Quick Start Guide



Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Parameter list (continued)

Description	ICAD parameter	Min	Max	Factory Setting	Stored	Unit	Password	Comments
In ON/OFF Mode Closing speed In Neutralzone/ 3 point control Closing speed = 10	i14	0	100	50/100	✓	-	No	See i04. Not applicable to CVE If i26= 1 - 3 then factory setting = 100 If i26= 4 - 10 then factory setting = 50
Manual set point	i15	0	100	0		-	No	When i01= 2, i15 determine the start up value
Encoder operation	i16	0	1	1	✓	-	Yes	NB: Password protected. Password = 7 0: Encoder disabled. Means ICAD operation as ICAD 600A/ICAD 600A-TS/1200A without encoder. 1: Encoder enabled
Forced closing when ICM valve Opening Degree < 3%	i17	0	1	0	✓	-	No	Enable/Disable forced closing. Not applicable to CVE 0: When ICM valve Opening Degree < 3% it will be forced to close regardless of requested ICM valve Opening Degree 1: When ICM valve Opening Degree < 3% no forced to closing will take place
Action when ICAD is losing step See Note 1	i18	0	6	6	✓	-	No	Action when ICAD is losing step. 0: A boost starts if lost step is detected. After 15 sec, the A9 alarm is flashing and DO A Common Alarm is ON. A second boost starts after the time in i19 has elapsed. If the second boost cyklus does not bring the valve back in operation a forced calibration is carried out. 3: A9 alarm flashing after 15 sec. DO A Common Alarm ON. ICAD is locked in actual position. No boost cyklus, Reset by Power OFF/ON, regardless of setting i21 6: Boost cyklus starts if lost step is detected. After 3 boost cyklus the A9 alarm is flashing and DO A Common Alarm is ON. Time interval between boost is set in i19. The boost cyklus continues until the valve is back in operation.
Delay after boost, before A9 alarm See Note 1	i19	0	30	1	✓	Minutes	No	Time delay between two boosts. Linked to i18 function
Max offset value See Note 1	i20	3	15	3	✓	%	Yes	Password=13. Offset value (numeric)=Requested Opening Degree [%] from Analog Input - Opening Degree [%] from encoder (Used with i21)
Define how to Reset/ Suppress A9 alarm See Note 1	i21	0	4	1	✓	-	No	Define how to Reset/Suppress A9 alarm. A9 alarm means A9 flashing in display and DO Common Alarm ON 0: Reset by Power OFF/ON 1: Autoreset when ICAD have succeeded to come back into normal operation. Normal operation defined as: Offset value < i20 (Max offset value) and i22 (delay) has elapsed. 2: A9 alarm is suppressed, meaning no A9 flashing in display and DO Common Alarm remains OFF
Reset delay for A9 See Note 1	i22	1	20	5	✓	Minutes	No	Reset delay for A9. Use when i21= 1 OBSERVE: i22 is recommended always to be bigger than i19 (i22>i19)
Valve configuration	i26	0	9	0	✓	-	Yes	NB: Password protected. Password = 11 0: No valve selected. Alarm A1 will become active 1: ICM 20 with ICAD 600A / ICMTS 20 with ICAD 600A-TS 2: ICM 25 with ICAD 600A 3: ICM 32 with ICAD 600A 4: ICM 40 with ICAD 1200A 5: ICM 50 with ICAD 1200A 6: ICM 65 with ICAD 1200A 7: ICM 100 with ICAD 1200A 8: ICM 125 with ICAD 1200A 9: ICM 150 with ICAD 1200A 10: CVE pilot with ICAD 1200A
Running current factor	i30	0	20	10	✓	-	Yes	Password=19. Mandatory to set, if ICM/ICADs are installed/serviced, with cold liquid (-30 °C (-22 °F) or lower) passing through ICM valve. See also document number AN285243155312
Holding current factor	i31	0	20	10	✓	-	Yes	

Note 1:
After a parameter change, it is necessary to carry out a Power OFF/ON

Appendix D • Liquid Injection Valve Setup Instructions and Quick Start Guide



Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

It is possible to **restore the original factory settings** to the ICAD by the following procedure:

1. Remove the power supply.
2. Activate the up arrow and the down arrow push buttons at the same time.
3. While pushing the up and down arrows, reconnect the power supply.
4. Release the up and down arrows.
5. When the display on the ICAD is alternating between CA and AI, the factory parameters have been restored.

Pre-startup Checklist

- Valve Assembly
 - Bonnet bolts are secure
 - Seat has been replaced in body (ICM 20)
 - The degree of opening of the valve is 75% or less
 - Grease has been applied to o-ring area on valve stem
 - Set screws have been uniformly tightened on ICAD Actuator
 - Power has been connected to actuator (24 V d.c.)
 - Back up power (UPS) has been connected to actuator (optional)
 - Control Wiring has been connected
 - Signal input: digital or analog
 - Feedback wiring (optional)
 - Programming (mandatory parameters)
 - The mode of operation has been set (i02)
 - The input signal type has been set (i03)
 - The ICM valve size has been set (i26)
- Battery back-up (optional) parameters have been established (i07, i08, i12)

Troubleshooting

Overview



The ICAD actuator has a number of very useful service parameters which should always be consulted first. In addition, a manual tool should always be available to manually close the valve completely in the event the ICAD has failed. When using the manual tool, turn the tool clockwise to open the valve and counter-clockwise to close the valve.

NOTE:

When rotating the valve manually you are changing the position of the valve to a value different than what is in the actuator's memory. Therefore, a calibration must be performed when ICAD is remounted to the valve. If power is cut from the actuator prior to using the manual tool or after the valve has been adjusted, no problem will occur as the valve will automatically recalibrate itself once power is restored. Power can easily be disconnected and reconnected by unscrewing and then reconnecting the power cable from the ICAD actuator.

Service parameter (View only)

Service

Description	ICAD parameter	Min	Max	Factory Setting	Stored	Unit	Password	Comments
OD %	i50	0	100	-		%	-	ICM valve Opening Degree / CVE pressure setting
AI [mA]	i51	0	100	-		mA	-	AI signal
AI [V]	i52	0	100	-		V	-	AI signal
AO [mA]	i53	0	100	-		mA	-	A0 signal
DI	i54	0	1	-		-	-	DI signals. Depending of i02 If i02 = 2, one digits are shown. See fig. 8 0 : DI1 = OFF 1 : DI1 = ON If i02 = 3, two digits are shown. See fig. 9 00 : DI1 = OFF, DI2 = OFF 10 : DI1 = ON, DI2 = OFF 01 : DI1 = OFF, DI2 = ON 11 : DI1 = ON, DI2 = ON
DO Close	i55	0	1	-		-	-	DO Closed status. ON when OD < 3 %
DO Open	i56	0	1	-		-	-	DO Open status. ON when OD > 97 %
DO Alarm	i57	0	1	-		-	-	DO alarm status. ON when a Alarm is detected
Display mP SW ver.	i58	0	100	-		-	-	Software version for display microprocessor
Motor mP SW ver.	i59	0	100	-		-	-	Software version for motor microprocessor



Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Alarms

Description	ICAD alarm text	Definition of event	Comments
No Valve type selected	A1	Alarm ON	At start-up A1 will be displayed
Controller fault	A2	Alarm ON	Internal fault inside electronics. Carry out: 1) Power OFF and Power ON If A2 still active. 2) Make a Reset to factory setting If A2 still active. Return ICAD to Danfoss
AI input error	A3	Alarm ON	Not active if i01 = 2, or i02 = 2 When i03 = 1 and AI A > 22 mA When i03 = 2 and AI A > 22 mA or AI A < 2 mA When i03 = 3 and AI A > 12 V When i03 = 4 and AI A > 12 V or AI A < 1 V
Low voltage of fail safe Supply	A4	Alarm ON	If 5 V < fail safe supply <18 V. Enabled by i08
Check supply to ICAD	A5	Alarm ON	If supply voltage < 18 V
Calibration extended failed	A6	Alarm ON	Check valve type selected. Check presence of foreign body internally in valve
Internal temperature alarm	A7	Alarm ON	Temperature for stepper motor component too high. Ventilate/lower ambient ICAD temperature
	A8	Alarm ON	Temperature for stepper motor component too high. Ventilate/lower ambient ICAD temperature.
POM mode (Preventive Operational Mode) Note: old alarms that may not be active anymore will be saved and listed in parameter i11	A9	See i18 and i21	Only active if i16 = 1 If ICAD meets too high torque from ICM valve (increased friction/sticking surfaces) ICAD automatic goes into POM mode to overcome lost step. (See i18 and i21)

Troubleshooting continued

The alarms and service values work together to allow the user to quickly diagnose the source of operating issues. The most common alarms are:

- A1** The user has not selected the valve type. Each ICAD actuator is capable of driving several different valve sizes. Upon installation of the valve, it is mandatory that the user select the valve size from parameter **i26**.
- A3** The control signal is out of the range of the selected values. The most common causes of this problem are:
 1. Improper wiring
 2. Incorrect selection of control signal (parameter **i03**)
 3. The source of the control signal is not outputting the correct type of signal.
- A9** The valve is locked, disconnect and remove motor. Use magnetic tool to slowly open/close the valve thru the full range. There should be at no point a sticking/tight spot. You may need to remove the valve bonnet/module to clean debris or replace the bonnet/module if it is damaged. If A9 alarm continues please contact Danfoss with application details.

Of course, there are numerous other alarm messages designed to protect the equipment and help to diagnose problems as pro-actively as possible. Most of these alarms are fairly self-explanatory.

Troubleshooting Tips

The valve does not appear to close or stay closed completely.

- The display shows 0% opening degree but the valve can be driven further closed with the manual tool.
Solution: Recalibrate the valve. In addition, if the manual tool has been used to open or close the valve, the valve should turn very easily. If there appears to be resistance in opening or closing the valve, replace the module.
- The display shows 0% opening degree and the valve cannot be driven closed any further with the manual tool.
Solution: Pull the function module and check to ensure that there are 2 o-rings on the module for ICM 25 and larger. For size ICM 20, make sure valve seat is installed.



Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

Troubleshooting Tips

The valve does not appear to be moving to the correct position.

- Check service value ;51. This is the mA input from the control system. The degree of opening is linearly proportional to the mA input. (For example, if 4-20 mA was chosen as the input range and the service value shows 12mA, the valve should be 50% open.)
Solution: Check parameter ;03 to make sure that the correct scale was selected.
- Compare service value ;51 to the value reported to be the output from the control system. If necessary, measure the actual current into the ICAD.
Solution: If the two values do not equate, check wiring, paying special attention to wire polarity. If measured mA does not equate to the stated controllers output, the problem is likely to be in the control system. If measured mA does not equate to the value seen in ;51 and everything is wired properly, the problem is likely with the ICAD actuator.
- The ICAD was not mounted properly on the valve stem.
Solution: Check to make sure that the ICAD set screws are evenly torqued around the base of the ICAD.

The valve does not appear to be opening fast enough or seems too fast

- The speed of the ICM valves are preset at the factory:
 - For ICM valves 20, 25, and 32, the preset speed is 100%
 - For ICM valves 40, 50, 65, 100, 125, and 150, the preset speed is 50%

Solution: Check parameter ;04 to note the actual setting and adjust accordingly

The valve position feedback signal is not working with the customer supplied controller/PLC.

- A power supply was installed in the 4-20mA/0-20 mA feedback loop. The ICAD motor actuator supplies power for the 4-20mA/0-20 mA feedback loop.
Solution: Remove any power source that may be supplied to the feedback loop.
- Wiring problem.
Solution: Check the service value of ;53 (the analog output signal) to see what the ICAD is outputting. If nothing is revealed, check the output wire (blue) with an ammeter to verify the actual output value.
- The feedback output signal was not turned on in parameter ;06.
Solution: Change this parameter to the appropriate signal.

Frequently Asked Questions

What happens in the event of a power failure?

The ICAD actuator will remain in the position it is in when power is lost. There are two approaches to solving the issue:

- Add a UPS (Uninterruptible Power Supply) device to the power wiring. This is easily accomplished with the brown (-) and black (+) wires in the power cable bundle. A UPS device is available from Danfoss and can provide up to 10 amps of power for up to 90 seconds in order to move the valve to the desired position. Because of the high amperage, the UPS is capable of providing power to several ICAD actuators depending on the size of the actuator. NOTE: The UPS is not a continuous power supply. It is only meant to change the valve position once in the event of a power failure.
- Add a solenoid valve in front of the ICM in order to stop refrigerant flow. This is a simple solution provided that there is no issue associated with the additional pressure drop through the solenoid valve.

How much power do I need to supply to the ICAD?

The total power required depends on the ICAD size and the number of ICAD's powered by the dc power supply. The power for each ICAD is:

- ICAD 600 (ICM 20, 25, and 32), the requirement per valve is approximately 30 watts.
- ICAD 900 (ICM 40, 50, and 65), the requirement per valve is approximately 50 watts.
- ICAD 1200 (ICM 100, 125, and 150) the requirement per valve is approximately 75 watts.
- ICAD 600A (ICM 20, 25, and 32), the requirement per valve is approximately 30 watts.
- ICAD 1200A (ICM 40, 50, 65, 100, 125, and 150) the requirement per valve is approximately 50 watts.

How can I monitor the valve position remotely?

The control wiring bundle provides for a 4 to 20 mA or 0 to 20 mA signal output with the blue (+) and orange (-) wires. The signal can be sent to:

- A remote display
- A PLC or PC
- Another ICAD actuator to provide the same input signal (daisy chain)

At what minimum OD%/mA will the ICAD automatically close and calibrate?

The ICAD will automatically close or be closed when the opening degree is below 3% which corresponds to 4.48 mA. After it is closed it will give a few extra steps to calibrate the valve.

If the 4-20mA signal is lost while the valve is open, will the ICAD close the valve?

Yes, if the input signal is lost while the valve is open, the ICAD will close the valve and flash an A3 alarm which is for an input error.



Quick Start Guide | ICM/ICAD Motorized Valves - Installation, Programming, and Troubleshooting

How many turns/revolutions with the manual tool will fully open/close ICM valve?

- ICM 20: 1.25 turns
- ICM 25: 2.5 turns
- ICM 32: 3 turns
- ICM 40: 4 turns
- ICM 50: 5 turns
- ICM 65: 5 turns
- ICM 100: 12.75 turns
- ICM 125: 15.25 turns
- ICM 150: 18.25 turns

Does the ICAD make a high frequency noise?

Yes, when the ICAD is at standstill, it will generate a high frequency noise which is normal.

What size wire gauge is recommended to run to the ICADs?

The typical wire gauge is 22 AWG. For power wiring, the recommended maximum lengths (for 22 AWG) are:

- ICAD 600 90 feet
- ICAD 900 50 feet
- ICAD 1200 30 feet
- ICAD 600A 90 feet
- ICAD 1200A 50 feet

Heavier wire gauge will allow for longer lengths of power wiring. For example with 17 AWG, maximum lengths are:

- ICAD 600 285 feet
- ICAD 900 170 feet
- ICAD 1200 115 feet
- ICAD 600A 285 feet
- ICAD 1200A 170 feet

Control wire lengths can be as long as 1500 feet.

When running wire to the ICADs, does the wire need to be shielded?

There is no need for shielded cable; however, if used, the EMC capabilities of the ICAD will be improved.

Appendix E

Liquid Injection Valve Station ICF 20-25 Installation Guide











Installation guide

Valve Station


Types ICF 15, ICF 20, ICF 25, ICF SS 20 and ICF SS 25




027R9782								027D0782							
Installation Installation Installation Instalación Instalação Montaż Монтаж 安装															
<p>ICF xx-2</p>  <p>1a</p>				<p>ICF xx-4</p>  <p>1b</p>				<p>ICF xx-6</p>  <p>1c</p>				<p>ICF xx-2 / ICF xx-4 / ICF xx-6 + ICM/ICFD/ICFG</p>  <p>1d</p>			
Welding Schweißen Soudure Soldadura Soldagem Spawanie Сварка 焊接															
<p>TIG/MIG/SMAW</p>  <p>2</p>								<p>Gas welding Gasschweißen Soudure au gaz Soldadura con gas Soldagem a gás Spawanie gazowe Газовая сварка 气焊</p>  <p>3a</p>							
Brazing Lötén Brasage Soldadura Brasagem Lutowanie twarde Пайка 钎焊															
 <p>3b</p>				 <p>3c</p>				<p>Ag40 Minimum 450–700 °C Ag40 Minimum 450 – 700 °C Minimum Ag40 450 – 700 °C Ag40 mínimo 450 – 700 °C Mínimo de Ag40 a 450 – 700 °C Ag40, minimum 450 – 700 °C Ag40, не менее 450 – 700 °C Ag40 最低 450 – 700 °C</p>							

Maintenance | Instandhaltung | Maintenance | Mantenimiento |
Manutenção | Servis | Техническое обслуживание | 维护


ICF 15, ICF 20, ICF SS 20, ICF 25, ICF SS 25



4a



4b


Tightening Drehmoment Serrage Par de apriete Aperto Dokręcenie Затяжка 紧固							
		M1	M2	M3	M4	M5	M6
	ICF 15	22 Nm (16 ft lbs)	22 Nm (16 ft lbs)	35 Nm (25.8 ft lbs)	35 Nm (25.8 ft lbs)		
	ICF 20 ICF SS 20	35 Nm (25.8 ft lbs)	35 Nm (25.8 ft lbs)	35 Nm (25.8 ft lbs)	35 Nm (25.8 ft lbs)	35 Nm (25.8 ft lbs)	35 Nm (25.8 ft lbs)
	ICF 25	60 Nm (44 ft lbs)	60 Nm (44 ft lbs)	60 Nm (44 ft lbs)	60 Nm (44 ft lbs)	60 Nm (44 ft lbs)	60 Nm (44 ft lbs)
	ICF SS 25	80 Nm (58 ft lbs)	80 Nm (58 ft lbs)	80 Nm (58 ft lbs)	80 Nm (58 ft lbs)	80 Nm (58 ft lbs)	80 Nm (58 ft lbs)
	ICF 15-25			60 Nm (44 ft lbs)			
ICF SS 20-25			80 Nm (58 ft lbs)				

5


ICF 15, ICF 20, ICF SS 20 Manual stem | Handbetätigung | Tige manuelle | Vástago manual |
Operação manual | Wrzeciono obsługi ręcznej | Ручное управление | 手动阀杆

</


ICFE 25, ICFE SS 25, ICFG 25, ICFE 20H, ICFE SS 20H Manual stem | Handbetätigung | Tige manuelle | Vástago manual |
Operação manual | Wrzeciono obsługi ręcznej | Ручное управление | 手动阀杆




Module location | Moduleinbauort | Emplacement des modules | Ubicación de los módulos |
Localização do módulo | Usytuowanie modułu | Расположение модуля | 模块位置



ICFD: Disassembly/assembly Transport device and float | ICFD: Entfernen der Transportsicherung und Demontage/Montage des Schwimmers |
ICFD: Démontage/montage Dispositif de transport et flotteur | ICFD: Desmontaje/montaje de dispositivo de transporte y flotador |
ICFD: Desmontagem/montagem Dispositivo de transporte e flutuador | ICFD: Demontaż/Montaż zabezpieczenia transportowego i pływaka |
ICFD: Разборка/сборка. Транспортировочное устройство и поплавков | ICFD: 针对阀门和浮球的运输, 拆卸/安装



ICFG 25: Disassembly/assembly module | ICFG 25: Demontage und montage des modules | ICFG 25: Démontage/montage du module | ICFG 25: Desmontaje/montaje del módulo | ICFG 25: Desmontagem/montagem Módulo | ICFG 25: Demontaž/Montaž modulu | ICFG 25: Раборка/сборка модуля | ICFG 25: 拆卸/安装模块



ENGLISH

Refrigerants

Applicable to HCFC, non flammable HFC, R717 (Ammonia) and R744 (CO₂).

Exception:

ICFD is designed for ammonia and CO₂ only
ICFD 20 = ammonia version
ICFD 20C = CO₂ version

The use of ICF valve stations with flammable hydrocarbons is not recommended.

The ICF is only recommended for use in closed circuits. For further information please contact Danfoss.

Temperature range

ICF in general:
-60/+120 °C (-76/+248 °F)

ICFD 20: -50/+50 °C (-58/+122 °F) at 28 bar g (406 psi g)

ICFD 20C: -50/+50 °C (-58/+122 °F) at 52 bar g (754 psi g)

Pressure range

The general ICF is designed for:
Max. working pressure: 52 bar g (754 psi g)
ICF 20-2 housing with 65 bar function modules only:
Max. working pressure: 65 bar g (943 psi g)

ICFD 20 (Ammonia):

For ICF with ICFD module the max. working pressure is 28 bar g / 406 psi g. If the refrigeration system include ICFD 20 module, a test pressure of the system must not exceed 28 bar g / 406 psi g, unless the ICFD float is temporarily taken out before test. See fig. 11.

ICFD 20C (CO₂):

For ICF with ICFD 20C module the max. working pressure is 52 bar g / 754 psi g. If the refrigeration system include ICFD 20C module, a test pressure of the system must not exceed 52 bar g / 754 psi g, unless the ICFD 20C float is temporarily taken out before test. See fig. 11.

Application

The ICF can be used in suction, liquid, hotgas

and liquid/vapor lines. The ICF is available with 2, 4 or 6 function modules. The ICF regulates the flow of the medium by modulation or on/off function, depending on function modules installed in the ICF.

Regulating range

Dependent on the chosen type and combination of modules installed in the valve.

Installation (fig. 1)

The ICF must be installed according to fig. 1. The ICF must be installed with the arrow in the direction of the flow).

ICM, ICFD and ICFG modules require horizontal valve orientation.

The ICF will be delivered with all the function modules fully assembled. The modules can be taken out for service or inspection and may be rotated 4 x 90° in relation to the valve body upon installation. Please make sure that the position of ICFD allows space for modules at each side of the ICFD.
The ICF may be fitted with a spindle for manual opening of the solenoid valve.

The ICF is designed to withstand a high internal pressure. However, the piping system should be designed to avoid liquid traps and reduce the risk of hydraulic pressure caused by thermal expansion.

It must be ensured that the ICF is protected from pressure transients like "liquid hammer" in the system.

Welding (fig. 2 and 3)

The ICF valve station can be welded by using either TIG/MIG/SAW welding (fig. 2) or gas welding/ brazing (fig. 3 a/b). Always keep inlet and outlet protecting caps on the valve until the valve is ready to be installed, in order to prevent rust formation inside the valve station.

TIG/MIG/SAW welding

It is not necessary to remove any of the function modules prior to TIG/MIG/SAW welding (fig. 2) and auxiliary cooling is not needed at normal heat impact.

At excessive heat impact due to high ambient temperature, sun radiation, a wet cloth is recommended around the valve housing.

Every precaution must be taken to minimize welding spatter.

For ICF valve stations equipped with a stop valve in the first module (M1) and a stop-, regulating- or stop/check valve in the last module (M4 or M6), it is recommended to open these valves slightly (approx. 1 turn from closed position) to minimize welding heat impact to the Teflon seats.

After welding it is recommended to close these valves again to avoid potential pull through of gases, and keep them closed until the system is ready for operation.
All other valve modules are able, in any module position, to compensate for normal welding heat impact and need no special attention.

Gas welding/ brazing

Remove all inserts before welding/ brazing (fig. 3 a/b).
Auxiliary cooling needed when brazing (fig. 3b) to reduce heat impact.

Follow these steps during brazing (fig. 3b):

1. Remove topcover/insert
2. Clean connections with cleaning agent
3. Wrap around wet cloth
4. Apply flux on piping ends
5. Apply inert gas internal
6. Heat up piping
7. Braze with recommended brazing material and within temperature range specified
8. Remove residual flux

Every precaution must be taken to minimize welding spatter.

After welding, clean the valve inside for welding spatter and welding debris.
It is recommended to reinstall the modules right after welding and to close the manual-operable M1 and M4/M6 in order to protect the interior of the valve until the system is ready for operation.
In case the valve is not assembled immediately make sure that rust protective oil is applied to the inside surfaces.

ENGLISH

The housing must be free from stresses (external loads) after installation. The ICF must not be mounted in systems where the outlet side of the ICF is open to atmosphere. The outlet side of the ICF must always be connected to the system or properly capped off, for example with a welded-on end plate.

Surface protection and identification (not applicable for SS versions)

The external surface is zinc-chromated to provide corrosion protection according to EN 12284:2003 8.13. The Zinc-Chromatization does not cover the welding connections. After installation has been completed the external surface of the valve must be protected against corrosion with a suitable top coating. Coverage of the ID label when painting the ICF is recommended.

Precise identification of the ICF is made via the ID label on each of the 2, 4 or 6 function modules.

Maintenance (fig. 4)



Do not mix up carbon steel parts with stainless steel parts.

Service

The ICF valve stations are easy to service. Do not open the ICF while it is still under pressure. Upon opening and removal of the function modules:

- Check that the flat gaskets and/or O-rings between the function module and the housing and O-rings on the function module has not been damaged. Replace flat gaskets and O-rings if not intact.

A valve with damaged O-rings or flat gaskets do not regulate in accordance with its specifications.

Flat gaskets are present in ICF 15 module M1/M2 and ICF 20-2/ICF 25/ICF SS 25 all modules.

Rubber gaskets are present in these locations: (see fig 4a, 4b)

ICF 15: 1 rubber gasket in each module M3/M4
ICF 20-4/6 and ICF SS 20-4/6: 1 rubber gasket in all modules



CO₂ applications

When used in CO₂ systems the O-rings (see fig. 4a and 4b) can swell (grow).

At service it is recommended to replace the actual number of used O-rings before the function modules are reinstalled in the ICF valve body.

ICFD 20C defrost module for CO₂:
Make sure that the module is type ICFD 20C

- Check that the piston and cylinder is free of scratches and look for wear marks. If the wear is excessive the function module should be replaced to prevent false pilot signal around the piston ring.
- Check that the movement of the cylinder and valve seat is free and with low friction.
- If the teflon valve plate has been damaged, the function module must be replaced.
- On ICM 20 motor valve modules check that the PEEK seat has not been damaged or scratched. If damaged or scratched; replace the PEEK seat. (Allen key 12 mm, torque 2 Nm (1.5 ft lb)).

Assembly

Remove any dirt from the housing before the ICF is assembled.

- Check that all channels in the ICF are free of particles or similar debris. If possible, apply some refrigeration oil to ease the insertion of the modules and to protect the O-rings.

Tightening (fig. 5, 6 and 7)

Tighten the top cover with a torque wrench, to the values indicated in the table (see fig. 5).

Operating the manual stem (fig. 6 to 8)

ICF 15, ICF 20, ICF SS 20 (fig. 6a and 6b)

- ICFS/ICFS SS - stop valve module
 - ICFR/ICFR SS - manual regulating valve module
 - ICFN/ICFN SS - stop/check valve module
 - ICFO/ICFO SS - manual opening module
- Before remounting the cap on the modules ICFS/ICFS SS (stop valve module), ICFR/ICFR SS (manual regulating valve module) or ICFN/ICFN SS (stop/check valve module) please ensure that the gasket is present in the cap. Then tighten the cap with 16 Nm (12 ft lbs).

ICF 25, ICF SS 25 (see fig. 7a)

- ICFS/ICFS SS - stop valve module
 - ICFR/ICFR SS - manual regulating valve module
 - ICFN/ICFN SS - stop/check valve module
 - ICFE/ICFE SS - manual opening module
- Before remounting the cap on the modules ICFS/ICFS SS (stop valve module), ICFR/ICFR SS (manual regulating valve module) or ICFN/ICFN SS (stop/check valve module) please ensure that the gasket is present in the cap. Then tighten the cap with 24 Nm (18 ft lbs).

Packing gland (ICFE/ICFE SS) (see fig. 7b):

If the packing gland is leaking, tighten it carefully with a wrench. Do not apply too much force.

Danfoss recommends that you conduct a stepwise tightening of the packing gland. For each turn check for possible leaks.

Operating the manual stem on ICFE 25/ICFE SS 25 solenoid module (see fig. 8a):

To force open the solenoid by the manual stem turn it **counter clockwise** full way up (manual mode).

To operate the solenoid in automatic mode, turn the manual stem **clockwise** until the locking ring stops.

Do not force the spindle further. If the locking ring is damaged or removed the spindle will start to leak.

The valve cannot be forced closed by the manual stem.

Operating the manual stem on ICFE 20H/ICFE SS 20H solenoid valve module (see fig. 8b)

Remove the cap on the side of the ICFE 20H/ICFE SS 20H

At 9 o'clock position the manual opener is disabled (not active).

To force the ICFE 20H/ICFE SS 20H solenoid to open use a 5 mm Allen key and turn it clockwise to 3 o'clock position.

ICFD defrost module

Transportation protection

Remove the transport security device (pos. 1 in fig 10). Insert the drain plug + alu gasket attached to the valve (pos. 2 in fig 10) and tighten with the torque indicated.

Test pressure maximum

If the system test pressure needs to exceed:
ICFD 20 (Ammonia): 28 bar g / 406 psi g
ICFD 20C (CO₂): 52 bar g / 754 psi g
it is necessary to prepare the ICFD module like shown in fig. 11:

1. Unscrew the 6 flange bolts and remove the Float housing.
2. + 3. Unscrew and remove the Lever together with the Float assembly using A/F 4 mm. **Caution** - float end of lever must not be unscrewed and do not use float for unscrewing.
4. Remount the Float housing and tighten the 6 flange bolts with the torque indicated in fig 10.
5. Test with the system pressure higher than:
ICFD 20 (Ammonia): 28 bar g / 406 psi g
ICFD 20C (CO₂): 52 bar g / 754 psi g
6. Reinstall the Lever together with the Float assembly using A/F 4 mm. Do not use float for tightening.
7. Remount the Float housing and tighten the 6 flange bolts with the torque indicated in fig 10.

It is recommended to replace the float housing gasket with a new gasket after this repeated compression.

Operating the manual stem on ICFD defrost module (see fig. 12)

Remove the cap on the side of the ICFD (pos. A in fig. 10).

At 9 o'clock position the manual opener is disabled (A = Automatic mode).

To force the ICFD to open use a 5 mm Allen key and turn it clockwise to approx.

2 o'clock position till it reaches the mechanical stop (M = Manual open mode).

Always return the manual opener to automatic mode for normal operation.

Remount the cap A in fig 10 and tighten with torque 80 Nm (59 ft lbs).

It is recommended to replace the Alu gasket if further openings of cap are required.

Operating the manual stem on ICFG 25 (see fig. 8a)

Always pay attention to the spindle during operation of the manual opener

1. Make sure that the locking ring is positioned on the spindle and is intact. A new locking ring is available in the inspection kit for the valve.
2. Pay attention to the locking ring reaching the top nut of the packing gland when turning the manual stem **clockwise** for opening the valve. **Never use excessive torque and stop turning when the locking ring gets in contact with the top nut.**
3. When turning the spindle **counter clockwise**, for deactivation of the manual opener, to the top point, tighten the spindle further counter clockwise to 8 Nm (5.9 lb/ft) torque.

ENGLISH

Module location (fig. 9a, 9b, 9c)

ICF with two modules

Function	Module Type	Can be installed in these locations	
ICFE/ICFA	Solenoid valve module	M1	
ICFE20H	Solenoid valve module	M1*	
ICFO	Manual opening module		M2
ICFB	Blank top cover	M1	M2
ICFW	Welding module	M1	M2
ICFC	Check valve module		M2
ICFC 20P1	Check valve module		M2
ICFN 20	Stop & check valve module		M2
ICFR	Manual regulating valve module	M1	M2
ICM	Motor valve module	M1	
ICFD 20	Defrost module		M2
ICFS	Shut-off valve module	M1	M2
ICFF	Strainer module		M2
ICM	Motor operated valve module	M1	

*) Not in combination with ICFO

ICF with four modules

Function	Module Type	Can be installed in these locations			
ICFS/ICFS SS	Stop valve module	M1 *)	M2	M3	M4
ICFR/ICFR SS	Manual regulating valve module	M1	M2	M3	M4
ICFF/ICFF SS	Filter (strainer) module		M2 *)		M4
ICFE/ICFE SS	Solenoid valve module			M3	
ICFC/ICFC SS	Check valve module				M4
ICFN / ICFN SS	Stop/check valve module				M4
ICM/ICM SS	Motor valve module	M1		M3	
ICFB/ICFB SS	Blank top cover	M1	M2	M3	M4
ICFA/ICFA SS	Electronic expansion valve module (not for ICF 25)	M1		M3	
ICFE 20H/ICFE SS 20H	Solenoid valve module (not for ICF 25)	M1		M3	
ICFO/ICFO SS	Manual opening module (not for ICF 25)				M4
ICFW/ICFW SS	Welding module	M1	M2	M3	M4
ICFD	Defrost module		M2		M4
ICFG	Pilot-operated servo module			M3	

ICF with six modules

Function	Module Type	Can be installed in these locations					
ICFS/ICFS SS	Stop valve module	M1	M2	M3	M4	M5	M6
ICFR/ICFR SS	Manual regulating valve module	M1	M2	M3	M4	M5	M6
ICFF/ICFF SS	Filter (strainer) module		M2		M4		M6
ICFE/ICFE SS	Solenoid valve module			M3			
ICFC/ICFC SS	Check valve module				M4		M6
ICFN / ICFN SS	Stop/check valve module				M4		M6
ICM/ICM SS	Motor valve module	M1		M3		M5	
ICFB/ICFB SS	Blank top cover	M1	M2	M3	M4	M5	M6
ICFA/ICFA SS	Electronic expansion valve module (not for ICF 25)	M1		M3		M5	
ICFE 20H/ICFE SS 20H	Solenoid valve module (not for ICF 25)	M1		M3		M5	
ICFO/ICFO SS	Manual opening module (not for ICF 25)				M4		
ICFW/ICFW SS	Welding module	M1	M2	M3	M4	M5	M6
ICFD	Defrost module		M2		M4		M6
ICFG	Pilot-operated servo module			M3			

Module locations are indicated by M1, M2, M3, M4, M5 and M6. With respect to refrigerant flow, M1 is closest to inlet.

location not possible

*) ICF 15 - M1 and M2 modules are fixed (stop valve and filter, respectively)

Use only original Danfoss parts, including O-rings and gaskets for replacement.
Materials of new parts are certified for the relevant refrigerant.
In cases of doubt, please contact Danfoss.

Appendix F

Hand-Held Slide Valve Calibration Tool

Hand-Held Slide Valve Calibration Tool
By Vilter™ (VPN 75002)

The Slide Valve Calibration Tool allows the operator to perform the calibration procedure of Vilter’s slide valve actuators (VPN 25972D) single-handedly, while standing at the actuator, without multiple trips to the panel screen, or the need of another person at the panel.

How It Works

The calibration tool replaces the power cable that feeds the actuator during normal operation, and provides 115 volts to the actuator motor using the CW and CCW push buttons. The regular control cable which provides 24 volts DC to the actuator must be connected at all times.

The greatest advantage from this set up is that the operator can perform the whole calibration procedure in front of the compressor, and therefore can easily detect if the actuator is driving the slide valves up against the mechanical stop inside the compressor.

Calibration Procedure

- 1. Look for the motor control cable on the actuator (connector J2), and disconnect it. Connect the calibration tool’s turck connector to the actuator.
- 2. Remove the screws securing the actuator cover to the actuator assembly, and carefully lift the actuator cover and tilt it towards connectors. Raise the cover high enough to attain access to the blue calibration button and be able to see the red LED on the top of assembly.
- 3. Press “CW” or “CCW” on the calibration tool to move the slide valve and check for the correct rotation, see the Increase Direction for **Single Screw Compressors Table** on the next page to establish which one is the **increase** button and which one the **decrease** button for your compressor model.



For use in non-hazardous locations
(VPN: 75002)

Features

The calibration procedure may be performed directly at the actuator, so the operator can immediately detect when the actuators start to slow down and reach the mechanical stop
Using this tool bypasses the standard calibration procedure which requires several trips between the actuator and the control panel, or to have two operators available
Electrical Rating of 125V and 5A (not fuse protected)
Light and easy to move around the compressors room
Pendant switch for easy access and comfortable handling


- 4. Quickly press and release the blue push button on the actuator once. This places the actuator in calibration mode. The red LED will start flashing rapidly.
- 5. Use the **decrease** button on the calibration tool to drive the slide valve to its minimum “mechanical stop” position. Release the **decrease** button when the slowing of the motor rotation and a winding sound from the actuator motor is noted.
- 6. Press and hold down on the photo-chopper shaft to disengage the brake slowly, releasing tension from the motor mount. Use the **increase** button to pulse the actuator to where the slide is just off of the mechanical stop and there is no tension on the motor shaft.

Appendix F • Hand-Held Slide Valve Calibration Tool

Slide Valve Increase Direction for Single Screw Compressors Table

Compressor Model Number	Capacity Slide Valve	Volume Slide Valve
VSCC 291	CW	CW
VSCC 341	CW	CW
VSCC 451	CW	CW
VSCC 601	CW	CW

7. Quickly press and release the blue button on the actuator again. The red LED will now flash at a slower rate, indicating that the minimum slide valve position (zero position) has been set.
8. Use the increase button on the calibration tool to drive the slide to its maximum “mechanical stop” position. Release the increase button when the slowing of the motor rotation and a winding sound from the actuator motor is noted.
9. Press and hold down on the photo-chopper shaft to disengage the brake slowly, releasing tension from the motor mount. Use the decrease button to pulse the actuator to where the slide is just off of its mechanical stop and there is no tension on the motor shaft.
10. Quickly press and release the blue button on the actuator one more time. The red LED will stop flashing. The actuator is now calibrated and knows the minimum and maximum positions of the slide valve it controls.
11. Disconnect the calibration tool’s turck from the actuator, and connect the motor control cable on the actuator (connector J2).



Order Vilter Slide Valve Calibration Tool
Using VPN 75002

General Inquiries

5555 S. Packard
Ave.
Cudahy, WI 53110
United States
Phone: 414-373-
7615
Fax: 414-744-
3483

Web: www.Vilter.com

Customer Service

Phone: 1-800-862-2677
Service.Vilter@copeland.com

Parts

Parts.Vilter@Copeland.com

For more product information and to order online visit:
VPI.Copeland.com

About Vilter

Vilter is a technology leader in energy-efficient, environmentally conscious solutions in its industry. The 150-year history of the Vilter brand tells a rich story of perseverance and drive to cultivate continuous innovation within the industrial refrigeration and gas compression industries. Vilter offers unprecedented efficiency, productivity and reliability in cooling, recovery, and compression. It combines best-in-class technology with proven engineering and design to create quality products and latest solutions for customers worldwide.

About Copeland

Vilter is a business segment of Copeland, a global leader in providing sustainable climate solutions for customers in industrial, commercial and consumer markets around the world. Copeland combines category-leading brands in compression, controls, software and monitoring for heating, cooling and refrigeration. With best-in-class engineering and design and the broadest portfolio of modulated solutions, we're not just setting the standard for compressor leadership; we're pioneering its evolution. Combining our technology with our smart energy management solutions, we can regulate, track, and optimize conditions to help protect temperature-sensitive goods over land and sea, while delivering comfort in any space. Through energy-efficient products, regulation-ready solutions, and expertise, we're revolutionizing the next generation of climate technology for the better. For more information please visit

[Copeland.com](https://www.copeland.com)

[Copeland.com/Vilter](https://www.copeland.com/Vilter)

Copeland Industrial LP (Vilter) reserves the right to make changes in design and specifications without notice.
35391SUB Rev. 0 (03/25) Copeland and Vilter are trademarks of Copeland or one of its affiliated companies.
©2025 Copeland LP. All rights reserved.

COPELAND. ENGINEERED FOR SUSTAINABILITY.