

Mounting Bracket

9424

For Multi-Function Thermometer

The 9424 Mounting bracket is designed for convenient storage of the Multi-Function Thermometer. The bracket is made of high-impact ABS plastic, making it durable and easy to keep clean. For the best results, mounting location should be a clean smooth plastic or metal surface.

Mounting Instructions:

- Determine suitable location to mount bracket with room above and below the bracket for the MFT Instrument and probe.
- For the best results, mounting location should be a clean smooth plastic or metal surface.
- Clean the mounting location and bracket surface using alcohol.
- Remove the paper liner from the foam tape and apply to the back of the bracket. Tape should be applied flush with the top/bottom edge and centered on the bracket face.
- Remove the red liner from the foam tape and press the bracket against the mounting surface with the wide opening facing up. Apply even pressure for at least 10 to 20 seconds.
- For the best adhesion results, wait 24 hours before using the bracket for holding the MFT Instrument.
- Alternate mounting: If supplied, mount using the (2) screws and wall anchors as needed. Install screws 1" apart and tighten the screws to secure bracket against the wall.

